

SONY®

VIDEOCASSETTE PLAYER

BVW-10P



BETACAM

OPERATION AND MAINTENANCE MANUAL

2nd Edition

Serial No. 10201 to 10300

ご注意

このマニュアルに記載されている事柄の著作権は当社にあり、説明内容は機器購入者の使用を目的としています。

従って、当社の許可なしに無断で複写したり、説明内容(操作、保守等)と異なる目的で本マニュアルを使用することを禁止します。

CONFIDENTIAL

The material contained in this manual consists of information that is the property of Sony Corporation and is intended solely for use by the purchasers of the equipment described in this manual.

Sony Corporation expressly prohibits the duplication of any portion of this manual or the use thereof for any purpose other than the operation or maintenance of the equipment described in this manual without the express written permission of Sony Corporation.

CONFIDENTIEL

Le matériel contenu dans ce manuel consiste en informations qui sont la propriété de Sony Corporation et sont destinées exclusivement à l'usage des acquéreurs de l'équipement décrit dans ce manuel.

Sony Corporation interdit formellement la copie de quelque partie que ce soit de ce manuel ou son emploi pour tout autre but que des opérations ou entretiens de l'équipement à moins d'une permission écrite de Sony Corporation.

VERTRAULICH

Das in dieser Anleitung enthaltene Material besteht aus Informationen, die Eigentum der Sony Corporation sind, und ausschließlich zum Gebrauch durch den Käufer der in dieser Anleitung beschriebenen Ausrüstung bestimmt sind.

Die Sony Corporation untersagt ausdrücklich die Vervielfältigung jeglicher Teile dieser Anleitung oder den Gebrauch derselben für irgendeinen anderen Zweck als die Bedienung oder Wartung der in dieser Anleitung beschriebenen Ausrüstung ohne ausdrückliche schriftliche Erlaubnis der Sony Corporation.

TABLE OF CONTENTS

INHALTSVERZEICHNIS

1. OPERATION

1-1.	Features	1-1 (E)
1-2.	Location and Function of Controls	1-2 (E)
1-2-1.	Control Panel	1-2 (E)
1-2-2.	Connector Panel	1-4 (E)
1-2-3.	Sub Control Panel	1-6 (E)
1-3.	Connections	1-8 (E)
1-3-1.	Playback	1-8 (E)
1-3-2.	Editing with Two VTRs	1-9 (E)
1-3-3.	Editing with a Control Unit	1-11(E)
1-4.	Cassette Insertion and Removal	1-13(E)
1-5.	Playback	1-14(E)
1-5-1.	Preparation	1-14(E)
1-5-2.	Operation	1-14(E)
1-5-3.	Adjustments	1-15(E)
1-5-4.	Tape Protection Devices	1-15(E)
1-6.	Check Routines	1-16(E)
1-7.	Head Cleaning	1-19(E)
1-8.	Specifications	1-19(E)
1-9.	Repacking for Shipment	1-22(E)

1. BETRIEB

1-1.	Besondere Merkmale	1-1 (G)
1-2.	Lage und Funktion der Bedienelemente	1-2 (G)
1-2-1.	Bedienungsfeld	1-2 (G)
1-2-2.	Anschlußfeld	1-4 (G)
1-2-3.	Hilfsbedienungsfeld	1-6 (G)
1-3.	Anschlüsse	1-8 (G)
1-3-1.	Wiedergabe	1-8 (G)
1-3-2.	Schneiden mit zwei Videorecordern	1-9 (G)
1-3-3.	Schneiden mit einer Steuereinheit	1-11(G)
1-4.	Einlegen und Herausnehmen der Cassette	1-13(G)
1-5.	Wiedergabe	1-14(G)
1-5-1.	Vorbereitung	1-14(G)
1-5-2.	Betrieb	1-14(G)
1-5-3.	Einstellungen	1-15(G)
1-5-4.	Bandschutzeinrichtungen	1-15(G)
1-6.	Überprüfungen	1-16(G)
1-7.	Reinigung der Köpfe	1-19(G)
1-8.	Technische Daten	1-19(G)
1-9.	Wiederverpackung zum Transport	1-22(G)

2. INSTALLATION

2-1.	Operational Environment	2-1
2-2.	Installation Space	2-1
2-3.	Operating Voltage	2-2
2-4.	Connectors for Optional Connection	2-2
2-5.	Input/Output Signal of the Connector	2-2
2-6.	Select Switch Setting	2-4
2-7.	Rack Mounting	2-5

2-8.	Supplied Accessory	2-6
2-9.	Optional Accessory	2-6

3. TECHNICAL INFORMATION

3-1.	Specifications	3-1
3-2.	Location of the Printed Circuit Board	3-3
3-3.	Location of the Mechanical Main Parts/Components	3-6
3-4.	Printed Circuit Boards	3-7

4. PERIODIC CHECK AND MAINTENANCE

4-1.	System Control Operation Check	4-1
4-2.	Maintenance Time Table	4-3
4-3.	Hours Meter	4-4
4-4.	Cleaning Procedure	4-4
4-4-1.	Video Head	4-4
4-4-2.	Stationary Heads	4-4
4-4-3.	Tape Movement Areas	4-4
4-5.	Maintenance after Repairs	4-4

5. SERVICE INFORMATION

5-1.	Removal of Cabinet	5-1
5-2.	Removal of Cassette-up Compartment	5-2
5-3.	Note for Check and Maintenance of Printed Circuit Board	5-2
5-4.	Module Extender	5-2
5-5.	Spare Parts	5-2
5-6.	To Operate the Machine without Installing Cassette Tape	5-2
5-7.	Maintenance of KY or DE Board	5-3
5-8.	Cassette Removal Procedure when the Tape is Slacken in the Machine.	5-3

17. SEMICONDUCTOR ELECTRODES

Semiconductor Electrodes	17-1
--------------------------	------

18. PRINTED WIRING BOARD AND SCHEMATIC DIAGRAM

VIDEO

PB-8	18-2
YD-15	18-5
CD-25	18-11
CF-12	18-17
CK-14	18-22
MY-17	18-40
PR-48	18-58
EN-20	18-76

AUDIO

AU-37	18-94
-------	-------

TABLE OF CONTENTS

SERVO

SV-51 18-101

SYSTEM CONTROL

SY-91 18-128

TIME CODE

TC-25 18-146

POWER SUPPLY/DRIVER

PS-16 18-151

CONTROL/CONNECTOR PANEL

CP-52 18-155

SW-85 18-155

VR-8 18-155

HP-7 18-155

LA-4 18-155

CP-56 18-159

SW-86 18-159

ST-22 18-163

KY-32 18-167

DP-30 18-167

PC-9 18-171

PC-14 18-171

RE-6 18-173

FRAME

DE-12 18-175

DE-11 18-175

SS-8 18-175

HE-5 18-175

PH-16 18-179

LE-19 18-179

SS-8 18-179

CL-7 18-181

PC-17 18-181

PC-18 18-181

LM-4 18-183

PD-20 18-184

TE-2 18-185

TR-14 18-186

AC-40 18-187

MB-41 18-189

MB-42 18-197

FRAME 18-203

Gear Box Block 19-16

Level Control Chassis Block 19-17

Function Control Chassis Block 19-19

Connector Panel Block 19-21

TBC Control Block 19-23

Chassis Block (1) 19-24

Switching Regulator 19-26

Switching Regulator (UR-06) 19-26

Switching Regulator (UR-07) 19-26

Cassette-up Compartment 19-29

Ornamental Panel Block (1) 19-31

Ornamental Panel Block (2) 19-33

Printed Circuit Board Block (1) 19-35

Printed Circuit Board Block (2) 19-37

Extension Board Block 19-39

19-31 Electrical Parts List 19-41

19-41 Packing Material 19-74

and Accessory (Supplied) 19-74

19. SPARE PARTS AND FIXTURE

19-1. Parts Information 19-1

19-2. Exploded View 19-1

Take-up Side Reel Chassis 19-5

Supply Side Reel Chassis 19-7

Head Drum, Stationary Heads and

Tape Guides Block 19-9

Threading Ring Block 19-11

Pinch Press Mechanism Block 19-13

Supply Tension Regulator Block 19-14

SECTION 1 OPERATION

The BVW-10P is a videocassette player for editing, and playing back a 1/2-inch Beta format video cassette tape recorded on the newly developed Betacam series VTR for the ENG (Electronic News Gathering) system.

Electronic editing can be done using the U-matic VTR BVU-800P, BVU-820P or the 1-inch VTR BVH-2000PS with or without the BVE-series editing control unit.

1-1. FEATURES

High quality picture

Even though only a 1/2-inch video cassette in the Beta format is used, the playback picture recorded on the newly developed Betacam series VTR is close to that recorded on the 1-inch VTR.

Front access

Every operation, including cassette insertion and removal, can be performed from the front panel, which can be tilted up to 90° (6 steps) to suit your preference.

Direct drive system with DC motors

Quick access to editing points is possible since independent DC motors drive the drum assembly, capstan assembly, supply and take-up reels and the tension on the tape is precisely set by a servo system.

Quick access to the editing points

Search functions providing a recognizable picture in the shuttle mode (in which the playback speed can be varied in 16 steps from $\frac{1}{30}$ to 10 times normal speed in both forward and reverse) and the jog mode (in which the picture changes as the search dial moves), enable operators to locate the editing point more quickly.

Picture in color can be monitored at the speed from -5 to +5 times normal speed.

Built-in time code reader

Time code reading and playback are possible using the built-in time code reader.

Connection with the video recorder

This player can be directly connected to a recorder such as a BVU-800P, BVU-820P, BVH-2000PS, and can be remotely controlled with the recorder.

Editing using a Sony BVE-series editing control unit is also possible.

Digital time counter

The time counter indicates the time code or the amount of tape advancement by counting the CTL signals, and facilitates locating editing points precisely.

Editing/duplicating connectors

The DUB OUT connector for U-matic H VTR allows editing and duplicating of video signals with little degradation.

Furthermore, a component signal of the luminance and chrominance can be obtained from the DUB/COMP OUT connector.

Built-in time base corrector (TBC)

Built-in TBC makes possible a stable playback picture.

Audio noise reduction system

The BVW-10P employs the newly-developed C-type Dolby NR* system for audio tape noise reduction. You can turn on and off this audio noise reduction system according to the tape to be used.

Auto rewind/auto stop

At the end of the tape, the tape rewinds automatically to the beginning. (Auto rewind)

At the top of the tape, the tape stops automatically. (Auto stop)

Plug-in type boards

Plug-in boards are designed for ease of service and maintenance. They are reached by simply removing the top panel.


Mountable in standard 19" rack

The BVW-10P can be mounted in a standard 19" rack. For rack mounting, refer to the Section 2.

* "Dolby" and the double-D symbol are trade marks of the Dolby Laboratories Licensing Corporation. Noise reduction system manufactured under license from Dolby Laboratories Licensing Corporation.

1-2. LOCATION AND FUNCTION OF CONTROLS

1-2-1. Control Panel



① POWER switch
Press the ON side to turn the power on. The lamp for the meters will light up.

② AUDIO LEVEL CH-1/CH-2 meters
Indicate the audio output level when the unit is in the playback mode.

③ AUDIO LEVEL CH-1/CH-2 controls
Adjust the audio output level of channel 1 and channel 2. To adjust the level, turn the controls so that the meter pointers swing up to "0" at the reference output level.

④ TRACKING meter
Indicates the FM signal level of the playback.

⑤ TRACKING control
Adjusts the tracking of the tape.
Normally, set to the center FIXED position.
When noise appears in the playback picture, turn the control to the left or right so that the TRACKING meter ④ pointer deflects to the maximum value. After the playback of that particular tape, return the control to the FIXED position.

⑥ AUDIO MONITOR selector
Selects the audio output signal from the HEADPHONES jack ⑧, the AUDIO MONITOR OUT connector (XLR) and the MONITOR connector (8 pin) on the rear panel.
CH-1: Audio channel 1 sound.
MIX: From the HEADPHONES jack, channel 1 sound from the left and channel 2 sound from the right.
From the AUDIO MONITOR OUT and the MONITOR connectors, mixed sound of both channels.
CH-2: Audio channel 2 sound.

⑦ REMOTE/LOCAL selector
REMOTE 1 (9P): Set to this position when the unit is to be remotely controlled by the equipment connected to the 9-pin REMOTE 1 connector on the rear panel. The function buttons on the BVW-10P (except the STOP and EJECT buttons) will be inoperative.
LOCAL: Set to this position when the unit is to be operated with its own function buttons.
REMOTE 2 (36P): Set to this position when the unit is to be remotely controlled by the equipment connected to the 36-pin REMOTE 2 connector on the rear panel. The function buttons on the BVW-10P (except the STOP and EJECT buttons) will be inoperative.

⑧ HEADPHONES jack (stereo phone type) and volume control

Connect 8-ohm stereo headphones here. The audio during playback can be monitored. The volume control adjusts the headphone volume.

⑨ STANDBY button

Whenever the head drum is rotating, the STANDBY button lights up, indicating that the unit is in the standby-on mode. If the STANDBY button is pressed in the stop mode, the head drum will stop and the unit will be in the standby-off mode. To resume the standby-on mode, press the STANDBY button again.

⑩ EJECT button

When this button is pressed, the cassette is ejected.

- Be sure to eject the cassette after every use before the power is turned off.

⑪ REW (rewind) button

Press to rewind the tape.

⑫ PLAY button

Press to play back the tape.

⑬ F FWD (fast forward) button

Press to advance the tape rapidly.

- In the following cases, the fast forward speed may be slowed down at about the center portion of the tape but this is not a problem.
 - The first fast forward after the cassette being inserted
 - The first fast forward after turning the power on

⑭ STOP button

Press to stop the tape.

In the stop mode, a still picture can be obtained because the head drum rotates and the tape is threaded.

The unit goes into the stop mode just after the cassette is inserted.

⑮ SEARCH button

Press to set the unit in the search mode; then the shuttle or jog function can be used. The lamp will light during the search mode.

⑯ Search dial

To locate the desired editing points quickly, use this dial. Pressing the dial in sets the unit in the jog mode and pressing it again and releasing it sets the unit in the shuttle mode. The appropriate lamp lights.

SHUTTLE: Turn the dial to the right or left. The tape speed can be varied from $\frac{1}{30}$ to approximately 10 times normal in either direction.

In the center (□) position, a still picture can be obtained.

JOG: Rotate the dial to the right or left. The tape moves in the direction and at the speed of rotation, from still to 1 time normal speed. When you stop rotating the dial, a still picture will be obtained.

- Be sure to set the dial to the □ position once before use when the power is turned on.

⑰ CTL/TIME CODE selector

Selects the indication on the time counter: CTL or time code.

When the REMOTE/LOCAL selector is set to REMOTE 1, the mode selected by the connected equipment will be indicated regardless of the setting of this selector.


⑱ Time counter

Indicates in hours, minutes, seconds and frames the tape position by reading the time code on the tape when the CTL/TIME CODE selector ⑰ is set to TIME CODE. When the selector is set to CTL, the time counter indicates how much the tape has advanced by counting the CTL signals.


⑲ RESET button

Press to set the counter number to "0:00:00:00" when the time counter is in the CTL mode. This button will not operate when the time counter indicates the time code.

Control panel positioning



1-2-2. Connector Panel



① DUB OUT (U-matic H) connector (7-pin, female)

The dubbing video signal is supplied.

Connect to the DUB IN connector of the U-matic H VTR using a dubbing cable (optional).

② DUB/COMP OUT connector (12-pin, female)

The component signal of the luminance (Y) and the chrominance (R-Y, B-Y) is supplied.

③ REF VIDEO IN (reference video input) connectors (BNC type)

Connect the reference video signal to either connector.

The other can be used as a looping output connector (bridge connector) to other video equipment. When only one of these connectors is to be used, set the 75Ω ON/OFF switch ④ to ON.

④ 75Ω ON/OFF switch

This is the video input 75 ohm termination switch.

ON: Normal position.

OFF: When one of the REF VIDEO IN connectors is being used as a looping output connector.

⑤ VIDEO OUT connectors (BNC type)

The composite video signal is supplied.

Connect to a video monitor or another VTR.

Video signal output from the VIDEO OUT 2 connector can be switched to the non-composite signal by using a switch on the printed circuit board. For details, see the Section 2.

⑥ TIME CODE OUT connector (BNC type)

The time code is supplied.

Connect to the TIME CODE IN connector of the time code reader or the VTR.

⑦ AUDIO OUT CH-1/CH-2 connectors (XLR, male)

Audio signals adjusted by the AUDIO LEVEL controls on the control panel are supplied.

⑧ AUDIO MONITOR OUT connector (XLR, male)

Connect audio equipment for monitoring. The output signal is selected by the AUDIO MONITOR selector on the control panel.

⑨ MONITOR connector (8-pin)

Video and audio signals are supplied.

Connect a color monitor with an optional monitor connecting cable. The audio output signal from this connector is selected by the AUDIO MONITOR selector on the control panel.

⑩ REMOTE 1 (9P) connector (9-pin, RS-422 spec.)

Connect equipment with a 9-pin remote control connector: either a VTR such as a BVU-800P, BVU-820P or BVH-2000PS using a supplied remote control cable, or an editing control unit such as a BVE-800, BVE-5000P.

⑪ REMOTE 2 (36P) connector (36-pin)


Connect a BVE series editing control unit such as a Sony BVE-500ACE, BVE-5000P, using an optional 36-pin remote control cable.

- The Sony BVR-510ACE remote control unit cannot be used.


⑫ AC IN connector

Connect to a wall outlet with the ac power cord supplied.

1-2-3. Sub Control Panel



Inside the control panel



① VIDEO control and its PRESET/MANUAL switch

When the PRESET/MANUAL switch is set to:

MANUAL: The composite video signal output level can be adjusted within a range of ± 3 dB by using the VIDEO control. As for the chroma level adjustment range, the total adjustment range cannot exceed +3 dB when used with the CHROMA control.

PRESET: The output video level is set at the preset level regardless of the position of the control.

② CHROMA control and its PRESET/MANUAL switch

When the PRESET/MANUAL switch is set to:

MANUAL: The output chroma level can be adjusted within a range of ± 3 dB by using the CHROMA control. The total adjustment range cannot exceed +3 dB, however, when used with the VIDEO control.

PRESET: The output chroma level is set at the preset level regardless of the position of the control.

③ BLACK LEVEL control and its PRESET/MANUAL switch

When the PRESET/MANUAL switch is set to:

MANUAL: The output black level can be adjusted within a range of 0 to +15 IRE by using the BLACK LEVEL control.

PRESET: The output black level is set at the preset level regardless of the position of the control.

④ Y/C DELAY control and its PRESET/MANUAL switch

When the PRESET/MANUAL switch is set to:

MANUAL: The Y/C delay difference can be adjusted within a range of ± 50 nsec.

PRESET: The Y/C delay difference is set at the preset value regardless of the position of the control.

⑤ SYSTEM SYNC PHASE control

Adjusts the output sync phase with respect to the reference input to the BVW-10P within a range of $-1 \mu\text{sec}$ to $+3 \mu\text{sec}$. Use this control, for instance, to bring the output phase in line with the broadcast's reference, or when two or more VTRs are being used with this unit to produce special effects such as fades and lap-dissolve.

⑥ SYSTEM SC PHASE control

Adjusts the output subcarrier phase with respect to the reference input to the BVW-10P within a range of 360° p-p. Use this control, for instance, to bring the output phase in line with the broadcast's reference, or when two or more VTRs are being used with this unit to produce special effects such as fades and lap-dissolve.

⑦ AUDIO NR (audio noise reduction) switch


This unit employs the C-type Dolby NR system for audio tape noise reduction.

ON: To play back the tape recorded with the Dolby NR process, set the switch to this position.

OFF: To play back the tape recorded without the Dolby NR process, set the switch to this position.


⑧ HOURS METER

This meter indicates the total elapsed time that the video head drum has rotated (max. 1000 hours).




1-3. CONNECTIONS


1-3-1. Playback



1-3-2. Editing with Two VTRs




1-3-3. Editing with a Control Unit



1-4. CASSETTE INSERTION AND REMOVAL

To insert a cassette




To remove a cassette

Press the EJECT button while the POWER switch is set to ON.


Note: Remove the cassette after every use.

1-5. PLAYBACK

1-5-1. Preparation



1-5-2. Operation



To start playback

Press the **PLAY** button.

The **PLAY** lamp will light up.

To stop playback

Press the **STOP** button.

The **PLAY** lamp will go off and the **STOP** lamp will light up.

- If the tape reaches the end, it will automatically rewind to the beginning and stop.

1-5-3. Adjustments

Tracking adjustment

Normally, set the TRACKING control at the FIXED position.

If noise appears on the playback picture, turn the TRACKING control to the left or right so that the pointer of the TRACKING meter deflects to the maximum value.

- When the playback of that particular tape is finished, return the control to the FIXED position.

Audio level adjustment

Adjust the AUDIO LEVEL controls for channels 1 and 2 so that the AUDIO LEVEL meters read approximately zero at the reference output level.

1-5-4. Tape Protection Devices

Tape protection

To protect the tape and the video heads, the unit will go into the tape protection mode if the tape is stopped for more than 8 minutes. There are two cases:

- If the unit stays in the stop mode for more than 8 minutes, the unit will go into the standby-off mode; the head drum will stop rotating, the tape will slacken and the STANDBY lamp will go off.

To set the unit into the desired function mode, press the appropriate button.

To obtain a still picture from the standby-off mode, press the STANDBY button.



- If a still picture is displayed more than 8 minutes in the search mode, the tape will then advance in the forward direction at $1/30$ normal speed.

Moisture condensation

If moisture condenses inside the player, the internal protection circuit will activate; the drum and the capstan motors will stop and the AUTO OFF lamp on the front panel will light. The cassette will be ejected if present. Then the drum will begin rotating again to quickly dry the drum assembly.

- Do not operate the unit for at least 10 minutes after you transport the unit directly from a cold location to a warm location as it takes a few minutes until moisture condenses on the head drum and causes the lamp to light. After 10 minutes, turn on the POWER button and check the following.

- If the lamp does not light: Operate the unit normally.
- If the lamp lights: Leave the unit with the power on and wait until the lamp goes off. While the lamp is lit, a cassette cannot be inserted.




1-6. CHECK ROUTINES

We recommend checking that the unit operates properly before every use.


- After checking, set the switches for later use.

Preparation


First, connect a video and audio monitor and prepare a video cassette tape on which video signals and audio CH-1 and CH-2 signals are recorded (do not use an alignment tape).



View of exterior




Dimensions of rack mounting (Side panels removed)



Unit: mm (inch)

1-9. REPACKING FOR SHIPMENT

adhesive to wall



TEIL 1

BETRIEB

Der BVW-10P Videocassetten-Spieler dient zum Schneiden und zum Wiedergeben einer 1/2-Zoll Beta-Format Videocassette, die auf der neuentwickelten Betacam Videorecorder aus dem ENG (Electronic News Gathering)-System bespielt wurde.

Zum elektronischen Schneiden können der U-matic Videorecorder BVU-800P oder BVU-820P sowie der 1-Zoll Videorecorder BVH-2000PS verwendet werden. Wahlweise können diese Geräte auch über eine Schnittsteuereinheit der BVE-Serie betrieben werden.

1-1. BESONDERE MERKMALE

Hohe Bildqualität

Obwohl nur eine 1/2-Zoll Beta-Format Videocassette verwendet wird, erhält man bei der Wiedergabe eines Bandes, das auf dem neuentwickelten Videorecorder der Betacam-Serie bespielt wurde, eine hohe Bildqualität, die der eines 1-Zoll Videorecorders kaum nachsteht.

Bequeme Bedienung an der Vorderseite

Alle Bedienungsvorgänge einschließlich Einlegen und Herausnehmen der Cassette, können an der Vorderseite durchgeführt werden. Zur bequemer Bedienung kann der untere Teil des Bedienungsfeldes in 6 Stufen bis um 90° verstellt werden.

Direktantriebssystem mit Gleichstrommotoren

Um schnellen Zugriff zu den Schnittpunkten zu ermöglichen sind unabhängige Gleichstrommotoren zum Antrieb von Kopftrommel, Capstan, Aufwickel- und Abwickelspulen vorgesehen, wobei ein Servosystem für eine präzise Einhaltung der Bandspannung sorgt.

Schneller Zugriff zu den Schnittpunkten

Eine Suchfunktion mit erkennbarem Bild im Schuttle-Betrieb (die Wiedergabegeschwindigkeit kann in 16 Schritten von $\frac{1}{30}$ bis 10fache Normalgeschwindigkeit in Vorwärts- und Rückwärtsrichtung variiert werden) und im Jog-Betrieb (das Bild ändert sich entsprechend der Bewegung des Suchlaufknopfes) ermöglichen ein schnelleres Auffinden der Schnittpunkte. Im Bereich -5facher bis +5facher Normalgeschwindigkeit erhält man ein Farb-Monitorbild.

Eingebauter Zeitcodeleser

Durch den eingebauten Zeitcodeleser ist ein Lesen und ein Wiedergeben des Zeitcodes möglich.

Anschlußmöglichkeit für Videorecorder

Der BVW-10P kann direkt an Recorder wie z.B. BVU-800P, BVU-820P, BVH-2000PS angeschlossen und von dem Recorder aus fernbedient werden.

Zum Schneiden kann auch die Schnittsteuereinheit der Sony BVE-Serie verwendet werden.

Digitaler Zeitzähler

Der Zähler zeigt den Zeitcode oder die bereits durchgelaufene Bandmenge durch Zählen der CTL-Signale an und ermöglicht genaues Auffinden der Schnittpunkte.

Schnitt/Überspielschlüsse

Der DUB OUT-Anschluß für einen U-matic Videorecorder ermöglicht ein hochqualitatives Schneiden und Überspielen des Videosignals.

Weiterhin können am DUB/COMP OUT-Anschluß die Luminanz- und Chroma-Signalkomponenten abgegriffen werden.

Eingebauter Time-Base-Corrector (TBC)

Ein eingebauter Time-Base-Corrector sorgt für ein stabiles Wiedergabebild.

Audio-Rauschverminderungssystem

Der BVW-10P besitzt das neuentwickelte Dolby-C*-System zur Audio-Rauschverminderung. Je nach verwendetem Band kann das Rauschverminderungssystem ein- oder ausgeschaltet werden.

Automatische Rückspul- und automatische Stop-Funktion

Am Bandende wird das Band automatisch zum Anfang zurückgespult. (Automatische Rückspul-Funktion)

Ist der Bandanfang erreicht, stoppt das Band automatisch. (Automatische Stop-Funktion)

Einsteckbare Leiterplatten

Das Gerät besitzt service- und wartungsfreundliche einsteckbare Leiterplatten, die nach Abnehmen der oberen Abdeckung bequem zugänglich sind.


Einbaumöglichkeit in 19-Zoll Normgestell

Der BVW-10P kann in ein 19-Zoll Normgestell eingebaut werden. Siehe dazu Teil 2.

* „Dolby“ und das Doppel-D-Symbol sind eingetragene Warenzeichen der Dolby Laboratories. Das Rauschverminderungssystem wird unter Lizenz der Dolby Laboratories hergestellt.

1-2. LAGE UND FUNKTION DER BEDIENUNGSELEMENTE

1-2-1. Bedienungsfeld



1 Netzschalter [POWER]

Zum Einschalten auf die „ON“ Seite des Schalters drücken.

2 Audio-Pegelanzeigen für Kanal 1/2 [AUDIO LEVEL CH-1/CH-2]

Zur Anzeige des Audio-Ausgangspegels bei Wiedergabebetrieb.

3 Audio-Pegelregler für Kanal 1/2 [AUDIO LEVEL CH-1/CH-2]

Zur Einstellung des Audio-Ausgangspegels von Kanal 1 und 2. Stellen Sie den Pegel so ein, daß die Zeiger der Anzeigen beim Referenz-Ausgangspegel bis „0“ ausschlagen.

4 Spurlagenanzeige [TRACKING]

Zeigt bei Wiedergabe den Signalpegel des FM-Signals an.

5 Spurlagenregler [TRACKING]

Zur Einstellung der Spurlage des Bandes.

Stellen Sie diesen Regler normalerweise in die Mittelstellung (FIXED).

Ist das Wiedergabebild jedoch gestört, so drehen Sie den Regler nach links oder nach rechts, bis die TRACKING-Anzeigen ④ maximalen Wert anzeigen. Vergessen Sie nicht, den Regler nach der Wiedergabe dieses speziellen Bandes wieder in die FIXED-Stellung zurückzustellen.

6 Audio-Monitor-Wähler [AUDIO MONITOR]

Zur Wahl des an der HEADPHONES-Buchse ⑧ am AUDIO MONITOR OUT-Anschluß (XLR) und am MONITOR-Anschluß (8-Pol) an der Rückseite anliegenden Audio-Ausgangssignals.

CH-1: Audio-Kanal 1.

MIX: An der HEADPHONES-Buchse erhält man Kanal 1 links und Kanal 2 rechts.

An den AUDIO MONITOR OUT- und MONITOR-Anschlüssen liegt ein Mischsignal aus beiden Kanälen an.

CH-2: Audio-Kanal 2.

7 Fernbedienungs/Direkt-Wähler [REMOTE/LOCAL]

REMOTE 1 (9P): Wählen Sie diese Stellung, wenn der BVW-10P von dem am 9-poligen REMOTE 1-Anschluß an der Rückseite angeschlossenen Gerät aus fernbedient werden soll.

Die Funktionstasten des BVW-10P arbeiten dann nicht mehr (außer STOP- und EJECT-Taste).

LOCAL: Zur direkten Bedienung an den Funktionstasten des BVW-10P.

REMOTE 2 (36P): Wählen Sie diese Stellung, wenn der BVW-10P von dem am 36-poligen REMOTE 2-Anschluß an der Rückseite angeschlossenen Gerät aus fernbedient werden soll.

Die Funktionstasten des BVW-10P arbeiten dann nicht mehr (außer STOP- und EJECT-Taste).

⑧ Kopfhörerbuchse und Lautstärkereglер [HEAD-PHONES] (Stereo-Klinkenbuchse)

Zur Überwachung des Wiedergabe-Tonsignals kann hier ein 8 Ohm Stereo-Kopfhörer angeschlossen werden. Die Kopfhörer-Lautstärke kann am Regler eingestellt werden.

⑨ Bereitschaftstaste [STANDBY]

Sobald sich die Kopftrommel dreht, leuchtet die STANDBY-Taste auf und zeigt damit an, daß sich das Gerät im Bereitschaftsbetrieb befindet. Wird die STANDBY-Taste in der Stop-Funktion gedrückt, so stoppt die Kopftrommel und der Bereitschaftsbetrieb wird abgeschaltet. Drücken Sie die STANDBY-Taste erneut, um wieder auf Bereitschaft zurückzuschalten.

⑩ Auswurf-taste [EJECT]

Drücken Sie diese Taste zum Auswerfen der Cassette.

- Nehmen Sie die Cassette nach der Verwendung stets heraus, bevor Sie das Gerät abschalten.

⑪ Rückspultaste [REW]

Zum Zurückspulen des Bandes.

⑫ Wiedergabetaste [PLAY]

Zum Wiedergeben des Bandes.

⑬ Schnellvorspultaste [F FWD]

Zum schnellen Vorspulen des Bandes.

- In folgenden Fällen kann die Schnellvorspulggeschwindigkeit etwa in der Mitte des Bandes abnehmen. Dies ist jedoch kein Anzeichen für das Vorliegen einer Betriebsstörung.
 - Beim ersten Schnellvorspulen nach dem Einsetzen der Cassette
 - Beim ersten Schnellvorspulen nach dem Einschalten des Gerätes

⑭ Stoptaste [STOP]

Zum Stoppen des Bandes.

Da in der Stop-Funktion die Kopftrommel weiterhin rotiert und das Band eingefädelt bleibt, kann ein Standbild beobachtet werden.

Nach dem Einlegen einer Cassette schaltet das Gerät stets zunächst auf die Stop-Funktion.

⑮ Suchlauf-taste [SEARCH]

Zum Umschalten auf Suchlauf. Die Lampe leuchtet dann auf, und der Suchlauf kann in der Shuttle- oder Jog-Funktion durchgeführt werden.

⑯ Suchlaufknopf

Zum schnellen Auffinden der gewünschten Schnittpunkte. Durch Drücken des Knopfes schaltet das Gerät in die Jog- und durch nochmaliges Drücken rastet der Knopf aus und das Gerät schaltet in die Shuttle-Funktion. Der entsprechende Indikator leuchtet jeweils auf.

SHUTTLE: Durch Drehen des Knopfes nach rechts oder links kann die Bandgeschwindigkeit in beiden Richtungen von $\frac{1}{30}$ bis ca. 10facher Normalgeschwindigkeit verändert werden.

In der Mittelstellung (□) erhält man ein Standbild.

JOG: Durch Drehen des Knopfes nach rechts oder links ist ein Variieren von Standbild bis 1-fache Normalgeschwindigkeit möglich, wobei die Bandlaufrichtung und die Bandgeschwindigkeit der Drehung des Knopfes entspricht. Wird der Knopf angehalten, so erhält man ein Standbild.

- Nach dem Einschalten des Gerätes ist darauf zu achten, den Knopf erst einmal in die □ Position zu stellen, bevor mit dem Suchlauf begonnen wird.

⑰ CTL/Zeitcode-Wähler [CTL/TIME CODE]

Zur Wahl der Zeitzähleranzeige: CTL oder Zeitcode.

Steht der REMOTE/LOCAL-Wähler auf REMOTE 1, so wird die Zeitzähleranzeige von den angeschlossenen Geräten aus umgeschaltet und der CTL/TIME CODE-Wähler bleibt wirkungslos.


⑱ Zeitzähler

Steht der CTL/TIME CODE-Wähler ⑰ auf TIME CODE, so wird der Zeitcode des Bandes gelesen und die Bandposition in Stunden, Minuten, Sekunden und Vollbildern angezeigt. Steht der Wähler auf CTL, so werden die CTL-Signale gezählt und der Zähler zeigt die bereits durchgelaufene Bandmenge an.


⑲ Rückstell-taste [RESET]

Zum Zurückstellen des Zählers auf „0:00:00:00“, wenn sich der Zeitzähler im CTL-Betrieb befindet. Befindet sich der Zähler jedoch im Zeitcode-Betrieb, so arbeitet diese Taste nicht.

Verstellen des Bedienungspultes



1-2-2. Anschlußfeld



① U-matic H-Überspielausgang [DUB OUT (U-matic H)]

Hier liegt das Video-Überspielsignal an.

Verbinden Sie diesen Ausgang unter Verwendung eines Überspielkabels (Sonderzubehör) an den DUB IN-Anschluß eines U-matic H-Videorecorders.

② Überspiel/Komponentenausgang [DUB/COMP OUT] (12-polige Buchse)

Hier liegen die Luminanz (Y)- und die Chroma (R-Y, B-Y)-Signalkomponenten an.

③ Referenz-Videoeingänge [REF VIDEO IN] (BNC-Buchse)

Beide Buchsen dienen zum Anschluß eines Referenz-Video-signals.

Die nichtverwendete Buchse kann als durchgeschleifter Ausgang (Brückenanschluß) für andere Videogeräte verwendet werden. Wird nur eine dieser Buchsen verwendet, so stellen Sie den 75Ω ON/OFF-Schalter ④ auf ON.

④ 75Ω Ein-/Ausschalter [75Ω ON/OFF]

Zum Abschließen der Videoeingänge mit 75 Ohm.

ON: Normalstellung.

OFF: Wenn eine der REF VIDEO IN-Buchsen als durchgeschleifter Ausgang verwendet wird.

⑤ Videoausgänge [VIDEO OUT] (BNC-Buchse)

Hier liegt das FBAS-Signal an.

Schließen Sie einen Video-Monitor oder einen Videorecorder an.

Das an der VIDEO OUT 2-Buchse anliegende Videosignal kann an einem Schalter der gedruckten Leiterplatte zwischen FBAS und FBA umgeschaltet werden. Genaueres dazu siehe Teil 2.

⑥ Zeitcodeausgang [TIME CODE OUT] (BNC-Buchse)

Hier liegt das Zeitcodesignal an.

Schließen Sie diese Buchse an den TIME CODE IN-Anschluß des Zeitcodelesers oder Videorecorders an.

⑦ Audio-Kanal-1/2-Ausgänge [AUDIO OUT CH-1/CH-2] (XLR-Stiftbuchse)

Hier liegen die an den AUDIO LEVEL-Reglern am Bedienungsfeld auf der Vorderseite einstellbaren Audiosignale an.

⑧ Audio-Monitorausgang [AUDIO MONITOR OUT] (XLR-Stiftbuchse)

Schließen Sie hier das Gerät zur Tonüberwachung an. Die Wahl des Ausgangssignals erfolgt am AUDIO MONITOR-Wähler des Bedienungsfeldes.

⑨ Monitorausgang [MONITOR] (8-polig)

Hier liegen die Video- und Audiosignale an.

Schließen Sie über ein gesondert lieferbares Monitorkabel einen Farb-Monitor an. Das an diesem Anschluß anliegende Ausgangssignal kann am AUDIO MONITOR-Wähler des Bedienungsfeldes umgeschaltet werden.

⑩ Fernbedienungsanschluß 1 [REMOTE 1 (9P)] (9-polig, RS-422 spec.)

Zum Anschluß von Geräten mit 9-poligem Fernbedienungsanschluß: Videorecorder wie z.B. BVU-800P, BVU-820P und BVH-2000PS (unter Verwendung eines mitgelieferten Fernbedienungskabels) oder Schnitt-Steuereinheit wie z.B. BVE-800 und BVE-5000P.

⑪ Fernbedienungsanschluß 2 [REMOTE 2 (36P)] (36-polig)


Zum Anschluß einer Sony Schnitt-Steuereinheit der BVE-Serie wie z.B. BVE-500ACE oder BVE-5000P über ein gesondert lieferbares 36-poliges Fernbedienungskabel.

- Die Sony Fernbedienungseinheit BVR-510ACE kann nicht verwendet werden.


⑫ Netzanschluß [AC IN]

Zum Anschluß des mitgelieferten Netzkabels.

1-2-3. Hilfsbedienungsfeld



Hinter dem Bedienungsfeld



① Videoregler [VIDEO] und Voreinstell/Manuell-Schalter [PRESET/MANUAL]

Der PRESET/MANUAL-Schalter hat folgende Funktion:

MANUAL: Der Ausgangspegel des FBAS-Signals kann am VIDEO-Regler in einem Bereich von ± 3 dB eingestellt werden. Am CHROMA-Regler kann der Chromapegel nicht über +3 dB eingestellt werden.

PRESET: Man erhält stets den voreingestellten Video-Ausgangspegel unabhängig von der Stellung des Reglers.

② Chromaregler [CHROMA] und Voreinstell/Manuell-Schalter [PRESET/MANUAL]

Der PRESET/MANUAL-Schalter hat folgende Funktion:

MANUAL: Der Ausgangspegel des Chromasignals kann am CHROMA-Regler in einem Bereich von ± 3 dB eingestellt werden. Am VIDEO-Regler ist jedoch keine Einstellung über +3 dB möglich.

PRESET: Man erhält stets den voreingestellten Chromapegel unabhängig von der Stellung des Reglers.

③ Schwarzpegelregler [BLACK LEVEL] und Voreinstell/Manuell-Schalter [PRESET/MANUAL]

Der PRESET/MANUAL-Schalter hat folgende Funktion:

MANUAL: Der Ausgangs-Schwarzpegel kann am BLACK LEVEL-Regler in einem Bereich von 0 bis 15 IRE eingestellt werden.

PRESET: Man erhält stets den voreingestellten Ausgangs-Schwarzpegel unabhängig von der Stellung des Reglers.

④ Y/C-Verzögerungsregler [Y/C DELAY] und Voreinstell/Manuell-Schalter [PRESET/MANUAL]

Der PRESET/MANUAL-Schalter hat folgende Funktion:

MANUAL: Die Y/C-Verzögerung kann in einem Bereich von ± 50 nsec eingestellt werden.

PRESET: Man erhält stets die eingestellte Y/C-Verzögerung unabhängig von der Stellung des Reglers.

⑤ System-Sync-Phasenregler [SYSTEM SYNC PHASE]

Die Ausgangs-Sync-Phase kann hier in einem Bereich von $-1 \mu\text{sec}$ bis $+3 \mu\text{sec}$ im Bezug auf das Referenz-Eingangssignal des BVW-10P eingestellt werden. Verwenden Sie diesen Regler z.B. um die Ausgangsphase auf die Referenz des Senders abzustimmen oder um Spezialeffekte wie z.B. Ein/Ausblenden oder weiches Überblenden zu erzielen, wenn zwei oder mehr Videorecorder an den BVW-10P angeschlossen sind.

⑥ System-Hilfsträger-Phasenregler [SYSTEM SC PHASE]

Die Ausgangs-Hilfsträgerphase kann hier in einem Bereich von 360° pp im Bezug auf das Referenz-Eingangssignal des BVW-10P eingestellt werden. Verwenden Sie diesen Regler z.B., um die Ausgangsphase auf die Referenz des Senders abzustimmen oder um Spezialeffekte wie z.B. Ein/Ausblenden oder weiches Überblenden zu erzielen, wenn zwei oder mehr Videorecorder an den BVW-10P angeschlossen sind.

⑦ Audio-Rauschverminderungsschalter [AUDIO NR]


Das Gerät besitzt eine Dolby-C Audio-Rauschverminderung.

ON: Zur Wiedergabe eines mit Dolby NR bespielten Bandes.

OFF: Zur Wiedergabe eines nicht mit Dolby NR bespielten Bandes.


⑧ Betriebsstundenanzeige [HOURS METER]

Hier wird die Gesamt-Rotationszeit der Video-Kopftrommel angezeigt (bis max. 1000 Stunden).




1-3. ANSCHLÜSSE


1-3-1. Wiedergabe



1-3-2. Schneiden mit 2 Videorecordern




1-3-3. Schneiden mit einer Steuereinheit



* Auf REMOTE 2 (36P) stellen, wenn zum Anschluß an eine Schnitt-Steuereinheit (BVE-500ACE etc.) und einen Videorecorder (BVU-200P etc.) ein 36-Stift-Anschluß verwendet wird.

1-4. EINLEGEN UND HERAUSNEHMEN DER CASSETTE

Einlegen der Cassette



Das Band fädelt sich automatisch ein, die Kopftrommel beginnt sich zu drehen, und es erscheint ein Standbild.


Herausnehmen der Cassette

Drücken Sie bei eingeschaltetem POWER-Schalter die EJECT-Taste.


Hinweis: Nehmen Sie die Cassette stets nach dem Betrieb heraus.

1-5. WIEDERGABE

1-5-1. Vorbereitung



1-5-2. Betrieb



Starten der Wiedergabe

Drücken Sie die **PLAY-Taste**.
Die **PLAY-Taste** leuchtet auf.

Stoppen der Wiedergabe

Drücken Sie die **STOP-Taste**.
Die **PLAY-Taste** erlischt und die **STOP-Taste** leuchtet auf.

- Am Bandende wird das Band automatisch zum Anfang zurückgespult und stoppt dort.

1-5-3. Einstellungen

Einstellung der Spurlage

Stellen Sie den TRACKING-Regler normalerweise auf FIXED. Ist das Wiedergabebild gestört, so drehen Sie den TRACKING-Regler nach links oder rechts, bis die TRACKING-Anzeige maximal ausschlägt.

- Nach der Wiedergabe dieses speziellen Bandes, stellen Sie den Regler auf FIXED zurück.

Einstellung des Audiopegels

Stellen Sie die AUDIO LEVEL-Regler für Kanal 1 und 2 so ein, daß die AUDIO LEVEL-Anzeigen beim Referenz-Ausgangspegel ungefähr null anzeigen.

1-5-4. Bandschutzeinrichtungen

Bandschutz



Zum Schutz von Band und Videoköpfen schaltet das Gerät in eine der beiden folgenden Bandschutzfunktionen, wenn das Band für länger als 8 Minuten angehalten wird:

- Wenn sich das Gerät länger als 8 Minuten in der Stop-Funktion befindet, so wird die Bereitschaftsfunktion abgeschaltet, die Kopftrommel bleibt stehen, das Band lockert sich und die STANDBY-Taste erlischt. Durch Drücken der entsprechenden Taste kann das Gerät dann in die gewünschte Betriebsart geschaltet werden. Um bei ausgeschalteter Bereitschaftsfunktion ein Standbild zu erhalten, drücken Sie die STANDBY-Taste.
- Wird im Suchbetrieb ein Standbild länger als 8 Minuten angezeigt, so läuft das Band mit $\frac{1}{30}$ Normalgeschwindigkeit in Vorwärtsrichtung weiter.

Kondenswasserbildung

Hat sich im Inneren des Gerätes Kondenswasser gebildet, so spricht eine eingebaute Schutzschaltung an, Kopftrommel und Capstanmotoren bleiben stehen und der AUTO OFF-Indikator am vorderen Bedienungsfeld erlischt. Ist eine Cassette eingelegt, so wird diese ausgeworfen. Danach beginnt die Kopftrommel wieder zu rotieren, damit die Trommeleinheit schneller trocknet.

- Wird das Gerät direkt von einem kalten in einen warmen Ort gebracht, so betreiben Sie es in den ersten 10 Minuten nicht, da es einige Minuten dauert, bevor die Feuchtigkeit an der Kopftrommel kondensiert und ein Aufleuchten des AUTO OFF-Indikators verursacht. Schalten Sie nach 10 Minuten den POWER-Schalter ein, und beachten Sie folgende Punkte.
 - a) Leuchtet der Indikator nicht, so kann das Gerät betrieben werden.
 - b) Leuchtet der Indikator, so lassen Sie das Gerät eingeschaltet und warten Sie, bis der Indikator erlischt. Während der Indikator leuchtet, kann keine Cassette eingelegt werden.




1-6. ÜBERPRÜFUNGEN

Wir empfehlen, das Gerät vor jedem Betrieb auf einwandfreies Funktionieren zu überprüfen.



- Stellen Sie die Bedienungselemente nach der Überprüfung entsprechend der späteren Verwendung ein.

TRACKING-Regler → FIXED

POWER-Schalter → ON



REMOTE/LOCAL-Wähler → LOCAL
(bei Anschluß eines weiteren
Videorecorders oder einer
Schnitt-Steuereinheit auf
REMOTE 1 oder REMOTE 2
stellen.)



1-7. REINIGUNG DER KÖPFE

Verwenden Sie zur Reinigung der Video- und Tonköpfe die gesondert lieferbare Reinigungscassette L-25CL. Genaueres dazu siehe Anleitung der Reinigungscassette.

- Nehmen Sie die Reinigungscassette nach der Verwendung auf jeden Fall heraus, da die Kopftrommel auch in der Stop-Funktion rotiert.

1-8. TECHNISCHE DATEN

Mechanische Daten

Gewicht	30 kg
Abmessungen	452 x 239 x 580 mm (B/H/T)
Betriebsposition	Horizontal (bis 30°)
Bandtransportmechanismus	Betacam-System
Videocassette	HG-20 Cassette oder entsprechender Typ
Bandgeschwindigkeit	101,5mm/sec
Wiedergabezeit	max. 20 Min. mit HG-20 Cassette
Vorspul-/Rückspulzeit	Weniger als 90 sec mit HG-20 Cassette
Suchlaufgeschwindigkeit	SHUTTLE: Standbild, $\frac{1}{30}$, $\frac{1}{10}$, $\frac{1}{5}$, $\frac{1}{2}$, 1, 2, 5 und 10fache Normalgeschwindigkeit in Vorwärts- und Rückwärtsrichtung. JOG: Standbild bis 1-fache Normalgeschwindigkeit in Vorwärts- und Rückwärtsrichtung.
Anschlüsse	
AC IN	3 Leitungen, parallele Erde
VIDEO OUT 1/2	BNC-Buchse
AUDIO OUT CH-1/CH-2/MONITOR	XLR-Stiftbuchsen
TIME CODE OUT	BNC-Buchse
DUB OUT (U-matic H)	7-Pol-Buchse
DUB/COMP OUT	12-Pol-Buchse
MONITOR	8-Pol-Anschluß
REMOTE 1 (9P)	9-Pol-Anschluß
REMOTE 2 (36P)	36-Pol-Anschluß
HEADPHONES	JM-60 Kopfhörer Stereo-Klinkenbuchse
REF VIDEO IN 1/2	BNC-Buchse
Betriebstemperatur	5°C bis 40°C
Lagertemperatur	-20°C bis +60°C

Elektrische Daten

Versorgungsspannung	90 - 265 V Wechselspannung, 48 - 64 Hz
Leistungsaufnahme	160 W
Video	
Video-Aufzeichnungssystem	Luminanz: FM Chroma: komprimiertes Zeitmultiplex FM-Signal
Bandbreite	Luminanz: 30 Hz - 4,0 MHz $\pm 0,5$ dB Chroma (R-Y): 30 Hz - 1,5 MHz $\pm 0,5$ dB (B-Y): 30 Hz - 1,5 MHz $\pm 0,5$ dB
Signal-Rauschabstand	Luminanz: Mehr als 46 dB AM: Mehr als 49 dB PM: Mehr als 49 dB
K-Faktor (2T-Impuls)	3%
Differentialgewinn	3%
Differentialphase	3°
Y/C-Verzögerung	20 ns
Eingang	REF VIDEO IN 1,0 Vss $\pm 0,3$ V, 75 Ohm, ein/ausschaltbar
Ausgang	VIDEO OUT 1 FBAS-Signal: 1,0 Vss, 75 Ohm, negative Synchronisation FBA-Signal: 0,7 Vss, 75 Ohm VIDEO OUT 2 FBAS-Signal: 1,0 Vss, 75 Ohm, negative Synchronisation FBA-Signal: 0,7 Vss, 75 Ohm DUB OUT (U-matic H) Luminanz: 0,5 Vss, 75 Ohm, negative Synchronisation Chroma: 0,5 Vss, 75 Ohm (Heruntergesetzter Hilfsträger) DUB/COMP OUT Luminanz: 1,0 Vss, 75 Ohm, negative Synchronisation Chroma (R-Y): 0,7 Vss, 75 Ohm (B-Y): 0,7 Vss, 75 Ohm

Audio

Frequenzgang	50 Hz - 15 kHz $\pm 3,0$ dB
Signal-Rauschabstand	Mehr als 50 dB (ohne Dolby, bei 3% Klirrgrad)
Klirrfaktor	Weniger als 2% (1 kHz, Referenzpegel)
Ausgang	AUDIO OUT CH-1/CH-2/MONITOR: +4 dB, niedrige Impedanz, symmetrisch (erlaubte Last 600 Ohm)
Zeitcode	2,2 Vss (erlaubte Lastimpedanz bis 600 Ohm)
Prozessor-Einstellbereich	
Videopegel	± 3 dB
Chromapegel	± 3 dB
Schwarzpegel	0 - +15 IRE
System-Hilfsträger-Phase	360° ss
System-Sync-Phase	± 3 μ s
Y/C-Verzögerung	± 50 ns
Mitgeliefertes Zubehör	Netzkabel (1) Fernbedienungskabel RCC-5G (9-Pol auf 9-Pol) (1)

Sonderzubehör

Gestellmontagesatz RMM-100
Überspielkabel VDC-5 (5 m)
Reinigungscassette L-25CL

Action	Check point
Insert a cassette.	• The cassette is properly inserted.
Press the F FWD button.	• The tape advances rapidly.
Press the STOP button.	• The tape stops. A still picture will appear on the monitor screen.
Press the PLAY button.	• The playback picture appears on the screen.
Set the AUDIO MONITOR switch to CH-1.	• The audio channel 1 sound is heard from the monitor.
Turn the AUDIO LEVEL CH-1 control to the right.	• The pointer of the AUDIO LEVEL CH-1 meter deflects to the far right.
Set the AUDIO MONITOR switch to CH-2.	• The audio channel 2 sound is heard from the monitor.
Turn the AUDIO LEVEL CH-2 control to the right.	• The pointer of the AUDIO LEVEL CH-2 meter deflects to the far right.
Set the AUDIO MONITOR switch to MIX.	• The mixed sound of the audio channel 1 and 2 is heard from the monitor.
Connect headphones to the HEAD-PHONES jack.	• The CH-1 and CH-2 sounds are heard from the left and right respectively when the AUDIO MONITOR switch is set to MIX.
Set the CTL/TIME CODE selector to CTL and TIME CODE alternately.	• The indications changes when the selector position is changed.
Set the CTL/TIME CODE selector to CTL and press the RESET button.	• The figure on the time counter returns to 0.

Action	Check point
Press the SEARCH button.	• The SEARCH lamp lights.
Turn the search dial to the right with the search dial released.	• The forward playback speed is accelerated as the dial turns to the right. (Forward shuttle mode) • When the dial is turned to the click position (x10), the pinch roller is released and the picture stops or is distorted for a moment.
Return the dial to the center position.	• A still picture appears.
Turn the search dial to the left with the search dial released.	• The reverse playback speed is accelerated as the dial turns to the left. (Reverse shuttle mode) • When the dial is turned to the click position (x-10), the pinch roller is released and the picture stops or is distorted for a moment.
Press the search dial in.	• A still picture appears. The JOG lamp lights.
Turn the search dial to the right.	• The tape advances in the forward direction with the dial rotation speed as the dial rotates.
Turn the search dial to the left.	• The tape advances in the reverse direction with the dial rotation speed as the dial rotates.
Press the STOP button and then the STANDBY button.	• The STANDBY lamp goes off and the picture on the monitor disappears. (Standby-off)
Press the REW button.	• The tape rewinds. The tape stops automatically at the beginning. (Auto stop)
Press the EJECT button.	• The cassette is ejected.

1-7. HEAD CLEANING

Clean the video heads and the audio heads with the L-25CL video head cleaning cassette (optional). For details, refer to the instructions which come with the cleaning cassette.

- As the head drum rotates even in the stop mode, be sure to eject the cleaning cassette after use.

1-8. SPECIFICATIONS

Mechanical

Weight	30 kg (66 lb 2 oz)
Dimensions	452 x 239 x 580 mm (w/h/d) (17 7/8 x 9 1/2 x 22 7/8 inches)
Operating position	Horizontal (within 30°)
Tape transport mechanism	Betacam system
Video cassettes	HG-20 cassette (1/2-inch cassette for Beta format) and equivalent
Tape speed	101.5 mm/s
Playback time	20 min max. with an HG-20 cassette
Fast forward/rewind time	Less than 90 sec. with an HG-20
Search speed	SHUTTLE: still, 1/30, 1/10, 1/5, 1/2, 1, 2, 5 and 10 times normal in forward and reverse directions JOG: still to 1 in forward and reverse directions
Connectors	AC IN 3-wire parallel ground VIDEO OUT 1/2 BNC connector AUDIO OUT CH-1/CH-2/MONITOR: XLR male connectors TIME CODE OUT: BNC connector DUB OUT (U-matic H) 7-pin female connector DUB/COMP OUT 12-pin female connector MONITOR 8-pin connector REMOTE 1 (9P) 9-pin connector REMOTE 2 (36P) 36-pin connector HEADPHONES JM-60 headphone stereo phone jack REF VIDEO IN 1/2 BNC connector
Operating temperature	5°C to 40°C (41°F to 104°F)
Storage temperature	-20°C to +60°C (-4°F to +140°F)

Electrical

Power requirements	AC 90 - 265 V, 48 - 64 Hz
Power consumption	160 W

Video

Video recording system	Luminance: FM Chrominance: compressed time division multiplex FM
Bandwidth	Luminance: 30 Hz - 4.0 MHz ± 0.5 dB Chrominance: R-Y 30 Hz - 1.5 MHz ± 0.5 dB B-Y 30 Hz - 1.5 MHz ± 0.5 dB
Signal to noise ratio	Luminance: More than 46 dB AM: More than 49 dB PM: More than 49 dB
K-factor (2T pulse)	3%
DG	3%
DP	3°
Y/C delay	20 ns
Input	REF VIDEO IN 1.0 Vp-p $\pm$ 0.3 V, 75 ohms ON/OFF
Output	VIDEO OUT 1 Composite video, 1.0 Vp-p, 75 ohms, sync negative VIDEO OUT 2 Composite video, 1.0 Vp-p, 75 ohms, sync negative Non-composite, 0.7 Vp-p, 75 ohms DUB OUT (U-matic H) Luminance: 0.5 Vp-p, 75 ohms, sync negative Chrominance: 0.5 Vp-p, 75 ohms (SC low-range conversion) DUB/COMP OUT Luminance: 1.0 Vp-p, 75 ohms, sync negative Chrominance: R-Y 0.7 Vp-p, 75 ohms B-Y 0.7 Vp-p, 75 ohms


Audio

Frequency response	50 Hz - 15 kHz ± 3.0 dB
Signal to noise ratio	More than 50 dB (at 3% distortion level, without the audio NR system)
Distortion	Less than 2% (1 kHz reference level)
Output	AUDIO OUT CH-1/CH-2/MONITOR: +4 dB, low impedance, balanced (600 ohm load permissible)
Time code	2.2 Vp-p (600 ohm load permissible)
Processor adjustment range	Video level ± 3 dB Chroma level ± 3 dB Black level 0 - +15 IRE System SC phase 360° p-p
System sync phase	± 3 μ s
Y/C delay	± 50 ns
Accessories supplied	AC power cord (1) Remote control cable RCC-5G (9-pin to 9-pin) (1)


Optional accessories

Rack mount kit	RMM-100
Dubbing cable	VDC-5 (5 m)
Cleaning cassette	L-25CL

Außenansicht




Abmessungen für Gestellmontage (Seitenteile abgenommen)



Einheit: mm (Zoll)

1-9. WIEDERVERPACKEN ZUM TRANSPORT






SECTION 2 INSTALLATION

Be sure to install the BVW-10P at the installation space under the required operational environment as regulated below. It will assure the BVW-10P's superior performance while maintaining the excellent serviceability and accessibility.

2-1. OPERATIONAL ENVIRONMENT

1. The operating temperature range:
 $+5^{\circ}\text{C} \sim +40^{\circ}\text{C}$
 (Good air circulation is essential to prevent internal heat build-up. Place the set in locations with sufficient air circulation. Do not block the ventilation holes on the cabinet and the rear panel.)
2. The storage temperature range:
 $-20^{\circ}\text{C} \sim +60^{\circ}\text{C}$
3. Avoidance installation areas:
 - Areas where the BVW-10P will be exposed to direct sunlight, or any other strong direct lights.
 - Dusty areas or areas where it is subject to vibration.
 - Areas where high electric or magnetic fields are to be found.
 - Areas near heat sources.



Unit: mm

2-2. INSTALLATION SPACE

1. The outer dimensions of the set are shown in the figure below. The rear side of the set must be at least 40 cm away from the wall for ventilation and maintenance.
2. When the set is operated on the desk or similar condition, assure that the vertical clearance above the BVW-10P is at least 40 cm to provide the accessibility to the printed circuit boards and other mechanical parts. But note that it is not necessary to provide the space when the set is mounted in a rack since the printed circuit boards can be repaired after the set is pulled out.

2-3. OPERATING VOLTAGE

100 V $\pm 10\%$ ~ 240 V $\pm 10\%$

48 Hz ~ 64 Hz

The power consumption: 160W

2-4. CONNECTORS FOR OPTIONAL CONNECTION

When external cables are connected to the various connectors on the BVW-10P connector panel during the installation or the maintenance, hardwares as stated below or the equivalents must be used.

Panel Indication	Connection Connector
REF. VIDEO IN VIDEO OUT TIME CODE OUT	1-560-069-11 PLUG, BNC, MALE
DUB OUT	1-508-948-00 PLUG, 7P, MALE
DUB/COMP OUT	1-560-995-00 PLUG, 12P, MALE
AUDIO OUT AUDIO MONITOR	1-508-083-00 CONNECTOR, 3P, MALE
MONITOR	1-506-161-00 CONNECTOR, 8P, MALE
REMOTE-1 (9P)	1-561-749-00 JUNCTION SHELL, 9P 1-560-651-00 PLUG, 9P (M)
REMOTE-2 (36P)	1-508-852-00 CONNECTOR, 36P, MALE

2-5. INPUT/OUTPUT SIGNAL OF THE CONNECTOR

INPUT

REF. VIDEO IN : 1.0 Vp-p ± 0.3 V, 75 ohms ON/OFF

OUTPUT

VIDEO OUT 1 : composite, 1.0 Vp-p, sync negative, 75 ohms

VIDEO OUT 2 : composite, 1.0 Vp-p, sync negative, 75 ohms

non-composite, 0.7 Vp-p, 75 ohms

DUB OUT : luminance signal, 0.5 Vp-p, 75 ohms, sync negative

chrominance signal, 0.5 Vp-p, 75 ohms (SC low-range conversion)

DUB/COMP OUT : luminance signal, 1.0 Vp-p, 75 ohms, sync negative

chrominance signal
R-Y, 0.7 Vp-p, 75 ohms

B-Y, 0.7 Vp-p, 75 ohms

AUDIO OUT : +4 dB, low impedance, balanced (600 ohm load permissible)

AUDIO MONITOR OUT : +4 dB, low impedance, balanced (600 ohm load permissible)

TIME CODE OUT: 2.2 Vp-p (600 ohm load permissible)

REMOTE-1 (9P)

Pin No.	Description	I/O
1	Frame Ground	—
2	Transmit A	O
3	Receive B	I
4	Receive Common	—
5	Spare	—
6	Transmit Common	—
7	Transmit B	O
8	Receive A	I
9	Frame Ground	—

REMOTE-2 (36P)

2. INSTALLATION

Pin No.	Description	LEVEL
1	UNREG 5 V	TTL
2	L - FF COMMAND IN	TTL
3	L - FWD COMMAND IN	TTL
4	L - REW COMMAND IN	TTL
5	L - EJECT COMMAND IN	TTL
6	L - STOP COMMAND IN	TTL
7	L - PAUSE COMMAND IN	TTL
8	—	—
9	—	—
10	—	—
11	—	—
12	L - FF STATUS OUT	TTL
13	L - FWD STATUS OUT	TTL
14	L - REW STATUS OUT	TTL
15	L - STANDBY STATUS OUT	TTL
16	L - STOP STATUS OUT	TTL
17	L - PAUSE STATUS 1 IN/OUT	TTL
18	—	—
19	—	—
20	—	—
21	—	—
22	—	—
23	L - REVERSE COMMAND IN	TTL
24	SPEED A IN	TTL
25	SPEED B IN	TTL
26	L - CTL PULSE OUT	TTL
27	L - TACH OUT	TTL
28	L - CAPSTAN LOCK OUT	TTL
29	SYNCHRONIZE IN	3.0 V : 0% -0.3 V : -10 ~ -15% +6 V : +10 ~ +15%
30	NC	—

Pin No.	Description	LEVEL
31	H - NORMAL FWD IN	TTL
32	L - PAUSE STATUS 2 OUT	TTL
33	L - SEARCH STATUS IN	TTL
34	NC	—
35	GND	—
36	GND	—

2-6. SELECT SWITCH SETTING

Along with the select switches on the control panel and the connector panel, the switches listed below are on the circuit boards. The switches must be used according to systems and conditions.

EN-20 BOARD

SW1. COMP/NON COMP select switch

COMP: The composite video signal is fed out from VIDEO OUT-2 connector.

NON COMP: The non-composite video signal is fed out from VIDEO OUT-2 connector.

When the set is shipped, the COMP/NON COMP select switch is set to the COMP position.

SW2. CHROMA ON/OFF switch

ON: The luminance signal is fed out after mixed with the chroma signal from VIDEO OUT 1/2 connectors.

OFF: The only luminance signal is fed out.

When the set is shipped, the CHROMA ON/OFF switch is set to the ON position.

AU-37 BOARD

S1. REC/PLAY select switch

This switch is used for electrical alignment.

When the set is shipped, the REC/PLAY select switch is set to the PLAY position.

TC-25 BOARD

S1-1. EBU/SMPTE select switch

OFF: SMPTE time code signal

ON: EBU time code signal

When the set is shipped, the EBU/SMPTE select switch is set to the ON position.

S1-2. 50/60 select switch

OFF: 60 (SMPTE time code signal)

ON: 50 (EBU time code signal)

When the set is shipped, the 50/60 select switch is set to the ON position.

S1-3. TIME CODE/AUTO modes select switch

OFF: AUTO mode

In normal operation, playing back time code signal is fed out. When the time code signal is missing, interpolated signal with CTL signal is fed out.

ON: TIME CODE mode

Only the playing back time code signal is fed out from time code out terminal on TC-25 board.

When the set is shipped, the TIME CODE/AUTO modes select switch is set to the OFF position.

S1-4. ERROR BYPASS ON/OFF switch

ON: The ERROR BYPASS circuit is activated

OFF: The ERROR BYPASS circuit is disable

When the set is shipped, the ERROR BYPASS ON/OFF switch is set to the ON position.

When the TIME CODE/AUTO modes select switch is turned to AUTO mode, this switch is disable.

S1-8. FACTORY MODE ONLY switch

This switch is used for the factory check

When the set is shipped, the FACTORY MODE ONLY switch is set to the OFF position.

S1-5 ~ S1-7: These switches does not have a function.

SY-91 BOARD

S1. SEARCH DIRECT/KEY select switch

ON: The set is turned into the SEARCH mode according to turn the SEARCH dial in any mode without pressing SEARCH button.

OFF: The set is turned into the SEARCH mode according to turn the SEARCH dial after pressing the SEARCH button in any mode.

When the set is shipped, the SEARCH DIRECT/KEY select switch is set to the ON position.

S4-6. TROUBLE INHIBIT switch

OFF: The protection circuit is activated.

ON: The protection circuit of the tape slack and so on is disable.

When the set is shipped, the TROUBLE INHIBIT switch is set to the OFF position.

S4-7. UNTHREAD INHIBIT switch

This switch is used for mechanical alignment.

When the set is shipped, the UNTHREAD INHIBIT switch is set to the OFF position.

S4-8. NTSC/CCIR select switch

ON: NTSC

OFF: CCIR

When the set is shipped, the NTSC/CCIR select switch is set to the OFF position.

S4-1 ~ S4-5: System check switch

The information for the system check is described Sec. 4, Service Information (available later).

2-7. RACK MOUNTING


The BVW-10P can be mounted in the 19-inch standard rack. It is recommended to use the RACK MOUNT KIT, RMM-100, optional parts (including the slide rails and the handle brackets) or the following ACCURIDE'S slide rail.

RACK-MOUNT SLIDES MODEL 305

SLIDE LENGTH 22 INCH

1. Loosen two mounting screws on the right and the left side panels.



- Mounting screws will not be detached since it use a retainer on the inside the cover.



2. Remove the each fine mounting screws on the (R) chassis and the (L) chassis.

3. Attach the inner members of the slide rails to the (R) chassis and the (L) chassis with the screws removed in step (2).


- Length of the screws used for the attachment is limited. If the screws supplied with the chassis are lost, a screw less than 10 mm in length must be used.
- The inner member must be fixed at four points with the screws.




4. Remove four legs located under the set

- If the set is mounted in the rack without removing the legs. It will contact the lower set and the upper set cannot be pulled out from the rack.

5. Attach the outer member bracket of the slide rail to the rack and position from the edge of the slide rail to the outside of the rack so that the position satisfies to the specified value.




6. Attach the handle brackets.



NOTE:

1. When the several sets are mounted on the rack, it is recommended to install the fan for ventilation. Good air circulation is essential to prevent internal heat buildup in the rack. 5°C to 40°C environmental condition must be met throughout all units.
2. Never remove the upper panel and the bottom plate at the rack mounting.
3. Be sure to stabilize the rack to the floor to avoid the accidents when the BVW-10P is pulled out.
4. Dimension without side panels are shown in figure. If the rack front width is narrower than the set width, the set must be mounted after the handles on the right and left made been removed.



2-8. SUPPLIED ACCESSORY

Supplied BVW-10P accessories are as follows.

1. AC Power Cord
2. 9-Pin Remote Control Cable, RCC-5G

2-9. OPTIONAL ACCESSORY

The followings are provided as the optional accessory. The suitable accessory should be used for each system.

1. Rack Mount Kit (RMM-100)

The rack mount kit is used for mounting the BVW-10P on the 19-inch standard rack or console. This mounting kit consists of two slide-rails and two types of handle-brackets.

2. 9-Pin Remote Control Cable

Three kinds of 9-pin remote control cable are provided.

Type Length

RCC-5G : 5m

RCC-10G : 10m

RCC-30G : 30m

NOTE: The remote cable can be extended up to 1200m.

SECTION 3 TECHNICAL INFORMATION

3-1. SPECIFICATIONS

Mechanical

Weight 30 kg (66 lb 2 oz)

Dimensions 452 x 239 x 580 mm (w/h/d)
(17⁷/₈ x 9¹/₂ x 22⁷/₈ inches)

Operating position
Horizontal (within 30°)

Tape transport mechanism
Betacam system

Video cassettes
HG-20 cassette (1/2-inch cassette for Beta format) and equivalent

Tape speed 101.5 mm/s

Playback time 20 min max. with an HG-20 cassette

Fast forward/rewind time
Less than 90 sec. with an HG-20

Search speed SHUTTLE: still, 1/30, 1/10, 1/5, 1/2, 1, 2, 5
and 10 times normal in forward and reverse directions
JOG: still to 1 in forward and reverse directions

Connectors

AC IN 3-wire parallel ground

VIDEO OUT 1/2
BNC connector

AUDIO OUT CH-1/CH-2/MONITOR:
XLR male connectors

TIME CODE OUT: BNC connector

DUB OUT (U-matic H)
7-pin female connector

DUB/COMP OUT
12-pin female connector

MONITOR 8-pin connector

REMOTE 1 (9P)
9-pin connector

REMOTE 2 (36P)
36-pin connector

HEADPHONES
JM-60 headphone stereo phone jack

REF VIDEO IN 1/2
BNC connector

Operating temperature

5°C to 40°C (41°F to 104°F)

Storage temperature

-20°C to +60°C (-4°F to +140°F)

Electrical

Power requirements

100 V±10% ~ 240 V±10%, 48 - 64 Hz

Power consumption

160 W

Video

Video recording system

Luminance: FM
Chrominance: compressed time division multiplex FM

Bandwidth Luminance: 30 Hz - 4.0 MHz^{+0.5}/_{-6.0} dB
Chrominance: R-Y, 30 Hz - 1.5 MHz^{+0.5}/_{-3.0} dB
B-Y, 30 Hz - 1.5 MHz^{+0.5}/_{-3.0} dB

Signal to noise ratio

Luminance: Better than 46 dB
AM: Better than 49 dB
PM: Better than 49 dB

K-factor (2T pulse)

Less than 3%

DG

Less than 3%

DP

Less than 3°

Y/C delay

Less than 20 ns

Input

REF VIDEO IN
1.0 Vp-p ±0.3 V, 75 ohms ON/OFF

Output

VIDEO OUT 1
Composite video, 1.0 Vp-p, 75 ohms, sync negative

VIDEO OUT 2

Composite video, 1.0 Vp-p, 75 ohms, sync negative

Non-composite, 0.7 Vp-p, 75 ohms

DUB OUT (U-matic H)

Luminance:
0.5 Vp-p (at load impedance of 75 ohms), sync negative

Chrominance:
0.5 Vp-p (at load impedance of 75 ohms) (SC low-range conversion)

DUB/COMP OUT

Luminance:
1.0 Vp-p, 75 ohms, sync negative

Chrominance:
R-Y, 0.7 Vp-p, 75 ohms
B-Y, 0.7 Vp-p, 75 ohms

Audio

Frequency response

50 Hz - 15 kHz ±3.0 dB

Signal to noise ratio

Better than 50 dB (at 3% distortion level, without the audio NR system)

Distortion

Less than 2% (1 kHz reference level)

Output

AUDIO OUT CH-1/CH-2/MONITOR:

+4 dB, low impedance, balanced
(600 ohm load permissible)

Time code

2.2 Vp-p (600 ohm load permissible)

Processor adjustment range

Video level ±3 dB

Chroma level ±3 dB

Black level 0 - +15 IRE

System SC phase

360° p-p

System sync phase


+3
-1 μs

Y/C delay

±50 ns


3-2. LOCATION OF THE PRINTED CIRCUIT BOARD

< TOP VIEW >



- | | |
|---------------|---------------|
| ① AC-40 board | ⑬ SV-51 board |
| ② UR-07 | ⑭ SY-91 board |
| ③ RE-6 board | ⑮ CP-52 board |
| ④ UR-06 | ⑯ MB-42 board |
| ⑤ SW-86 board | ⑰ EX-31 board |
| ⑥ CP-56 board | ⑱ PS-16 board |
| ⑦ MB-41 board | ⑲ AU-37 board |
| ⑧ EX-30 board | ⑳ YD-15 board |
| ⑨ CK-14 board | ㉑ CD-25 board |
| ⑩ MY-17 board | ㉒ CF-12 board |
| ⑪ PR-48 board | ㉓ TC-25 board |
| ⑫ EN-20 board | ㉔ DE-12 board |

< FRONT VIEW >




- | |
|---------------|
| ⑮ LA-4 board |
| ⑯ VR-8 board |
| ⑰ HP-7 board |
| ⑱ CP-52 board |
| ⑲ ST-22 board |
| ⑳ SW-85 board |
| ㉑ DP-30 board |
| ㉒ KY-32 board |
| ㉓ PC-9 board |
| ㉔ PC-14 board |

3.3 LOCATION OF THE MECHANICAL MAIN PARTS/COMPONENTS

< TOP VIEW >

< TOP VIEW >




- ③⑤ PD-20 board
- ③⑥ PH-16 board
- ③⑦ SS-8 board
- ③⑧ LE-19 board
- ③⑨ TE-2 board
- ④① CL-7 board (cassette-up compartment)
- ④② PC-18 board (cassette-up compartment)
- ④③ PC-17 board (cassette-up compartment)

- ④④ SR-18 board
- ④⑤ LM-4 board
- ④⑥ PB-8 board
- ④⑦ SS-8 board
- ④⑧ TR-14 board
- ④⑨ HE-5 board
- ⑤① DE-11 board

3-3. LOCATION OF THE MECHANICAL MAIN PARTS/COMPONENTS

< TOP VIEW >



- | | |
|--|--------------------------------|
| ① Audio/TC head | ⑬ Supply reel soft brake |
| ② Pinch solenoid block | ⑭ Supply reel brake solenoid |
| ③ Capstan shaft | ⑮ Reel table rotation detector |
| ④ Pinch roller | ⑯ Threading ring |
| ⑤ Supply tension regulator | ⑰ Head drum |
| ⑥ CTL head | ⑱ Threading gear box |
| ⑦ Tape end sensor | ⑲ Slip ring |
| ⑧ Threading end detector | ⑳ Tape beginning sensor |
| ⑨ Threading end/unthreading end detector | ㉑ Take-up reel brake solenoid |
| ⑩ Supply reel main brake | ㉒ Take-up reel brake |
| ⑪ Supply reel table | ㉓ Take-up reel main brake |
| ⑫ Main brake solenoid | ㉔ Take-up reel table |

3.4. PRINTED CIRCUIT BOARDS

The circuit information is provided below.

System	Board	Circuit function
Video	PB-8	• PB RF amplifier
	EN-20	• Video encoder
	YD-15	• Luminance signal demodulator
	CD-25	• Chrominance signal demodulator
	CF-12	• Chrominance signal comb filter
Audio	AU-37	• Audio PB system
	VR-8	• Headphones level control
	HP-7	• Headphones jack
	SW-85	• Audio monitor select
Servo	SV-51	• Servo system
	DE-11	• Reel FG
	DE-12	• Reel FG amplifier
	PS-16	• Reel motor driver
Time code	TC-25	• Time code reader
TBC	CK-14	• Video TBC
	MY-17	
	PR-48	
	ST-22	• TBC control panel
System control	SY-91	• System control
	KY-32	• Key panel
	DP-30	• Time counter display
	PS-16	• Tape beginning sensor • Tape end sensor • Humid sensor • Brake solenoid driver • Pinch solenoid driver
	TC-25	• Threading motor driver • Cassette-up motor driver
	SW-85	• Remote select
	PC-9	• Search dial
	PC-14	• Search dial
	PD-20	• Pinch solenoid
	PH-16	• Tape roll sensor (photo-transistor)
	LE-19	• Tape roll sensor (LED)
	SS-8	• Tape beginning sensor • Tape end sensor
	TE-2	• Threading/unthreading end detector

System	Board	Circuit function
System control	TR-14	• Tape tension sensor
	LA-4	• Auto off lamp
	RE-6	• Remote connector panel
	LM-4	• Threading motor
Power	UR-06	• Switching regulator
	UR-07	• Switching regulator
	AC-40	• AC line filter
	PS-16	• DC regulator
	SW-86	• Connector panel
	CP-56	• Connector panel
	CP-52	• Control panel
	CL-7	• Cassette-up compartment
	PC-18	• Cassette-up compartment
	PC-17	• Cassette-up compartment
	SR-18	• Brush board
	HE-5	• Drum heater
	MB-41	• Mother board
	MB-42	• Mother board
	EX-30	• Extension board
	EX-31	• Extension board

2011-2012

understanding a system's structure and

SECTION 4

PERIODIC CHECK AND MAINTENANCE

4-1. SYSTEM CONTROL OPERATION CHECK

It is recommended that the following is checked daily before the operation.


The check procedure described here is only for the BVW-10P but can be applied on the operation with the remote control unit.

Note that the switches must be set according to the way the machine is used after the check.

Equipment : Recorded tape (Video, Audio CH-1/CH-2, Time Code). (Do not utilize an alignment tape.)


Video and audio monitor

With switches set to : POWER → ON
 REMOTE/LOCAL → LOCAL
 TRACKING knob → FIXED
 AUDIO MONITOR → CH-1
 CTL/TIME CODE sw → CTL



ACTION

Check that



- ● The playback speed changes from low to high.
- ● The machine putted into the fast forward mode (x10).
- ● The still picture in SHUTTLE mode appears.
- ● The playback speed changes from low to high.
- ● The machine putted into the rewind mode (x10).
- ● The still picture in JOG mode appears.
- ● The forward playback picture in the JOG mode appears.
- ● The rewind playback picture in the JOG mode appears.
- ● STANDBY lamp lights.
The still picture does not appear.
- ● The tape rewinds.
At the beginning of the tape, the tape stops automatically.
- ● The cassette is ejected.

4-2. MAINTENANCE TIME TABLE

It is recommended that the following periodic check and maintenance schedule be employed in order to obtain maximum performance and longer tape life from the BVW-10P

(Note) Do not clean the surface of the tape on the

Periodic check and maintenance schedule is going to be available soon.

4-3. MAINTENANCE AFTER REPAIR

Perform the following maintenance after repair:

Video heads and stationary heads cleaning (Refer to sec 4-4-1 and 4-4-2)

Tape movement and cleaning (Refer to sec 4-4-3)

4-3. HOUSING METER

Open the function control panel by loosening the screws on both right and left sides. The house meter glass at the back side of the function control panel.

The house meter recorder and record the elapsed time of the following modes: PLAY, STILL, F.WD, REV and SEARCH modes. It is recommended that the house meter is used as a tool for determining the normal check. When the house meter indicates the maximum value (100 hours) the house meter must be replaced with a new one.

ISOMY Part No. 1-748-100-11

4-4. CLEANING PROCEDURE


Perform the cleaning in the following procedure. After cleaning insert a cassette tape into the cleaning head cap.

4-4-1. Video Head

Place the cleaning piece mounted with the cleaning fluid and turn the drum slowly with hand.

(Note) 1. Never move the cleaning piece in the vertical direction of the head in the cleaning.

2. Perform the cleaning with the power OFF.



4-4-2. Stationary Head

Clean with the cleaning fluid mounted with the cleaning fluid.

4-3. HOURS METER

Open the function control panel by loosening the stopper screws on both right and left sides. The hours meter placed at the back side of the function control panel.

The hours meter accumulates and records the elapsed time of the following modes; PLAY, STOP, F-FWD, REW and SEARCH modes. It is recommended that the hours meter is used as a tool for determining the periodic check. When the hours meter indicates the maximum value, 1000 hours, the hours meter must be replaced with a new one.

(SONY Part No.: 1-548-100-11)


4-4. CLEANING PROCEDURE

Perform the cleaning as the following procedure. After cleaning, insert a cassette tape after the cleaning fluid evaporate completely.

4-4-1. Video Head

Press the cleaning piece moistened with the cleaning fluid and turn the drum slowly with hand.

- (Note) 1. Never move the cleaning piece in the vertical direction of the head tip in the cleaning.
2. Perform the cleaning with the power OFF.



4-4-2. Stationary Heads

Clean with the cleaning piece moistened with the cleaning fluid.

4-4-3. Tape Movement Areas

Wipe the tape bearing surface (of the tape guides, drum, capstan and pinch roller) with a piece of cleaning piece moistened with the cleaning fluid. (Note) Do not clean the surface condensation sensor on the lower drum with the cleaning cloth moistened with the cleaning fluid. Clean the surface with dry cloth.

4-5. MAINTENANCE AFTER REPAIRS


Perform the following maintenance after repair without regarding the machine operating hours.

1. Video heads and stationary heads cleaning.
(Referring sec. 4-4-1. and 4-4-2.)
2. Tape movement area cleaning.
(Referring sec. 4-4-3.)

SECTION 5


SERVICE INFORMATION

5-1. REMOVAL OF CABINET



5-2. REMOVAL OF CASSETTE-UP COMPARTMENT

1. Loosen the two fixing screws of the cassette-up compartment stay.
2. Disconnect the connector, CN-801 of the cassette-up compartment.
3. Bring up the cassette-up compartment from the machine.



5-3. NOTE FOR CHECK AND MAINTENANCE OF PRINTED CIRCUIT BOARD

Be sure to turn off power before inserting or removing of the printed circuit boards.

5-4. MODULE EXTENDER

The two types of the module extender are supplied in the machine. The Amp chassis printed circuit boards can be serviced using the module extender. Simply insert the extender into the Amp chassis and connect the circuit board to be serviced to the end of the extender.

5-5. SPARE PARTS

1. **Safety Related Components Warning.**
Components identified by shading marked with **A** on the schematic diagrams, exploded views and electrical spare parts list are critical to safe operation. Replace these components with Sony parts whose part numbers appear in this manual or in service bulletins and service manual supplements published by Sony.
2. Replacement Parts supplied from Sony Parts Center will sometimes have a different shape from the original

parts. This is due to "accommodating the improved parts and/or engineering changes" or "standardization of genuine parts".

This manual's exploded views and electrical spare parts list indicate the parts numbers of "the standardized genuine parts at present".

Regarding engineering parts changes in our engineering department, refer to Sony service bulletins and service manual supplements.

3. Printed Components in Bold-Face type on the exploded views and electrical spare parts list are normally stocked for replacement purposes. The remaining parts are not normally required for routine service work. Orders for parts not shown in Bold-Face type will be processed, but allow for additional delivery time.

5-6. TO OPERATE THE MACHINE WITHOUT INSTALLING CASSETTE TAPE

The following procedures are described without installing the cassette-up compartment.

1. Threading

Turn power on.

The threading ring rotates in the counterclockwise direction automatically, and set is put into the threading completion mode.

2. PLAY

Press PLAY button after the set is put into the threading completion mode. Then set is put into PLAY mode.

3. Unthreading

Press EJECT button. The threading ring rotates in the clockwise direction. Turn off power quickly after the set is put into the unthreading completion mode. (If the power does not turn off, the set is put into the threading mode again.)

4. Search

Turn SEARCH dial after the set is put into the threading completion mode.

5. FF and REW

The FF and REW modes cannot be obtained by only pressing the FF or REW button. (Because the tape roller guide on the threading ring does not rotate.)

Then set the S1-6 switch on the SY-91 board to the ON position. Press the FF or REW button. The set is put into the FF or REW mode.



After adjustment, the S1-6 switch must be set to OFF position.

5-7. MAINTENANCE OF KY OR DE BOARD

When perform the maintenance of the KY board or DE board, it is recommended to remove the function control panel block from the set.

The function control panel removal procedures are as follows;

1. Loosen the function control panel stopper on the right and left side panels. Open the function control panel.
2. Remove the two fixing screws as shown in figure and move the panel in the direction shown by the arrows.



5-8. CASSETTE REMOVAL PROCEDURE WHEN THE TAPE IS SLACKEN IN THE MACHINE

When the tape is slacken in the machine, remove the cassette tape as the following procedures;



1. Turn power off.
2. Turn the pulley of the gear box block until the pinch roller comes in front of the audio head while pushing the ring arm in the direction of the arrow.
3. Remove the tape that is remaining on the threading ring from the tape guides carefully so that it does not damage.
4. Remove the cassette-up compartment stay.
5. Disconnect the connector, CN801 of the cassette-up compartment.
6. Bring up the cassette-up compartment with cassette tape in it slowly so that the tape does not damage.
7. Wind the tape into the cassette tape by turning the reel hub on the back of the cassette tape with finger.
8. Turn the worm gear of the cassette-up compartment by hand in order to place the cassette-up compartment into the up state. Remove the cassette tape.
9. Locate the cause of the trouble and remedy the problem.

9-1. MAINTENANCE OF KEY OR OF BOARD

When performing the maintenance of the KEY board or DE board, it is recommended to remove the function control panel block from the set.

The function control panel removal procedure is as follows:

1. Loosen the function control panel stopper on the right and left side panels. Open the function control panel.
2. Remove the two fixing screws as shown in Figure and move the panel in the direction shown in the arrow.



9-2. CASSETTE REMOVAL PROCEDURE WHEN THE TAPE IS SLACKEN IN THE MACHINE

When the tape is slacken in the machine, remove the cassette tape in the following procedure:

1. Turn power off.
2. Turn the roller of the gear box block with the roller roller in the direction of the arrow while holding the ring and in the direction of the arrow.
3. Return the tape that is remaining on the following ring from the tape guide carefully so that it does not damage.
4. Remove the cassette tape from the cassette deck.
5. Disconnect the connection of the cassette tape from the cassette deck.
6. Bring up the cassette tape with the roller roller in the direction of the arrow and hold it in the direction of the arrow.
7. Place the tape into the cassette tape of the machine in the direction of the arrow.
8. Turn the roller of the cassette tape in the direction of the arrow.
9. Press in order to place the cassette tape in the machine.
10. Turn the up start. Remove the cassette tape.
11. Locate the cause of the trouble and proceed to the next step.

SECTION 17

SEMICONDUCTOR ELECTRODES

Type	Page
IC	
AFL25F15000G1	17-4
AM26LS31PC	17-4
AM26LS32PC	17-4
BX1056	17-4
BX1098	17-4
BX1099	17-4
BX1101	17-4
BX1140	17-4
BX1152	17-4
BX1154	17-5
BX1155	17-5
BX342	17-5
BX343	17-5
BX365A	17-5
BX366A	17-5
BX381	17-5
BX388	17-5
BX389	17-5
BX3915A	17-5
CA3054	17-6
CX130	17-6
CX134A	17-6
CX170	17-6
CX20051	17-6
CX20051A	17-6
CX20052	17-6
CX773A	17-7, 17-8
CX7903	17-8
CX7912	17-9, 17-10
CX894	17-10
HA1-4905	17-10
HD10105	17-10
HD10116	17-10
HD10124	17-10
HD10125	17-10
HD10131	17-11
HD14011BP	17-11
HD14069UBP	17-11
HD14538BP	17-11
HI1-201	17-11
HM6116LP-2	17-11
LH0080	17-12
LH0082	17-12
LH0084	17-13

Type	Page
LM358P	17-13
M54517P	17-13
M54523P	17-13
M54529P	17-13
M54532P	17-13
M54543L	17-14
MB84001B	17-14
MB84011B	17-11
MB84013B	17-14
MB84049UB	17-14
MB84051B	17-14
MB84053B	17-14
MB84069UB	17-11
MB84070B	17-14
MB84081B	17-14
MBM2149L-55	17-15
MBM2732A-35Z	17-15
MC10113L	17-15
MC10124L	17-10
MC10125L	17-10
MC10198L	17-15
MC14011BCP	17-11
MSM2128-1AS	17-15
MSM2128-12RS	17-15
MSM2128-15RS	17-15
MSM4022RS	17-16
MSM4094RS	17-16
MSM5128-12RS	17-11
NJM2043D	17-16
NJM2903D	17-16
NJM4558D	17-16
NJM4560D	17-16
NJM4562D	17-16
NJM78L**A	17-17
NJM78M**A	17-17
SN7400N	17-17
SN7404N	17-17
SN7406N	17-17
SN7408N	17-17
SN74191N	17-17
SN74265N	17-17
SN74273N	17-18
SN74365AN	17-18
SN74LS00N	17-17
SN74LS02N	17-18
SN74LS04N	17-17
SN74LS05N	17-18
SN74LS08N	17-17

SEMICONDUCTOR ELECTRODES


Type	Page	Type	Page
SN74LS10N	17-18	TC4093BP	17-24
SN74LS11N	17-18	TC40H004P	17-24
SN74LS112AN	17-18	TC40H011P	17-24
SN74LS113AN	17-18	TC40H032P	17-24
SN74LS123N	17-19	TC40H042P	17-24
SN74LS151N	17-19	TC40H074P	17-24
SN74LS157N	17-19	TC40H138P	17-24
SN74LS161AN	17-19	TC40H139P	17-24
SN74LS163AN	17-19	TC40H240P	17-25
SN74LS164N	17-20	TC40H244P	17-25
SN74LS166AN	17-20	TC40H245P	17-25
SN74LS174N	17-20	TC40H273P	17-25
SN74LS175N	17-20	TC40H368P	17-25
SN74LS191N	17-17	TC4516BP	17-25
SN74LS20N	17-20	TC4528BP	17-26
SN74LS221N	17-20	TC4532BP	17-26
SN74LS273N	17-18	TC4543BP	17-26
SN74LS30N	17-20	TC5067BP	17-26
SN74LS32N	17-20		
SN74LS374N	17-21	TL082CP	17-26
SN74LS37N	17-21	TL084CN	17-26
SN74LS393N	17-21	TL601CP	17-26
SN74LS423N	17-21	TL607CP	17-26
SN74LS74AN	17-21	TL8605P	17-27
SN74LS85N	17-21		
SN74S163N	17-19	μ A760HC	17-27
SN74S32N	17-20	μ A796HC	17-27
SN74S51N	17-22		
SN75107AN	17-22	μ PC143**H	17-27
SN75110AN	17-22	μ PC319C	17-27
SN75207BN	17-22	μ PC324C	17-27
SN75452BP	17-22	μ PC339C	17-27
SN75454BP	17-22	μ PC358C	17-13
		μ PC4082C	17-26
TA7060AP	17-22	μ PC4557C	17-27
TA78L***AP	17-22	μ PC4558C	17-16
		μ PC78**H	17-27
TC4001BP	17-14	μ PC78L**A	17-27
TC4011BP	17-11	μ PC79**H	17-28
TC4013BP	17-22		
TC4020BP	17-22	μ PD4069UBC	17-11
TC4021BP	17-23	μ PD4519BC	17-28
TC4022BP	17-16	μ PD4584BC	17-28
TC4024BP	17-23	μ PD5101LC-1	17-28
TC4030BP	17-23		
TC4049BP	17-14		
TC4050BP	17-23	Transistor	
TC4051BP	17-14		
TC4053BP	17-14	2SA1005	17-29
TC4066BP	17-23	2SA1015	17-29
TC4069UBP	17-11	2SA1026	17-29
TC4071BP	17-23	2SA1027R	17-29
TC4073BP	17-23	2SA1048	17-29
TC4075BP	17-23	2SA1115	17-29
TC4081BP	17-14	2SA1175	17-29

SEMICONDUCTOR ELECTRODES


Type	Page	Type	Page
2SA530H	17-29	Diode	
2SA733	17-29		
2SA772	17-29	GL5-HD5	17-29
2SA773	17-29	LN25RP	17-29
2SA844	17-29	LN35BP	17-29
2SA925	17-29	SE301A	17-29
		TLO124	17-29
2SB507HP	17-29	TLR321	17-29
2SB548	17-29		
2SB553	17-29	Others	
2SB733	17-29		
2SB734	17-29	DM-208	17-29
2SB739	17-29	DM-211	17-29
2SB740	17-29	PS4005-L	17-29
2SB825	17-29		
2SB857	17-29		
2SB858	17-29		
2SC1275	17-29		
2SC1310	17-29		
2SC1363	17-29		
2SC1364	17-29		
2SC1474	17-29		
2SC1475	17-29		
2SC1636	17-29		
2SC1815	17-29		
2SC1983	17-29		
2SC2458	17-29		
2SC2603	17-29		
2SC2724	17-29		
2SC2771	17-29		
2SC2785	17-29		
2SC2901	17-29		
2SC403C	17-29		
2SC403SP	17-29		
2SC689H	17-29		
2SC945	17-29		
2SD1134	17-29		
2SD313HP	17-29		
2SD414	17-29		
2SD553	17-29		
2SD774	17-29		
2SD789	17-29		
2SD795	17-29		
2SD880	17-29		
2SD882	17-29		
2SK240-BL	17-29		
2SK43	17-29		
TPS601-B	17-29		
JC501	17-29		

SEMICONDUCTOR ELECTRODES

AFL25F15000G1 (MURATA)
ACTIVE LOW-PASS FILTER
— IMPRINTED SIDE VIEW —




AM26LS31PC (ADVANCED MICRO DEVICE)
HIGH SPEED DIFFERENTIAL LINE DRIVER
— TOP VIEW —



EN2	EN1	OUTPUT
0	0	ENABLE
0	1	ENABLE
1	0	HI-Z
1	1	ENABLE

AM26LS32PC (ADVANCED MICRO DEVICE)
HIGH SPEED DIFFERENTIAL LINE RECEIVER
— TOP VIEW —




EN2	EN1	OUTPUT
0	0	ENABLE
0	1	ENABLE
1	0	HI-Z
1	1	ENABLE


0; LOW LEVEL
1; HIGH LEVEL
HI-Z; HIGH IMPEDANCE

SENSE	INPUT VOLT
LS32	$\pm 200\text{mV}$ $\pm 7\text{V}$
LS33	$\pm 500\text{mV}$ $\pm 15\text{V}$


BX1056 (SONY)
CHROMA FREQUENCY CONVERTER
— REAR VIEW —




BX1152 (SONY)
DOLBY (C TYPE) NOISE REDUCTION SYSTEM
— REAR VIEW —




BX1154 (SONY)
DRUM PWM
— REAR VIEW —




BX1155 (SONY)
CAPSTAN PWM
— REAR VIEW —




BX342 (SONY)
AMPLIFIER/DETECTOR
— REAR VIEW —




BX343 (SONY)
OSCILLATOR/DETECTOR
— REAR VIEW —




BX365A (SONY)
VIDEO AMPLIFIER
— SIDE VIEW —




BX366A (SONY)
VIDEO BUFFER
— SIDE VIEW —




BX381 (SONY)
PHASE COMPARATOR
— SIDE VIEW —




BX388 (SONY)
VIDEO AMP/VD MIXER
— IMPRINTED SIDE —



BX389 (SONY)
VIDEO AMPLIFIER
— IMPRINTED SIDE —



BX3915A (SONY)
SYNC SEPARATOR
— IMPRINTED SIDE —



UNIVERSITY OF ALABAMA

CONT.INPUT (PIN6)	SW
LOW OR OPEN	
HIGH	

	1	A-VEE	D-GND	28
	2	NC	D-VEE	27
DIGITAL INPUT	3	A-VEE	NC	26
D1	4		NC	25
D2	5		A-VEE	24
D3	6		23	1 SET (OUTPUT 1 CONTROL)
D4	7		A-GND	22
D5	8		A-GND	21
D6	9		20	OUTPUT
D7	10		NC	19
D8	11		NC	18
D9	12		17	T (CLOCK)
D10	13		16	$\bar{T}$ (CLOCK)
	14	D-GND	D-VEE	15

	1	H-COMP BIAS		28	VRB IN	24	VRT	MSB: D1	12
T IN (CLOCK)	2			27	VRL IN	23	VRH		10
T IN (CLOCK)	3			27	VRL IN	27	VRL		04
	4	D-GND		26	VRM IN	26	VRB		05
D8 OUT (LSB)	5			25	VRH IN	21	A-SIG	LSB: D8	5
D7 OUT	6			24	VRT IN				4
			A-VEE (-5V)	23		2		A-GND	22
D6 OUT	7		A-GND	22		3	T	A-GND	15
								D-GND	13
D5 OUT	8			21	A-SIG IN			D-GND	4
								A-VEE A-VEE D-VEE	23 19 16
D4 OUT	9		A-GND	20					
D3 OUT	10		A-VEE (-5V)	19					
D2 OUT	11		NC	18					
D1 OUT (MSB)	12		NC	17					
	13	D-GND	NC	16					
	14	D-VEE (-5V)	D-GND	15					

TIMING DIAGRAM

T (CLOCK)

A-SIG IN (S/H SIGNAL)

DIGITAL
OUT

OUTPUT CODING			
STEP	RANGE EX. 2.000V FULL SCALE	MSB	LSB
000	0.0000V	11111111	
001	-0.0078V	11111110	
:	:	:	:
127	-0.9961V	10000000	
128	-1.0039V	01111111	
129	-1.0118V	01111110	
:	:	:	:
255	-2.0000V	00000000	

The timing diagram illustrates the relationship between the A-SIG IN (S/H SIGNAL), the T (CLOCK), and the DIGITAL DATA. The A-SIG IN signal is sampled at the rising edges of the clock. The diagram shows three samples: SAMPLE N, SAMPLE N+1, and SAMPLE N+2. The digital data is shown as a sequence of bits: DATA N-1, DATA N, and DATA N+1. The A-SIG IN signal is sampled at the rising edges of the clock, which occur at the boundaries of the digital data words.

SAMPLING PULSE

A-SIG IN

T(CLOCK)

T_A

T_B

T_C

T



$T_A > 2ns$

$T_B > 20ns$


$T_C > 2ns$

T_H : UPPER 4-BIT A/D ACTION TIMING

T_L : LOWER 4-BIT A/D ACTION TIMING



CX773A (SONY)
C-MOS SYNC GENERATOR (NTSC, PAL-M, PAL, SECAM)
— TOP VIEW —




O/E : ODD/EVEN FIELD
CF : COLOUR FRAME PULSE
HCOM : H COMPARATOR


SYSTEM	4Fsc	CLOCK
NTSC	910 FH	910 FH
PAL	1135 FH+2FV	908 FH
PALM	909 FH	910 FH
SECAM		908 FH

INTUPS	SYSTEM	INTUPS	FUNCTION
MODE1	MODE2	EXT	TEST
0	0	0	INTERNAL
0	1	0	INVALID
1	0	0	EXT
1	1	1	TEST



*1 : VDD
*0 : GND
TEST '0': OPEN
INTERNAL (PULLED DOWN)




NTSC, PAL-M (FIELD 1, 3)




NTSC, PAL-M (FIELD 2, 4)




PAL, SECAM (FIELD 4, 2)




PAL, SECAM (FIELD 1, 3)



P: PAL, SECAM
N: NTSC, PALM




CX7903 (SONY)
CMOS GENLOCK DRIVER FOR CX773A
— TOP VIEW —



INPUTS		EXT LOCK MODE
MODE2	MODE1	
0	0	M1 PAL:VBS
0	1	M2 PALM:VBS
1	0	M3 PAL:VS/SC/LA SECAM:VS/SC/LA
1	1	M4 NTSC:VBS NTSC:VS/SC PALM:VS/SC/LA

0 : LOW LEVEL
1 : HIGH LEVEL




SEMICONDUCTOR ELECTRODES

SEMICONDUCTOR ELECTRODES


HD14538BP (HITACHI)
C-MOS DUAL RETRIGGERABLE/NON-RETRIGGERABLE
MONOSTABLE MULTIVIBRATOR

-TOP VIEW-



RETRIGGERABLE M.M.V.


NON-RETRIGGERABLE M.M.V.



HD14069UBP (HITACHI)
MB84069UB (FUJITSU)
TC4069UBP (TOSHIBA)
μPD4069UBC (NEC)

C-MOS INVERTER


-TOP VIEW-



HI1-201 (HARRIS)

C-MOS ANALOG SWITCH

-TOP VIEW-




* NOTE

INTERFACE	VREF CONNECTION
TTL	OPEN
C-MOS	VDD ≤ 5.5V ; OPEN VDD > 5.5V ; TO VDD

HD10131 (HITACHI)
ECL D-TYPE FLIP FLOP


-TOP VIEW-



HD14011BP (HITACHI)
MB84011B (FUJITSU)
MC14011BCP (MOTOROLA)
TC4011BP (TOSHIBA)


C-MOS 2-INPUT NAND GATE

-TOP VIEW-





HM6116P-2 (HITACHI) (ACCESS TIME = 120 nS)
MSM5128-12RS (OKI) (ACCESS TIME = 120 nS)
C-MOS 16384(2048x8)-BIT HIGH SPEED STATIC RAM

-TOP VIEW-





SEMICONDUCTOR ELECTRODES

LH0080 (SHARP)
N-MOS 8-BIT MICROPROCESSOR
— TOP VIEW —



SEMICONDUCTOR 17.

LH0082 (SHARP)
N-MOS COUNTER TIMER CIRCUIT
— TOP VIEW —



phi : SYSTEM CLOCK
CE : CHIP ENABLE
CS0, CS1 : CHANNEL SELECT
CT0-CT3 : EXTERNAL CLOCK/TIMER TRIGGER
D0-D7 : 3-STATE DATA INPUT/OUTPUT
IEI : INTERRUPT ENABLE INPUT
IEO : INTERRUPT ENABLE OUTPUT
INT : INTERRUPT REQUEST (OPEN DRAIN)
IORQ : I/O REQUEST
M1 : MACHINE CYCLE 1
READ : READ CYCLE STATUS
Z0-Z2 : ZERO COUNT/TIME OUT

CHANNEL SELECT FUNCTION

CS1	CS0	SELECTED CHANNEL
0	0	0
0	1	1
1	0	2
1	1	3

0: LOW LEVEL
1: HIGH LEVEL

17. SEMICONDUCTOR

Pinout for 8255 PPI:


- Pin 1:** D1 I/O
- Pin 2:** D3 I/O
- Pin 3:** D5 I/O
- Pin 4:** D7 I/O
- Pin 5:** INT OUT
- Pin 6:** IEI IN
- Pin 7:** IEO OUT
- Pin 8:** MI IN
- Pin 9:** +5V
- Pin 10:** W/RDY A OUT
- Pin 11:** SYNC A I/O
- Pin 12:** RXD A IN
- Pin 13:** RXC A IN
- Pin 14:** TXC A IN
- Pin 15:** TXD A OUT
- Pin 16:** DTR A OUT
- Pin 17:** RTS A OUT
- Pin 18:** CTS A IN
- Pin 19:** DCD A IN
- Pin 20:** Ø IN
- Pin 21:** RESET IN
- Pin 22:** DCD B IN
- Pin 23:** CTS B IN
- Pin 24:** RTS B OUT
- Pin 25:** DTR B OUT
- Pin 26:** TXD B OUT
- Pin 27:** RXTXC B IN
- Pin 28:** RXD B IN
- Pin 29:** SYNC B I/O
- Pin 30:** W/RDY B OUT
- Pin 31:** GND
- Pin 32:** RD IN
- Pin 33:** C/D IN
- Pin 34:** B/A IN
- Pin 35:** CE IN
- Pin 36:** IORQ IN
- Pin 37:** D6 I/O
- Pin 38:** D4 I/O
- Pin 39:** D2 I/O
- Pin 40:** D0 I/O

Channel Select Function Table:



C/D	B/A	FUNCTION
0	0	CH-A DATA
0	1	CH-B DATA
1	0	CH-A CONT. WORK
1	1	CH-B CONT. WORK

0: LOW LEVEL


—TOP VIEW—



TRANSISTOR
- TOP VIEW -




- TOP VIEW -





IN	EN	OUT
0	1	1
1	1	0
X	0	OPEN

TOP VIEW



SEMICONDUCTOR ELECTRODES


M54543L (MITSUBISHI)
BI-DIRECTIONAL MOTOR DRIVER
—SIDE VIEW—




IN	OUT	MODE
1 2 1 2		
0 0 Z Z		NO OPERATION
1 0 1 0		ROTATION
0 1 0 1		REVERSE ROTATION
1 1 0 0		BRAKE

0: LOW LEVEL
1: HIGH LEVEL
Z: HIGH IMPEDANCE


MB84001B (FUJITSU)
TC4001BP (TOSHIBA)
C-MOS 2-INPUT NOR GATE
—TOP VIEW—




MB84013B (FUJITSU)
C-MOS D-TYPE FLIP FLOP WITH DIRECT SET/RESET
—TOP VIEW—



MB84049UB (FUJITSU)
TC4049BP (TOSHIBA)
C-MOS INVERTING TYPE BUFFER/CONVERTER
—TOP VIEW—




MB84051B (FUJITSU)
TC4051BP (TOSHIBA)
C-MOS 8-CHANNEL MULTIPLEXER/DEMULTIPLEXER
—TOP VIEW—



EN	C	B	A	"ON" CHANNEL
0	0	0	0	0
0	0	0	1	1
0	0	1	0	2
0	0	1	1	3
0	1	0	0	4
0	1	0	1	5
0	1	1	0	6
0	1	1	1	7
1	X	X	X	OPEN


X: DON'T CARE
1: HIGH LEVEL
0: LOW LEVEL

MB84053B (FUJITSU)
TC4053BP (TOSHIBA)
C-MOS 2-CHANNEL MULTIPLEXER/DEMULTIPLEXER
—TOP VIEW—




CONT. INPUTS	ON CHANNEL
EN A (XYZ)	
0 0 0	0
0 1 1	1
1 X X	OPEN

MB84070B (FUJITSU)
C-MOS EXCLUSIVE OR GATE
—TOP VIEW—




MB84081B (FUJITSU)
TC4081BP (TOSHIBA)
C-MOS 2-INPUT AND GATE
—TOP VIEW—




SEMICONDUCTOR ELECTRODES

MBM2149L-55 (FUJITSU)
N-MOS 4096-BIT(1024x4) STATIC RAM WITH 3-STATE OUTPUT
-TOP VIEW-




A0-A9 : ADDRESS INPUTS
CS : CHIP SELECT INPUT
D0-D3 : DATA INPUT/OUTPUT (3-STATE)
W/R : WRITE/READ ENABLE INPUT




TYPE	-45	-55	-70	L-55	L-70
ADDRESS ACCESS TIME (MAX)	45ns	55ns	70ns	55ns	70ns
CHIP SELECT ACCESS TIME (MAX)	20ns	25ns	30ns	25ns	30ns
Icc (MAX)	180mA	160mA	180mA	125mA	125mA


MBM2732A-35Z (FUJITSU)
32K(4K-8) UV ERASABLE PROM
-TOP VIEW-



MC10113L (MOTOROLA)
ECL EXCLUSIVE OR GATE
-TOP VIEW-



MC10198L (MOTOROLA)
RETRIGGERABLE MONOSTABLE MULTIVIBRATOR
-TOP VIEW-




T : CLOCK TRIGGER INPUT
THS : HIGH-SPEED CLOCK TRIGGER INPUT
EN+ : TRIGGER POSITIVE ENABLE
EN- : TRIGGER NEGATIVE ENABLE
PWC : EXTERNAL PULSE WIDTH CONTROL

EN+	EN-	TRIG. SLOPE
0	0	1
0	1	1
1	0	1
1	1	DISABLE

OUTPUT PULSE WIDTH: PWQ
PWQ = 1.19 * CEXT (EXT + 284)

WHERE
PWQ : SEC
CEXT : FARADS
EXT : OHMS
VEE : -5.2V
PWC : -3.6V
NOTE : SELECT REXT RANGING FROM ZERO TO 16K OHMS.
SELECT CEXT GREATER THAN 20PF.


MSM2128-1AS (OKI) (ACCESS TIME = 200ns)
MSM2128-12RS (OKI) (ACCESS TIME = 300ns)
MSM2128-15RS (OKI) (ACCESS TIME = 450ns)
N-MOS 16384(2048x8)-BIT STATIC RAM
-TOP VIEW-



SEMICONDUCTOR ELECTRODES

MSM4022RS (OKI)
TC4022BP (TOSHIBA)
C-MOS OCTAL COUNTER/DIVIDER

—TOP VIEW—




COUNT	RD	T1-T2	7	6	5	4	3	2	1	0	CO
0	1	X	0	0	0	0	0	0	1	0	1
0	0	—	0	0	0	0	0	0	1	1	—
1	0	—	0	0	0	0	0	0	1	0	1
2	0	—	0	0	0	0	0	1	0	0	1
3	0	—	0	0	0	0	1	0	0	0	1
4	0	—	0	0	0	1	0	0	0	0	0
5	0	—	0	0	1	0	0	0	0	0	0
6	0	—	0	1	0	0	0	0	0	0	0
7	0	—	1	0	0	0	0	0	0	0	0
NOCOUNT	0	1									
	0	0									

1: HIGH
0: LOW
X: DON'T CARE

MSM4094RS (OKI)
C-MOS 8-STAGE SHIFT-AND-STORE BUS REGISTER

—TOP VIEW—




SI: SERIAL DATA INPUT
T: CLOCK INPUT
STRB: STROBE INPUT
EN: OUTPUT ENABLE INPUT
Q1~Q8: PARALLEL DATA OUTPUTS
Q'S, Q'S: SERIAL DATA OUTPUTS

INPUTS				PARALLEL OUT		SERIAL OUT
T	EN	STRB	SI	Q1	Qn	Q'S
—	0	X	X	HI-Z	HI-Z	Q7
—	0	X	X	HI-Z	HI-Z	Q7
—	1	0	X	NC	NC	Q7
—	1	1	0	0	Qn-1	Q7
—	1	1	1	1	Qn-1	Q7
—	1	1	1	NC	NC	Q7

1: HIGH
0: LOW
X: DON'T CARE
HI-Z: HIGH IMPEDANCE
NC: NO CHANGE


NJM2043D (JRC)
OPERATIONAL AMPLIFIER

—TOP VIEW—




NJM2903D (JRC)
OPERATIONAL AMPLIFIER

—TOP VIEW—




NJM4558D (JRC)
μPC4558C (NEC)
OPERATIONAL AMPLIFIER

—TOP VIEW—




NJM4560D (JRC)
OPERATIONAL AMPLIFIER

—TOP VIEW—




NJM4562D (JRC)
OPERATIONAL AMPLIFIER

—TOP VIEW—




SEMICONDUCTOR ELECTRODES


NJM78L□□A (JRC)
VOLTAGE REGULATOR




2V NJM78L02A
5V NJM78L05A
6V NJM78L06A
8V NJM78L08A
9V NJM78L09A
12V NJM78L12A
15V NJM78L15A





NJM78M□□A (JRC)
VOLTAGE REGULATOR
— FRONT VIEW —





5V NJM78M05A
6V NJM78M06A
8V NJM78M08A
9V NJM78M09A
12V NJM78M12A
15V NJM78M15A
18V NJM78M18A
20V NJM78M20A
24V NJM78M24A





SN7400N (TI)
SN74LS00N (TI)
TTL NAND GATE
— TOP VIEW —





SN7404N (TI)
SN74LS04N (TI)
TTL INVERTER
— TOP VIEW —





SN7406N (TI)
TTL INVERTER BUFFER/DRIVER
WITH OPEN-COLLECTOR
— TOP VIEW —



SN7408N (TI)
SN74LS08N (TI)
TTL 2-INPUT POSITIVE-AND GATE
— TOP VIEW —




SN74191N (TI)
SN74LS191N (TI)
TTL PRESETTABLE SYNCHRONOUS 4-BIT BINARY UP/DOWN COUNTER
— TOP VIEW —



MODE SELECTION

CONTROL INPUTS			MODE
PE	EN	UP/DWN	
0	X	X	PRESET (ASYNCHRONOUS)
1	1	X	NO COUNT
1	0	0	UP COUNT
1	0	1	DOWN COUNT

0: LOW LEVEL
1: HIGH LEVEL
X: DON'T CARE.



COUNT SEQUENCE


COUNT	OUTPUTS			
	QD	QC	QB	QA
0	0	0	0	0
1	0	0	0	1
2	0	0	1	0
3	0	0	1	1
4	0	1	0	0
5	0	1	0	1
6	0	1	1	0
7	0	1	1	1
8	1	0	0	0
9	1	0	0	1
10	1	0	1	0
11	1	0	1	1
12	1	1	0	0
13	1	1	0	1
14	1	1	1	0
15	1	1	1	1

UP COUNT
DOWN COUNT

CA/BRW1 OUTPUT IS HIGH WHEN COUNT IS "15" AT UP-COUNT OR WHEN COUNT IS "0" AT DOWN COUNT.


CA/BRW2 OUTPUT IS LOW WHEN BOTH THE CLOCK AND EN INPUTS ARE LOW AND CA/BRW1 OUTPUT IS HIGH.

SN74265N (TI)
TTL COMPLEMENTARY-OUTPUT ELEMENT
— TOP VIEW —





SEMICONDUCTOR ELECTRODES


SN74273N (TI)
SN74LS273N (TI)
TTL D-TYPE FLIP-FLOP WITH DIRECT RESET
— TOP VIEW —




SN74LS10N (TI)
TTL 3-INPUT POSITIVE NAND GATE
— TOP VIEW —




SN74LS11N (TI)
TTL 3-INPUT POSITIVE-NAND GATE
— TOP VIEW —




SN74365AN (TI)
TTL 3-STATE BUS DRIVER
— TOP VIEW —




SN74LS02N (TI)
TTL 2-INPUT POSITIVE-NOR GATE
— TOP VIEW —




SN74LS05N (TI)
TTL INVERTER WITH OPEN-COLLECTOR
— TOP VIEW —



SN74LS112AN (TI)
TTL J-K FLIP-FLOP WITH DIRECT SET/RESET
— TOP VIEW —



SN74LS113AN (TI)
TTL J-K FILP FLOP WITH DIRECT SET
— TOP VIEW —




SEMICONDUCTOR ELECTRODES

SN74LS123N (TI)

TTL RETRIGGERABLE MONOSTABLE MULTIVIBRATOR WITH DIRECT RESET

— TOP VIEW —



INPUTS	OUTPUTS
Rd A B Q	Q
L X X L H	
X H X L H	
X X L L H	
H L L L L	
L L L L L	

OUTPUT PULSE WIDTH

$$t_{W123} = 0.28 \left(1 + \frac{700}{R} \right) CR$$

$$t_{W123} = 0.33 \left(1 + \frac{700}{R} \right) CR$$


$$t_{W123} = 0.29 \left(1 + \frac{700}{R} \right) CR$$

$$t_{W123} = 0.29 \left(1 + \frac{700}{R} \right) CR$$

SN74LS161AN (TI)

TTL PRESETTABLE SYNCHRONOUS 4-BIT BINARY COUNTER

— TOP VIEW —



MODE SELECTION

CONTROL INPUTS	MODE
Rd PE EN1 EN2	
0 X X X	RESET (ASYNCHRONOUS)
1 0 X X	PRESET (SYNCHRONOUS)
1 1 0 X	NO COUNT
1 1 X 0	NO COUNT
1 1 1 1	COUNT

0; LOW LEVEL
1; HIGH LEVEL
X; DON'T CARE

CARRY OUTPUT "CO"

CO IS HIGH WHEN EN2 INPUT IS HIGH AND COUNT IS "15"


COUNT SEQUENCE

COUNT	QD	QC	QB	QA
0	0	0	0	0
1	0	0	0	1
2	0	0	1	0
3	0	0	1	1
4	0	1	0	0
5	0	1	0	1
6	0	1	1	0
7	0	1	1	1
8	1	0	0	0
9	1	0	0	1
10	1	0	1	0
11	1	0	1	1
12	1	1	0	0
13	1	1	0	1
14	1	1	1	0
15	1	1	1	1

SN74LS151N (TI)

TTL 8-LINE-TO-1-LINE DATA SELECTOR/MULTIPLEXER

— TOP VIEW —




CONTROL INPUTS	ON CHANNEL
INH C B A	
0 0 0 0	0
0 0 0 1	1
0 0 1 0	2
0 0 1 1	3
0 1 0 0	4
0 1 0 1	5
0 1 1 0	6
0 1 1 1	7
1 X X X	GND

0; LOW LEVEL
1; HIGH LEVEL
X; DON'T CARE

SN74LS163AN (TI)

TTL PRESETTABLE SYNCHRONOUS 4-BIT BINARY COUNTER

— TOP VIEW —



MODE SELECTION

CONTROL INPUTS	MODE
Rd PE EN1 EN2	
0 X X X	RESET (SYNCHRONOUS)
1 0 X X	PRESET (SYNCHRONOUS)
1 1 0 X	NO COUNT
1 1 X 0	NO COUNT
1 1 1 1	COUNT

0; LOW LEVEL
1; HIGH LEVEL
X; DON'T CARE

CARRY OUTPUT "CO"

CO IS HIGH WHEN EN2 INPUT IS HIGH AND COUNT IS "15"


COUNT SEQUENCE

COUNT	QD	QC	QB	QA
0	0	0	0	0
1	0	0	0	1
2	0	0	1	0
3	0	0	1	1
4	0	1	0	0
5	0	1	0	1
6	0	1	1	0
7	0	1	1	1
8	1	0	0	0
9	1	0	0	1
10	1	0	1	0
11	1	0	1	1
12	1	1	0	0
13	1	1	0	1
14	1	1	1	0
15	1	1	1	1

SN74LS157N (TI)

TTL 2-LINE-TO-1-LINE DATA SELECTOR/MULTIPLEXER

— TOP VIEW —





CONT. IN	ON CHANNEL
INH A	
L L	0
L H	1
H X	GND

SEMICONDUCTOR ELECTRODES

SN74LS164N (TI)


TTL 8-BIT PARALLEL-OUT SERIAL SHIFT REGISTER

—TOP VIEW—



INPUTS	OUTPUTS
Rd T A B	Q1 Q2 Q3 Q4 Q5 Q6 Q7 Q8
0 X X X	0 0 0 0 0 0 0 0
1 0 X X	Q1n Q2n Q3n Q4n Q5n Q6n Q7n Q8n
1 1 1 1	1 1 1 1 1 1 1 1
1 0 X X	Q1n Q2n Q3n Q4n Q5n Q6n Q7n Q8n
1 1 X 0	0 Q1n Q2n Q3n Q4n Q5n Q6n Q7n


0; LOW LEVEL
1; HIGH LEVEL
X; DON'T CARE




SN74LS166AN (TI)

TTL 8-BIT SHIFT REGISTER

—TOP VIEW—




SD; SERIAL DATA INPUT
P1~P8; PARALLEL DATA INPUTS



SN74LS174N (TI)

TTL D-TYPE FLIP-FLOP WITH DIRECT RESET

—TOP VIEW—



EACH FLIP-FLOP


INPUTS	OUT
Rd T D Q	Q
0 X X X	0
1 0 X X	Qn
1 1 1 1	1
1 0 X 0	Qn

0; LOW LEVEL
1; HIGH LEVEL
X; DON'T CARE

SN74LS175N (TI)

TTL D-TYPE FLIP-FLOP WITH CLEAR

—TOP VIEW—




INPUTS	OUTPUTS
Rd T D Q	Q
0 X X 0	1
1 0 1 0	1
1 0 0 1	1
1 0 X 0	Qn

0; LOW LEVEL
1; HIGH LEVEL
X; DON'T CARE

SN74LS20N (TI)

TTL 4-INPUT POSITIVE NAND GATE

—TOP VIEW—



$$X = ABCD = A + B + C + D$$


A	B	C	D	X
0	0	0	0	1
0	0	0	1	1
0	0	1	0	1
0	0	1	1	1
0	1	0	0	1
0	1	0	1	1
0	1	1	0	1
0	1	1	1	1
1	0	0	0	1
1	0	0	1	1
1	0	1	0	1
1	0	1	1	1
1	1	0	0	1
1	1	0	1	1
1	1	1	0	1
1	1	1	1	1

0; LOW LEVEL
1; HIGH LEVEL

SN74LS221N (TI)

TTL MONOSTABLE MULTIVIBRATOR WITH SCHMITT TRIGGER INPUT

—TOP VIEW—




INPUTS	OUTPUTS
Rd A B C	Q
L X X L	H
X H X L	H
X X L L	H
H L L L	L
L L L L	L
L L L H	L
L L H L	L
L L H H	L
L H L L	L
L H L H	L
L H H L	L
L H H H	L
H L L L	L
H L L H	L
H L H L	L
H L H H	L
H H L L	L
H H L H	L
H H H L	L
H H H H	L

OUTPUT PULSE WIDTH = 0.7CR

SN74LS30N (TI)

TTL 8-INPUT NAND GATE

—TOP VIEW—




$$X = A \cdot B \cdot C \cdot D \cdot E \cdot F \cdot G \cdot H$$

$$= A + B + C + D + E + F + G + H$$

SN74LS32N (TI)

TTL 2-INPUT POSITIVE - OR GATE

—TOP VIEW—




$$Y = A + B = A \cdot B$$

A	B	Y
0	0	0
0	1	1
1	0	1
1	1	1


0; LOW LEVEL
1; HIGH LEVEL

SEMICONDUCTOR ELECTRODES


SN74LS374N (T1)
TTL 3-STATE OCTAL D-TYPE FLIP-FLOP
— TOP VIEW —




SN74LS423N (T1)
TTL RETRIGGERABLE MONOSTABLE MULTIVIBRATOR WITH DIRECT RESET
— TOP VIEW —




SN74LS37N (T1)
TTL 2-INPUT POSITIVE-NAND GATE BUFFER
— TOP VIEW —




SN74LS74AN (T1)
TTL D-TYPE FLIP FLOP WITH DIRECT SET/RESET
— TOP VIEW —



SN74LS393N (T1)
TTL 4-BIT BINARY COUNTER
— TOP VIEW —





SN74LS85N (T1)
TTL 4-BIT MAGNITUDE COMPARATOR
— TOP VIEW —



SEMICONDUCTOR ELECTRODES



SN74S51N (TI)

TTL 2-WIDE 2-INPUT AND-OR-INVERT GATE
— TOP VIEW —



SN75454BP (TI)


TTL PERIPHERAL POSITIVE-NOR DRIVER
WITH OPEN COLLECTOR
— TOP VIEW —



A	B	X
0	0	1
0	1	0
1	0	0
1	1	0

SN75107AN (TI)

LINE RECEIVER
— TOP VIEW —




DIFF. INPUTS	EN	ENC	Y
$B - A \leq 25\text{mV}$	X	X	H
$ B - A < 25\text{mV}$	X	L	H
	L	X	H
	H	H	N-D
$B - A \geq 25\text{mV}$	X	L	H
	L	X	H
	H	H	L

ND: NOT DEFINED

TA78L000AP (TOSHIBA)


VOLTAGE REGULATOR



+5V	TA78L005AP
+6V	TA78L006AP
+7V	TA78L007AP
+7.5V	TA78L075AP
+8V	TA78L008AP
+9V	TA78L009AP
+10V	TA78L010AP
+12V	TA78L012AP
+13.2V	TA78L0132AP
+15V	TA78L015AP
+18V	TA78L018AP
+20V	TA78L020AP
+24V	TA78L024AP

SN7510AN (TI)


LINE DRIVER
— TOP VIEW —



IN	OUT
A B C D	Y Z
X X X L	OFF OFF
X X L X	OFF OFF
X L H H	ON OFF
L X H H	ON OFF
H X H H	OFF ON
H H H H	OFF ON

TC4013BP (TOSHIBA)

C-MOS D-TYPE FLIP FLOP WITH DIRECT SET/RESET
CLOCK
— TOP VIEW —




DIRECT R-S FLIP FLOP	D-TYPE FLIP FLOP
S _D R _D Q _D	I _n I _n 1
0 0 0 0	D Q
0 1 0 1	0 0
1 0 1 0	1 1
1 1 0 1	1 1

CLOCK T₁
I_n: BEFORE CLOCK
I_n1: AFTER CLOCK
0: LOW LEVEL
1: HIGH LEVEL

SN75207BN (TI)

BIPOLAR LINE RECEIVER (TTL COMPATIBLE)
— TOP VIEW —





INPUTS	OUT
B - A	EN ENC Y
$B - A \leq 10\text{mV}$	X 0 1
	0 X 1
	1 1 0
$ B - A < 10\text{mV}$	X 0 1
	0 X 1
	1 1 ?
$B - A \leq -10\text{mV}$	X X 1

0: LOW LEVEL
1: HIGH LEVEL
X: DON'T CARE



TC4020BP (TOSHIBA)

C-MOS 14-STAGE RIPPLE-CARRY BINARY COUNTER/DRIVER
— TOP VIEW —



SN75452BP (TI)


TTL PERIPHERAL POSITIVE-NAND DRIVER
WITH OPEN-COLLECTOR
— TOP VIEW —



A	B	X
L	L	H
L	H	H
H	L	H
H	H	L


TA7060AP (TOSHIBA)

LINEAR AMP
— SIDE VIEW —




SEMICONDUCTOR ELECTRODES

TC4021BP (TOSHIBA)
C-MOS ASYNCHRONOUS PARALLEL/SYNCHRONOUS SERIAL INPUT 8-BIT STATIC SHIFT REGISTER
— TOP VIEW —




INPUT				INTERNAL OUTPUTS							
P/S CONT	T	P	DS	Q1	Q2	Q3	Q4	Q5	Q6	Q7	Q8
1	X	P1 ~ P8	X	P1	P2	P3	P4	P5	P6	P7	P8
0	F	X	1	1	Q1n	Q2n	Q3n	Q4n	Q5n	Q6n	Q7n
0	F	X	0	0	Q1n	Q2n	Q3n	Q4n	Q5n	Q6n	Q7n
X	0	X	X	Q1n	Q2n	Q3n	Q4n	Q5n	Q6n	Q7n	Q8n

In: BEFORE CLOCK
In + 1: AFTER CLOCK




TC4030BP (TOSHIBA)
C-MOS EXCLUSIVE OR GATE
— TOP VIEW —



$A \oplus B = X$
 $X = A \oplus B + A \oplus B$

A	B	X
0	0	0
0	1	1
1	0	1
1	1	0


TC4050BP (TOSHIBA)
C-MOS NON-INVERTING TYPE BUFFER/CONVERTER
— TOP VIEW —



$X = A$

A	X
0	0
1	1


TC4066BP (TOSHIBA)
C-MOS BILATERAL ANALOG SWITCH
— TOP VIEW —



CONTROL SWITCH


CONTROL	SWITCH
0	OFF
1	ON

TC4024BP (TOSHIBA)
C-MOS ASYNCHRONOUS 7-BIT BINARY COUNTER
— TOP VIEW —




COUNT	INPUTS		OUTPUTS							
	T	R0	Q7	Q6	Q5	Q4	Q3	Q2	Q1	
0	X	1	0	0	0	0	0	0	0	
1	1	0	0	0	0	0	0	0	1	
2	1	0	0	0	0	0	0	1	0	
3	1	0	0	0	0	0	0	1	1	
4	1	0	0	0	0	1	0	0	0	
125	1	0	1	1	1	1	1	0	1	
126	1	0	1	1	1	1	1	1	0	
127	1	0	1	1	1	1	1	1	1	
—	0	0	NO CHANGE							
—	1	0	NO CHANGE							

0: LOW
1: HIGH
X: DON'T CARE




TC4071BP (TOSHIBA)
C-MOS 2-INPUT OR GATE
— TOP VIEW —



$A \vee B = X$
 $X = A \vee B + A \vee B$

A	B	X
0	0	0
0	1	1
1	0	1
1	1	1


TC4073BP (TOSHIBA)
C-MOS 3-INPUT POSITIVE AND GATE
— TOP VIEW —



$A \vee B \vee C = Y$
 $Y = A \vee B \vee C + A \vee B \vee C$

A	B	C	Y
0	0	0	0
0	0	1	1
0	1	0	1
0	1	1	1
1	0	0	1
1	0	1	1
1	1	0	1
1	1	1	1

TC4075BP (TOSHIBA)
C-MOS 3-INPUT OR GATE
— TOP VIEW —





$A \vee B \vee C = Y$
 $Y = A \vee B \vee C + A \vee B \vee C$


A	B	C	Y
0	0	0	0
0	0	1	1
0	1	0	1
0	1	1	1
1	0	0	1
1	0	1	1
1	1	0	1
1	1	1	1

SEMICONDUCTOR ELECTRODES

TC4093BP (TOSHIBA)
C-MOS 2-INPUT NAND SCHMITT TRIGGER
— TOP VIEW —




TC40H042P (TOSHIBA)
C-MOS BCD-TO-DECIMAL DECODER/DRIVER
— TOP VIEW —




STATE	A	B	C	D	0	1	2	3	4	5	6	7	8	9
0	0	0	0	0	1	1	1	1	1	1	1	1	1	1
1	1	0	0	0	1	0	1	1	1	1	1	1	1	1
2	0	1	0	0	1	0	1	1	1	1	1	1	1	1
3	1	1	0	0	1	1	0	1	1	1	1	1	1	1
4	0	0	1	0	1	1	1	0	1	1	1	1	1	1
5	1	0	1	0	1	1	1	1	0	1	1	1	1	1
6	0	1	1	0	1	1	1	1	1	0	1	1	1	1
7	1	1	1	0	1	1	1	1	1	1	0	1	1	1
8	0	0	0	1	1	1	1	1	1	1	1	0	1	1
9	1	0	0	1	1	1	1	1	1	1	1	1	0	1
10	X	1	X	1	1	1	1	1	1	1	1	1	1	1
15	X	X	1	1	1	1	1	1	1	1	1	1	1	1

X: DON'T CARE
1: HIGH LEVEL
0: LOW LEVEL


TC40H004P (TOSHIBA)
C-MOS INVERTER
— TOP VIEW —



TC40H011P (TOSHIBA)
C-MOS 3-INPUT POSITIVE-AND GATE
— TOP VIEW —




TC40H138P (TOSHIBA)
C-MOS 3-TO-8-LINE DECODER/DEMULPLEXER
— TOP VIEW —




INPUTS	EN	C	B	A	Y7	Y6	Y5	Y4	Y3	Y2	Y1	Y0
0	X	X	X	1	1	1	1	1	1	1	1	1
1	0	0	0	1	1	1	1	1	1	1	0	1
1	0	0	1	1	1	1	1	1	1	0	1	1
1	0	1	0	1	1	1	1	1	0	1	1	1
1	0	1	1	1	1	1	1	0	1	1	1	1
1	1	0	0	1	1	1	0	1	1	1	1	1
1	1	0	1	1	1	0	1	1	1	1	1	1
1	1	1	0	1	1	1	1	1	1	1	1	1

EN = EN1 · EN2 · EN3
0: LOW LEVEL
1: HIGH LEVEL
X: DON'T CARE


TC40H032P (TOSHIBA)
C-MOS 2-INPUT POSITIVE-OR GATE
— TOP VIEW —




TC40H074P (TOSHIBA)
C-MOS HIGH SPEED D-TYPE FLIP-FLOP WITH DIRECT SET/RESET
— TOP VIEW —




TC40H139P (TOSHIBA)
C-MOS 2-TO-4-LINE DECODER/DEMULPLEXER
— TOP VIEW —




TC40H240P (TOSHIBA)
C-MOS 3-STATE INVERTER/LINE DRIVER
— TOP VIEW —





TC40H244P (TOSHIBA)
C-MOS 3-STATE BUFFER/DRIVER
— TOP VIEW —




TC40H245P (TOSHIBA)
C-MOS BILATERAL BUS TRANSCEIVERS WITH 3-STATE OUTPUT
— TOP VIEW —




TC40H273P (TOSHIBA)
C-MOS D-TYPE FLIP-FLOP WITH DIRECT RESET
— TOP VIEW —



TC40H368P (TOSHIBA)
C-MOS INVERTING 3-STATE BUFFER
— TOP VIEW —



TC4516BP (TOSHIBA)
C-MOS PRESETTABLE BINARY UP/DOWN COUNTER
— TOP VIEW —





COUNT					OUTPUTS			
QD	QC	QB	QA		QD	QC	QB	QA
0	0	0	0	0	0	0	0	0
1	0	0	0	1	0	0	0	1
2	0	0	1	0	0	0	1	0
3	0	0	1	1	0	0	1	1
4	0	1	0	0	0	1	0	0
5	0	1	0	1	0	1	0	1
6	0	1	1	0	0	1	1	0
7	0	1	1	1	0	1	1	1
8	1	0	0	0	1	0	0	0
9	1	0	0	1	1	0	0	1
10	1	0	1	0	1	0	1	0
11	1	0	1	1	1	0	1	1
12	1	1	0	0	1	1	0	0
13	1	1	0	1	1	1	0	1
14	1	1	1	0	1	1	1	0
15	1	1	1	1	1	1	1	1

CO=L
CI=L B(DOWN·COUNT "0" OR UP·COUNT "15")


17. **התאחדות העובדים**

DATE: 08-09-67 TIME: 14:00



$$\begin{aligned} \text{Sulfuric acid} &+ \text{Sulfur dioxide} \rightarrow \text{Sulfur trioxide} \\ \text{H}_2\text{SO}_4 + \text{SO}_2 &\rightarrow \text{H}_2\text{S}_2\text{O}_7 \\ \text{H}_2\text{SO}_4 + \text{SO}_2 &\rightarrow \text{H}_2\text{S}_2\text{O}_7 \end{aligned}$$


INPUTS										OUTPUTS			
EN	D7	D6	D5	D4	D3	D2	D1	D0	GS	Q2	Q1	Q0	EO
0	X	X	X	X	X	X	X	X	0	0	0	0	0
1	0	0	0	0	0	0	0	0	0	0	0	0	1
1	0	1	X	X	X	X	X	X	1	1	1	0	0
1	0	1	0	1	X	X	X	X	1	1	1	0	0
1	0	0	1	X	X	X	X	X	1	0	1	0	0
1	0	0	0	1	X	X	X	X	1	1	0	0	0
1	0	0	0	0	1	X	X	X	1	0	1	1	0
1	0	0	0	0	0	1	X	X	1	0	1	0	0
1	0	0	0	0	0	0	1	X	1	0	0	1	0
1	0	0	0	0	0	0	0	1	1	0	0	0	0

TYPE

[illegible]

1. 1992年1月1日起，凡在境内销售货物或提供应税劳务的纳税人，均应按销售额和规定的税率计算应纳税额，并不得抵扣任何税额。



0: LOW LEVEL
1: HIGH LEVEL
X: DON'T CARE

* * = ABOVE COMBINATIONS.



10-11-1964






Figure 1. The effect of the concentration of the *Agrobacterium* suspension on the transformation efficiency of *Agrobacterium* strains. The concentration of the *Agrobacterium* suspension was 10⁶ cells/ml (a), 10⁷ cells/ml (b), 10⁸ cells/ml (c), and 10⁹ cells/ml (d). The concentration of the *Agrobacterium* suspension was 10⁶ cells/ml (a), 10⁷ cells/ml (b), 10⁸ cells/ml (c), and 10⁹ cells/ml (d). The concentration of the *Agrobacterium* suspension was 10⁶ cells/ml (a), 10⁷ cells/ml (b), 10⁸ cells/ml (c), and 10⁹ cells/ml (d).




0; LOW LEVEL			
1; HIGH LEVEL	1	1	
X; DON'T CARE			

SEMICONDUCTOR ELECTRODES


TL8605P (TOSHIBA)
CCD ANALOG PROCESSING UNIT
— TOP VIEW —




μA760HC(FSC)
HIGH SPEED VOLTAGE COMPARATOR
— TOP VIEW —




μPC143□□H (NEC)
μPC78□□H (NEC)
POSITIVE VOLTAGE REGULATOR (1A)




μPC 319C (NEC)
DUAL VOLTAGE COMPARATOR
— TOP VIEW —




μPC4557C (NEC)
OPERATIONAL AMPLIFIER
(WIDE BAND, LOW NOISE)
— TOP VIEW —




μA796HC (FSC)
DOUBLE-BALANCED MOD/DEMOD
— BOTTOM VIEW —




μPC324C (NEC)
QUAD. OP. AMPLIFIER
— TOP VIEW —



μPC339C (NEC)
COMPARATOR
— TOP VIEW —




μPC78L□□A (NEC)
POSITIVE VOLTAGE REGULATOR (100mA)




2.6V
5V μPC78L05(A)
6.2V
8V μPC78L08
8.2V
9V
10V
12V μPC78L12
15V μPC78L15
18V
24V

SEMICONDUCTOR ELECTRODES

μPC7900H (NEC)
NEGATIVE VOLTAGE REGULATOR (1A)




-5V	μPC7905H
-6V	
-8V	μPC7908H
-12V	μPC7912H
-15V	μPC7915H
-18V	μPC7918H
-24V	μPC7924H




μPD4519BC (NEC)
C-MOS 4-BIT AND/OR SELECTOR
2-CHANNEL DATA SELECTOR
EXCLUSIVE "NOR" GATE

—TOP VIEW—





CONTROL		OUTPUT
A	B	Z
0	0	GND
0	1	Y
1	0	X
1	1	 Z




μPD5101LC-1 (NEC)
C-MOS 1024-BIT(256X4) STATIC RAM

—TOP VIEW—





INPUTS				OUTPUTS	FUNCTION
CE1	CE2	OD	WR	D0	
1	X	X	X	HIGH Z	NOT SELECTED
X	0	X	X	HIGH Z	NOT SELECTED
X	X	1	1	HIGH Z	OUTPUT DISABLE
0	1	1	0	HIGH Z	WRITE
0	1	0	0	D1	WRITE
0	1	0	1	DENTERED	READ

HIGH Z; HIGH IMPEDANCE




μPD4584BC (NEC)
C-MOS SCHMITT TRIGGER INVERTER



—TOP VIEW—




SEMICONDUCTOR ELECTRODES



SEMICONDUCTOR ELECTRONICS




SECTION 18
PRINTED WIRING BOARD AND SCHEMATIC DIAGRAM



102 WIRING BOARD
102 WIRING BOARD
102 WIRING BOARD
102 WIRING BOARD
102 WIRING BOARD

PB-8 (PB RF PREAMPLIFIER)


PRINTED CIRCUIT BOARD AND SCHEMATIC DIAGRAM




PB-8-SOLDERING SIDE -

1-608-263-12,13
BVW - 10
BVW - 10P

PB-8 (PB RF PREAMPLIFIER)





YD-15 (LUMINANCE SIGNAL DEMODULATOR)



CN1	F - 3	Q1	C - 6
CN2	G - 4	Q2	C - 6
		Q3	C - 6
D1	B - 1	Q4	C - 3
D2	A - 1	Q5	C - 3
D3	A - 3	Q6	A - 2
D4	B - 7	Q7	C - 1
D5	E - 2	Q8	C - 2
D6	F - 3	Q10	G - 5
D7	F - 3	Q11	A - 6
		Q12	B - 6
DL1	E - 2	Q13	E - 1
DL2	E - 3	Q14	F - 4
		Q15	B - 7
E1	C - 1	Q16	E - 1
E2	G - 7	Q18	E - 2
E3	G - 2	Q20	G - 3
		Q21	G - 3
FL1	F - 3	Q22	G - 4
		Q23	G - 4
IC1	B - 4	Q24	F - 4
IC2	D - 2	Q25	E - 3
IC3	E - 3	Q26	B - 3
IC4	A - 2		
IC5	F - 3	RV1	B - 5
IC7	G - 1	RV2	C - 4
IC8	E - 5	RV3	C - 2
IC9	F - 6	RV4	C - 2
IC10	G - 6	RV5	D - 1
IC11	E - 5	RV6	B - 2
IC12	F - 7	RV11	A - 5
		RV12	C - 5
LV1	C - 5	RV20	G - 3
LV2	C - 4	RV71	F - 1
LV11	B - 5	RV72	E - 5
LV12	C - 5	RV73	F - 6
		RV74	G - 6
		RV75	E - 4
		RV76	G - 4
		RV77	G - 4
		TP1	C - 1
		TP2	B - 1
		TP3	C - 1
		TP4	D - 1
		TP6	F - 5
		TP7	E - 6
		TP8	C - 2
		TP9	C - 1
		TP11	G - 2

YD-15 (LUMINANCE SIGNAL DEMODULATOR)







YD-15


1-608-583-12, 13
BVW-10P

D-25 (CHROMINANCE SIGNAL DEMODULATOR)






CD-25 (CHROMINANCE SIGNAL DEMODULATOR)




CN1	F-3	Q1	C-6
CN2	G-4	Q2	C-6
		Q3	C-3
D1	B-1	Q4	C-3
D2	A-1	Q5	C-3
D3	A-3	Q6	A-2
D4	B-7	Q7	C-1
D6	F-3	Q8	C-2
D7	F-3	Q10	G-5
		Q11	A-6
DL1	E-2	Q12	B-6
		Q13	E-6
E1	C-1	Q14	F-4
E2	G-7	Q15	B-7
E3	G-2	Q16	E-1
		Q20	G-3
FL1	F-3	Q21	G-3
		Q22	G-4
		Q25	E-3
IC1	B-4	RV1	B-5
IC2	D-2	RV2	C-4
IC3	E-3	RV3	C-2
IC4	A-2	RV4	C-2
IC5	F-3	RV5	D-1
IC6	D-4	RV6	B-2
IC7	G-1	RV7	D-4
IC8	E-5	RV11	A-5
IC9	F-6	RV12	C-5
IC10	G-6	RV70	G-3
IC11	E-5	RV71	F-1
IC12	F-7	RV72	E-5
		RV73	F-6
LV1	C-5	RV74	G-6
LV2	C-4	RV75	E-4
LV11	B-5	RV76	G-4
LV12	C-5		
		TP1	C-1
		TP2	B-1
		TP3	C-1
		TP4	D-1
		TP6	F-5
		TP7	E-6
		TP8	C-2
		TP9	C-1
		TP11	G-2

CF-12 (CHROMINANCE SIGNAL COMB FILTER)
DU-431A ~ 30A ---- COMPONENT SIDE
1B ~ 30B ---- SOLDERING SIDECF-12 - SOLDERING SIDE -
1-607-978-12
BVW-10P

D1 F-6
D2 G-2
D3 A-5
D105 E-3
E1 A-1
E2 F-2
E3 D-7
E4 G-7
IC1 G-6
IC2 G-4
IC3 F-7
IC4 C-6
LV1 E-5
Q1 G-5
Q2 G-3
Q3 G-3
Q4 G-2
Q5 E-6
Q6 E-6
Q7 E-6
Q8 E-6
Q9 D-6
Q10 E-5
Q11 E-5
Q12 D-4
Q13 E-4
Q14 E-4
Q15 G-2
Q16 F-2
Q17 F-3
Q18 E-3
Q19 D-3
Q20 D-4
Q21 D-3
Q23 C-3
Q25 C-4
Q27 C-4
Q28 C-5
Q29 C-5
Q30 C-5
Q31 B-6
Q32 B-6
Q33 B-3
Q35 B-4
Q37 B-4
Q38 B-5
Q39 B-5
Q40 B-5

Q41 D-1
Q42 D-1
Q43 E-1
Q44 E-1
Q45 E-1
Q46 E-2
Q47 B-1
Q48 B-1
Q49 C-1
Q50 B-2
Q51 B-2
Q52 C-2
Q53 C-6
Q54 G-6
Q55 G-4
Q56 D-6
RV1 G-3
RV2 F-2
RV3 C-3
RV4 C-6
RV5 B-3
RV6 C-6
RV7 C-5
RV8 C-2
RV9 A-2
RV12 G-6
RV13 G-4
RV14 C-6
RV121 A-5
RV122 A-5
TP1 D-5
TP2 E-4
TP3 E-3
TP4 D-3
TP5 C-5
TP6 C-5
TP7 B-6
TP8 A-7
TP9 B-5
TP10 B-5
TP11 D-1
TP12 E-1
TP13 B-1
TP14 B-1
TP15 G-5
X1 G-5



HROMINANCE SIGNAL COMB FILTER)

Q5 2SC403C Q6 2SA1026 Q7 2SC403C Q8 2SA1026 Q9 2SC403C

Q11 2SA1026 Q10 2SC403C

Q13 2SA1026 Q12 2SC403C


Q14 2SC403C

Q54 2SA1026

IC1 TL6605P


Q1 2SC403C


Q55 2SA1026







Ref. No.	Type	Pin No.				
		-11V	-5V	GND	+5V	+11V
IC1	SN74LS74AAN			7	14	
IC1B	SN74LS82AN			8	16	
IC1C	SN74LS74AAN			7	14	
IC1D	SN74LS00N			7	14	
IC1E	SN74LS151N			7	14	
IC1F	HAT-4805-5	5	7	8	1	13
IC1GA	TLM01CIP	5	5	1	1	8
IC1GB	TLM01CIP	5	5	1	1	8
IC1HA	TLM01CIP	5	5	1	1	8
IC1HB	TLM01CIP	5	5	1	1	8
IC1J	SN74LS123AN			7	14	
IC1K	SN7400N			7	14	
IC1L	PC3198C	6	3,8	14	11	
IC1M	SN74LS74AAN			7	14	
IC1N	SN74LS00N			7	14	
IC1NA	SN74LS11N			7	14	
IC1P	HAT-4805-5	5	7	8	1	13
IC1RA	TLM01CIP	5	5	1	1	8
IC1RB	TLM01CIP	5	5	1	1	8
IC1SA	TLM01CIP	5	5	1	1	8
IC1SB	TLM01CIP	5	5	1	1	8
IC1T	CTX73A			12	24	
IC1U	HD1012S	8	16	7	14	
IC1V	SN74LS00N			7	14	
IC1X	CTX703			7	2	
IC1Y	PC3198C	6	3,8	14	11	
IC2A	HD1012A	8	16	9		
IC2B	SN74LS221N			8	16	2
IC2C	SN74LS163AN			8	16	
IC2D	SN74LS163AN			8	16	
IC2E	SN74LS112AAN			8	16	
IC2G	TLM082C					8
IC2H	TLM084CN	11				8
IC2I	HD1012A	8	16	9		
IC2K	SN74LS221N			8	16	
IC2L	SN74LS163AN			8	16	
IC2M	SN74LS163AN			8	16	
IC2N	SN74LS112AAN			8	16	
IC2R	TLM082C	4				8
IC2S	TLM084CN	11				8
IC2T	SN74LS85AN			8	16	
IC2U	SN7404N			8	14	
IC2V	SN75007BN	13	7	7	14	
IC2W	SN7400N			7	14	
IC3A	HD1018BL	8	1,16			
IC3B	SN74LS163AN			7	14	
IC3C	SN7400N			7	16	
IC3D	SN74LS164N			7	14	
IC3E	SN74LS08N			7	14	
IC3F	HIT-201-5	4	5	13		
IC3G	EX381	9	6	6		
IC3H	HIT-201-5	4	5	13		
IC3I	HD1018BL	8	1,16			
IC3J	SN74LS163AN			7	14	
IC3K	SN7400N			7	14	
IC3L	SN74LS164N			7	14	
IC3M	SN74LS08N			7	14	
IC3P	HIT-201-5	4	5	13		
IC3R	EX381	9	6	6		
IC3S	HIT-201-5	4	5	13		
IC3T	SN74LS164N			7	14	
IC3U	SN74LS164N			7	14	
IC3V	SN74LS221N			8	16	
IC3W	SN74205N			8	16	
IC3X	EX381	9	6	6	2	
IC4A	MC1018BL	8	1,16			
IC4B	SN74LS163AN			8	16	
IC4C	SN74LS164N			7	14	
IC4D	SN74LS112AN			7	14	
IC4E	SN74LS04N			7	14	
IC4F	PC45C57C					8
IC4G	NAM6600C					8
IC4H	SN75207BN	13	7	7	14	
IC4I	MC1018BL	8	1,16			
IC4J	SN74LS163N			8	16	
IC4L	SN74LS74AAN			7	14	
IC4M	SN74LS123AN			7	14	
IC4N	SN74LS04N			7	14	
IC4P	PC45C57C	4				8
IC4Q	NAM6600C					8
IC4R	SN75207BN	13	7	7	14	
IC4T	SN74LS164N			7	14	
IC4U	SN74LS00N			7	14	
IC4V	SN7404N			7	14	
IC4W	SN74LS163AN			8	16	
IC5A	SN74LS164N			7	14	
IC5A2	HD1012S	8	16	9		
IC5B	SN74LS191N			8	16	
IC5C	SN74LS174N			8	16	
IC5D	SN74S551N			7	14	
IC5E	SN74LS221N			8	16	
IC5F	SN74LS221N			8	16	
IC5G	SN754528P			4	8	
IC5H	PC3198C	6	3,8	14	11	
IC5J	HD1012S	8	16	9		
IC5K	SN74191N			8	16	
IC5L	SN74LS174N			8	16	
IC5M	SN74S551N			7	14	
IC5N	SN74LS221N			8	16	
IC5O	SN74LS221N			8	16	
IC5R	SN754528P			4	8	
IC5S	PC3198C	6	3,8	14	11	
IC5T	SN74LS164N			7	14	
IC5U	SN74S551N			7	14	
IC5V	SN74LS221N			8	16	
IC5W	SN74LS163AN			8	16	
IC5X	SN74LS163N			8	16	
IC5Z	SN74LS221N			8	16	







D1	H-2	TP1	A-1
D2	H-2	TP2	G-2
D3	A-2	TP3	H-2
D4	A-2	TP4	B-3
D5	A-2	TP5	C-3
D7	E-3	TP6	F-3
D8	E-3	TP7	G-3
D9	G-5	TP8	C-4
D10	J-1	TP9	E-5
D11	J-1	TP10	F-5
D12	K-1	TP11	F-5
D13	S-2	TP12	R-2
D14	S-2	TP13	S-2
D15	J-2	TP14	K-3
D16	J-2	TP15	L-3
D17	J-3	TP16	P-3
D19	N-3	TP17	S-3
D20	N-3	TP18	I-4
D21	R-3	TP19	K-4
D22	R-5	TP20	K-5
D23	X-1	TP21	M-5
D24	V-2	TP22	P-5
D25	X-2	TP23	S-1
D26	Y-2	TP24	T-1
D27	Y-3	TP25	Y-1
D28	Y-3	TP27	Y-1
D29	Y-4	TP29	W-3
D30	W-4	TP30	U-4
D33	G-3	TP31	V-4
D50	V-3	TP32	Y-4
		TP33	T-5
		TP34	T-5
		TP35	U-5
		TP36	W-1
		TP37	M-1
		TP38	N-2
IC1	T-3	TPE1	F-1
Q1	G-4	TPE2	B-5
Q2	R-4	TPE3	N-2
Q3	X-2	TPE4	R-5
Q4	Y-2	TPE5	X-5
Q5	Y-2	TPE6	Y-4
Q6	Y-2		
Q7	Y-3		
Q8	Y-3		
Q9	Y-4		
RV1	E-4		
RV2	G-4		
RV3	H-4		
RV5	P-2		
RV6	R-4		
RV7	N-4		
RV8	V-3		
RV9	X-1		
RV12	W-4		
RV13	Z-4		
RV14	T-5		
RV20	V-3		













D1	H-2	TP1	A-1
D2	H-2	TP2	G-2
D3	A-2	TP3	H-2
D4	A-2	TP4	B-3
D5	A-2	TP5	C-3
D7	E-3	TP6	F-3
D8	E-3	TP7	G-3
D9	G-5	TP8	C-4
D10	J-1	TP9	E-5
D11	J-1	TP10	F-5
D12	K-1	TP11	F-5
D13	S-2	TP12	R-2
D14	S-2	TP13	S-2
D15	J-2	TP14	K-3
D16	J-2	TP15	S-3
D17	J-3	TP16	P-3
D19	N-3	TP17	S-3
D20	N-3	TP18	I-4
D21	R-3	TP19	K-4
D22	R-5	TP20	K-5
D23	X-1	TP21	M-5
D24	V-2	TP22	P-5
D25	X-2	TP23	S-1
D26	Y-2	TP24	T-1
D27	Y-3	TP25	V-1
D28	Y-3	TP26	W-1
D29	Y-4	TP27	Y-1
D30	W-4	TP28	W-3
D33	G-3	TP29	U-4
D50	V-3	TP30	V-4
		TP31	Y-4
		TP32	T-5
		TP33	T-5
		TP34	T-5
		TP35	U-5
		TP36	W-1
		TP37	M-1
		TP38	N-2
IC1	T-3	TPE1	F-1
Q1	G-4	TPE2	B-5
Q2	R-4	TPE3	N-2
Q3	X-2	TPE4	R-5
Q4	Y-2	TPE5	X-5
Q5	V-2	TPE6	Y-4
Q6	Y-2		
Q7	Y-3		
Q8	Y-3		
Q9	Y-4		
RV1	E-4		
RV2	G-4		
RV3	H-4		
RV5	P-2		
RV6	R-4		
RV7	N-4		
RV8	V-3		
RV9	X-1		
RV12	W-4		
RV13	Z-4		
RV14	T-5		
RV20	V-3		






Ref. No.	Type	Pin No.				
		-11V	-5V	0V	+5V	+11V
IC 1	SN74LS74AN	7	14			
IC 1B	SN74LS223N	8	16			
IC 1C	SN74LS74AN	7	14			
IC 1D	SN74LS00N	7	14			
IC 1E	SN74LS11N	7	14			
IC 1F	HA1-4905-5	5	5	1	13	8
IC 1GA	TL061CP	1	1	1	8	8
IC 1GB	TL061CP	5	5	1	8	8
IC 1HA	TL061CP	1	1	1	8	8
IC 1HB	TL061CP	5	5	1	8	8
IC 1I	SN74LS123N	8	16			
IC 1J	SN7400N	7	14			
IC 1K	PC319C	6	3,8	11		
IC 1L	SN74LS74AN	7	14			
IC 1M	SN74LS00N	7	14			
IC 1N	SN74LS11N	7	14			
IC 1P	HA1-4905-5	5	5	1	13	8
IC 1RA	TL061CP	1	1	1	8	8
IC 1RB	TL061CP	5	5	1	8	8
IC 1SA	TL061CP	1	1	1	8	8
IC 1SB	TL061CP	5	5	1	8	8
IC 1T	HD10125	8	16	9	24	
IC 1U	HD10125	8	16	9	24	
IC 1V	SN74LS00N	7	14			
IC 1X	CA7963	6	3,8	11		
IC 1Y	PC319C	6	3,8	11		
IC 2A	HD10124	8	16	9	24	
IC 2B	SN74LS221N	8	16	9	24	
IC 2C	SN74LS163AN	8	16	9	24	
IC 2D	SN74LS221N	8	16	9	24	
IC 2E	SN74LS112AN	8	16	9	24	
IC 2G	TL082CP	4	11	8	4	
IC 2H	TL082CP	4	11	8	4	
IC 2J	HD10124	8	16	9	24	
IC 2K	SN74LS221N	8	16	9	24	
IC 2L	SN74LS163AN	8	16	9	24	
IC 2M	SN74LS221N	8	16	9	24	
IC 2N	SN74LS112AN	8	16	9	24	
IC 2R	TL082CP	4	11	8	4	
IC 2S	TL082CP	4	11	8	4	
IC 2T	SN74365AN	7	14			
IC 2U	SN7400N	7	14			
IC 2V	SN75207BN	13	7	14		
IC 2W	SN7400N	7	14			
IC 3A	HD10198L	8	1,16	16		
IC 3B	SN74LS163AN	8	1,16	16		
IC 3C	SN7400N	7	14			
IC 3D	SN74LS164N	7	14			
IC 3E	SN74LS00N	7	14			
IC 3F	HI1-201-5	4	5	13	2	
IC 3G	BX381	4	5	13	2	
IC 3H	HI1-201-5	4	5	13	2	
IC 3I	HD10198L	8	1,16	16		
IC 3K	SN74LS163AN	8	1,16	16		
IC 3L	SN7400N	7	14			
IC 3M	SN74LS164N	7	14			
IC 3N	SN74LS00N	7	14			
IC 3P	HI1-201-5	4	5	13	2	
IC 3R	BX381	4	5	13	2	
IC 3S	HI1-201-5	4	5	13	2	
IC 3T	SN74LS164N	7	14			
IC 3U	SN74LS164N	7	14			
IC 3V	SN74LS221N	8	16	9	24	
IC 3W	SN74LS221N	8	16	9	24	
IC 3X	SN74LS221N	8	16	9	24	
IC 3Y	SN74LS221N	8	16	9	24	
IC 3Z	SN74LS221N	8	16	9	24	
IC 4A	MC10198L	8	1,16	16		
IC 4B	SN74LS163AN	8	1,16	16		
IC 4C	SN74LS74AN	7	14			
IC 4D	SN74LS123N	8	16	9	24	
IC 4E	SN74LS00N	7	14			
IC 4F	PC4557C	4	5	13	2	
IC 4G	NJM4560D	4	5	13	2	
IC 4H	SN75207BN	13	7	14		
IC 4I	MC10198L	8	1,16	16		
IC 4J	SN74LS163N	8	1,16	16		
IC 4K	SN74LS163N	8	1,16	16		
IC 4L	SN74LS74AN	7	14			
IC 4M	SN74LS123N	8	16	9	24	
IC 4N	SN74LS00N	7	14			
IC 4P	PC4557C	4	5	13	2	
IC 4R	NJM4560D	4	5	13	2	
IC 4S	SN75207BN	13	7	14		
IC 4T	SN74LS164N	7	14			
IC 4U	SN74LS00N	7	14			
IC 4V	SN7400N	7	14			
IC 4W	SN74LS163AN	8	1,16	16		
IC 4Z	SN74LS164N	7	14			
IC 5A	HD10125	8	16	9	24	
IC 5B	SN74LS174N	8	16	9	24	
IC 5C	SN74LS51N	8	16	9	24	
IC 5D	SN74LS51N	8	16	9	24	
IC 5E	SN74LS221N	8	16	9	24	
IC 5F	SN74LS221N	8	16	9	24	
IC 5G	SN754528P	6	3,8	11		
IC 5H	PC319C	6	3,8	11		
IC 5I	HD10125	8	16	9	24	
IC 5K	SN74LS174N	8	16	9	24	
IC 5L	SN74LS51N	8	16	9	24	
IC 5M	SN74LS51N	8	16	9	24	
IC 5N	SN74LS221N	8	16	9	24	
IC 5P	SN74LS221N	8	16	9	24	
IC 5R	SN754528P	6	3,8	11		
IC 5S	PC319C	6	3,8	11		
IC 5T	SN74LS164N	7	14			
IC 5U	SN74LS51N	8	16	9	24	
IC 5V	SN74LS221N	8	16	9	24	
IC 5W	SN74LS163AN	8	1,16	16		
IC 5X	SN74LS163N	8	1,16	16		
IC 5Z	SN74LS221N	8	16	9	24	






D1	H-2	TP1	A-1
D2	H-2	TP2	G-2
D3	A-2	TP3	H-2
D4	A-2	TP4	B-3
D5	A-2	TP5	C-3
D6	E-3	TP6	F-3
D7	E-3	TP7	G-3
D8	E-3	TP8	C-4
D9	G-5	TP9	E-5
D10	J-1	TP10	F-5
D11	J-1	TP11	F-5
D12	K-1	TP12	R-2
D13	S-2	TP13	S-2
D14	S-2	TP14	K-3
D15	J-2	TP15	L-3
D16	J-2	TP16	P-3
D17	J-3	TP17	S-3
D18	N-3	TP18	I-4
D19	N-3	TP19	K-4
D20	N-3	TP20	K-5
D21	R-5	TP21	M-5
D22	X-1	TP22	P-5
D23	X-1	TP23	S-1
D24	V-2	TP24	T-1
D25	X-2	TP25	Y-1
D26	Y-2	TP26	Y-1
D27	Y-2	TP27	Y-1
D28	Y-3	TP28	W-3
D29	Y-4	TP29	W-3
D30	W-4	TP30	U-4
D31	G-3	TP31	V-4
D32	G-3	TP32	Y-4
D33	G-3	TP33	T-5
D34	V-3	TP34	T-5
D35	V-3	TP35	U-5
IC1	T-3	TP36	W-1
Q1	G-4	TP37	M-1
Q2	R-4	TP38	N-2
Q3	X-2		
Q4	Y-2	TP1	F-1
Q5	Y-2	TP2	B-5
Q6	Y-2	TP3	N-2
Q7	Y-3	TP4	R-5
Q8	Y-3	TP5	X-5
Q9	Y-4	TP6	Y-4
RV1	E-4		
RV2	G-4		
RV3	H-4		
RV4	P-2		
RV5	R-4		
RV6	N-4		
RV7	V-3		
RV8	X-1		
RV9	W-4		
RV10	Z-4		
RV11	T-5		
RV12	V-3		

K-14 (3/3) (VIDEO TBC)



CK-14(3/3)
BW-10P





CK-14(3/3)
BVW-10P

MY-17 (VIDEO TBC)

Ref. No.	Type	Pin No.	
		GND	+5V
IC 1A	SN74LS164N	7	14
IC 1B	SN74LS164N	7	14
IC 1C	SN74LS164N	7	14
IC 1D	SN74LS166AN	8	16
IC 1E	SN74LS374N	10	20
IC 1F	SN74LS164N	7	14
IC 1G	SN74LS166AN	8	16
IC 1H	SN74LS161AN	8	16
IC 1J	SN74LS161AN	8	16
IC 1M	SN7400N	7	14
IC 2A	SN74LS374N	10	20
IC 2B	SN74LS374N	10	20
IC 2C	SN74LS164N	7	14
IC 2D	MSM5128-12RS	12	24
IC 2E	SN74LS164N	7	14
IC 2F	SN74LS166AN	8	16
IC 2G	MSM5128-12RS	12	24
IC 2H	SN74LS157N	8	16
IC 2J	SN74LS161AN	8	16
IC 2K	SN74LS161AN	8	16
IC 2L	SN74LS221N	8	16
IC 2M	SN74LS164N	7	14
IC 2N	SN74LS164N	7	14
IC 3A	SN74LS166AN	8	16
IC 3B	SN74LS166AN	8	16
IC 3C	SN74LS164N	7	14
IC 3E	SN74LS164N	7	14
IC 3F	SN74LS374N	10	20
IC 3H	SN74LS157N	8	16
IC 3J	SN74LS175N	8	16
IC 3K	SN74LS175N	8	16
IC 3L	SN74LS161AN	8	16
IC 3M	SN74LS74AN	7	14
IC 3N	SN74LS74AN	7	14
IC 4A	SN74LS166AN	8	16
IC 4B	SN74LS166AN	8	16
IC 4C	MSM5128-12RS	12	24
IC 4E	SN74LS374N	10	20
IC 4F	SN74LS166AN	8	16
IC 4G	MSM5128-12RS	12	24
IC 4H	SN74LS157N	8	16
IC 4J	SN74LS175N	8	16
IC 4K	SN74LS163AN	8	16
IC 4L	SN74LS151N	8	16
IC 4M	SN74LS30N	7	14
IC 4N	SN74LS74AN	7	14
IC 5A	SN74LS166AN	8	16
IC 5B	SN74LS166AN	8	16
IC 5C	SN74LS374N	10	20
IC 5D	MSM5128-12RS	12	24
IC 5E	SN74LS164N	7	14
IC 5G	MSM5128-12RS	12	24
IC 5H	SN74LS157N	8	16
IC 5J	SN74LS163AN	8	16
IC 5K	SN74LS85N	8	16
IC 5L	SN74LS393N	7	14
IC 5M	SN74LS04N	7	14
IC 5N	SN74LS04N	7	14
IC 6A	SN74LS166AN	8	16
IC 6B	SN74LS166AN	8	16
IC 6C	SN74LS164N	7	14
IC 6E	SN74LS164N	7	14
IC 6F	SN74LS164N	7	14
IC 6H	SN74LS161AN	8	16
IC 6J	SN74LS191N	8	16
IC 6K	SN74LS00N	7	14
IC 6L	SN74LS00N	7	14
IC 6M	SN74LS74AN	7	14
IC 6P	SN74LS00N	7	14
IC 7A	SN74LS166AN	8	16
IC 7B	SN74LS166AN	8	16
IC 7C	SN74LS164N	7	14
IC 7D	MSM5128-12RS	12	24
IC 7E	SN74LS166AN	8	16
IC 7F	SN74LS166AN	8	16
IC 7G	MSM5128-12RS	12	24
IC 7H	SN74LS157N	8	16
IC 7J	SN74LS157N	8	16
IC 7K	SN74LS161AN	8	16
IC 7L	SN74LS00N	7	14
IC 7M	SN74LS221N	8	16
IC 7N	SN74LS123N	8	16
IC 7P	SN74LS164N	7	14


Ref. No.	Type	Pin No.	
		GND	+5V
IC 8A	SN74LS166AN	8	16
IC 8B	SN74LS166AN	8	16
IC 8C	SN74LS374N	10	20
IC 8E	SN74LS374N	10	20
IC 8F	SN74LS164N	7	14
IC 8H	SN74LS157N	8	16
IC 8J	SN74LS157N	8	16
IC 8K	SN74LS161AN	8	16
IC 8L	SN74LS191N	8	16
IC 8M	SN74LS00N	7	14
IC 8N	SN7404N	7	14
IC 8P	SN7404N	7	14
IC 9A	SN74LS166AN	8	16
IC 9B	SN74LS166AN	8	16
IC 9C	SN74LS164N	7	14
IC 9D	MSM5128-12RS	12	24
IC 9E	SN74LS166AN	8	16
IC 9F	SN74LS164N	7	14
IC 9G	MSM5128-12RS	12	24
IC 9H	SN74LS163AN	8	16
IC 9J	MBM2149L-55	9	18
IC 9K	SN74LS123N	8	16
IC 9L	SN74LS161AN	8	16
IC 9M	SN74LS04N	7	14
IC 9N	SN74LS161AN	8	16
IC 9P	SN74LS00N	7	14
IC 10A	SN74LS166AN	8	16
IC 10B	SN74LS166AN	8	16
IC 10C	SN74LS374N	10	20
IC 10D	MSM5128-12RS	12	24
IC 10E	SN74LS166AN	8	16
IC 10F	SN74LS374N	10	20
IC 10G	MSM5128-12RS	12	24
IC 10H	SN74LS163AN	8	16
IC 10J	MBM2149L-55	9	18
IC 10L	SN74LS74AN	7	14
IC 10M	SN7400N	7	14
IC 10N	SN74LS161AN	8	16
IC 10P	SN74LS161AN	8	16
IC 11A	SN74LS166AN	8	16
IC 11B	SN74LS166AN	8	16
IC 11C	SN74LS374N	10	20
IC 11E	SN74LS374N	10	20
IC 11F	SN74LS374N	10	20
IC 11H	SN74LS163AN	8	16
IC 11J	SN74LS374N	10	20
IC 11K	SN74LS02N	7	14
IC 11L	SN74LS374N	10	20
IC 11M	SN74LS374N	10	20
IC 11N	SN74LS04N	7	14
IC 12A	SN74LS374N	10	20
IC 12B	SN74LS374N	10	20
IC 12C	SN74LS164N	7	14
IC 12D	MSM5128-12RS	12	24
IC 12E	SN74LS157N	8	16
IC 12F	SN74LS04N	7	14
IC 12G	SN74LS164N	7	14
IC 12H	SN7404N	7	14
IC 12J	SN74LS74AN	7	14
IC 12K	SN74LS04N	7	14
IC 12N	SN74LS04N	7	14






TP1 K-10
TP2 H-12
TP3 J-12
TP4 E-9
TP5 F-11
TP6 F-12
TP7 N-8
TP8 P-11


TPE1 A-2
TPE2 P-1
TPE3 C-7
TPE4 A-12
TPE5 P-12






Ref. No.	Type	Pin No.	
		GND	+5V
IC 1A	SN74LS164N	7	14
IC 1B	SN74LS164N	7	14
IC 1C	SN74LS164N	7	14
IC 1D	SN74LS166AN	8	16
IC 1E	SN74LS374N	10	20
IC 1F	SN74LS164N	7	14
IC 1G	SN74LS166AN	8	16
IC 1H	SN74LS161AN	8	16
IC 1J	SN74LS161AN	8	16
IC 1M	SN7408N	7	14
IC 2A	SN74LS374N	10	20
IC 2B	SN74LS374N	10	20
IC 2C	SN74LS164N	7	14
IC 2D	MSM5128-12RS	12	24
IC 2E	SN74LS164N	7	14
IC 2F	SN74LS166AN	8	16
IC 2G	MSM5128-12RS	12	24
IC 2H	SN74LS157N	8	16
IC 2J	SN74LS161AN	8	16
IC 2K	SN74LS161AN	8	16
IC 2L	SN74LS221N	8	16
IC 2M	SN74LS164N	7	14
IC 2N	SN74LS164N	7	14
IC 3A	SN74LS166AN	8	16
IC 3B	SN74LS166AN	8	16
IC 3C	SN74LS164N	7	14
IC 3E	SN74LS164N	7	14
IC 3F	SN74LS374N	10	20
IC 3H	SN74LS157N	8	16
IC 3J	SN74LS157N	8	16
IC 3K	SN74LS157N	8	16
IC 3L	SN74LS161AN	8	16
IC 3M	SN74LS74AN	7	14
IC 3N	SN74LS74AN	7	14
IC 4A	SN74LS166AN	8	16
IC 4B	SN74LS166AN	8	16
IC 4C	SN74LS374N	10	20
IC 4D	MSM5128-12RS	12	24
IC 4E	SN74LS374N	10	20
IC 4F	SN74LS166AN	8	16
IC 4G	MSM5128-12RS	12	24
IC 4H	SN74LS157N	8	16
IC 4J	SN74LS157N	8	16
IC 4K	SN74LS163AN	8	16
IC 4L	SN74LS151N	8	16
IC 4M	SN74LS30N	7	14
IC 4N	SN74LS74AN	7	14
IC 5A	SN74LS166AN	8	16
IC 5B	SN74LS166AN	8	16
IC 5C	SN74LS374N	10	20
IC 5D	MSM5128-12RS	12	24
IC 5E	SN74LS164N	7	14
IC 5F	SN74LS374N	10	20
IC 5G	MSM5128-12RS	12	24
IC 5H	SN74LS157N	8	16
IC 5J	SN74LS163AN	8	16
IC 5K	SN74LS85N	8	16
IC 5L	SN74LS393N	7	14
IC 5M	SN74LS04N	7	14
IC 5N	SN74LS04N	7	14
IC 6A	SN74LS166AN	8	16
IC 6B	SN74LS166AN	8	16
IC 6C	SN74LS164N	7	14
IC 6E	SN74LS164N	7	14
IC 6F	SN74LS164N	7	14
IC 6H	SN74LS161AN	8	16
IC 6J	SN74LS161AN	8	16
IC 6K	SN74LS191N	8	16
IC 6L	SN74LS00N	7	14
IC 6M	SN74LS74AN	7	14
IC 6P	SN74LS00N	7	14
IC 7A	SN74LS166AN	8	16
IC 7B	SN74LS166AN	8	16
IC 7C	SN74LS164N	7	14
IC 7D	MSM5128-12RS	12	24
IC 7E	SN74LS166AN	8	16
IC 7F	SN74LS166AN	8	16
IC 7G	MSM5128-12RS	12	24
IC 7H	SN74LS157N	8	16
IC 7J	SN74LS157N	8	16
IC 7K	SN74LS161AN	8	16
IC 7L	SN74LS08N	7	14
IC 7M	SN74LS221N	8	16
IC 7N	SN74LS123N	8	16
IC 7P	SN74LS164N	7	14


Ref. No.	Type	Pin No.	
		GND	+5V
IC 8A	SN74LS166AN	8	16
IC 8B	SN74LS166AN	8	16
IC 8C	SN74LS374N	10	20
IC 8E	SN74LS374N	10	20
IC 8F	SN74LS164N	7	14
IC 8H	SN74LS157N	8	16
IC 8J	SN74LS157N	8	16
IC 8K	SN74LS161AN	8	16
IC 8L	SN74LS191N	8	16
IC 8M	SN74LS00N	7	14
IC 8N	SN7404N	7	14
IC 8P	SN7404N	7	14
IC 9A	SN74LS166AN	8	16
IC 9B	SN74LS166AN	8	16
IC 9C	SN74LS164N	7	14
IC 9D	MSM5128-12RS	12	24
IC 9E	SN74LS166AN	8	16
IC 9F	SN74LS164N	7	14
IC 9G	MSM5128-12RS	12	24
IC 9H	SN74LS163AN	8	16
IC 9J	MBM2149L-55	9	18
IC 9K	SN74LS123N	8	16
IC 9L	SN74LS161AN	8	16
IC 9M	SN74LS04N	7	14
IC 9N	SN74LS161AN	8	16
IC 9P	SN74LS00N	7	14
IC 10A	SN74LS166AN	8	16
IC 10B	SN74LS166AN	8	16
IC 10C	SN74LS374N	10	20
IC 10D	MSM5128-12RS	12	24
IC 10E	SN74LS166AN	8	16
IC 10F	SN74LS374N	10	20
IC 10G	MSM5128-12RS	12	24
IC 10H	SN74LS163AN	8	16
IC 10J	MBM2149L-55	9	18
IC 10L	SN74LS74AN	7	14
IC 10M	SN7400N	7	14
IC 10N	SN74LS161AN	8	16
IC 10P	SN74LS161AN	8	16
IC 11A	SN74LS166AN	8	16
IC 11B	SN74LS166AN	8	16
IC 11C	SN74LS374N	10	20
IC 11E	SN74LS374N	10	20
IC 11F	SN74LS374N	10	20
IC 11H	SN74LS163AN	8	16
IC 11J	SN74LS374N	10	20
IC 11K	SN74LS02N	7	14
IC 11L	SN74LS374N	10	20
IC 11M	SN74LS374N	10	20
IC 11N	SN74LS04N	7	14
IC 12A	SN74LS374N	10	20
IC 12B	SN74LS374N	10	20
IC 12C	SN74LS164N	7	14
IC 12D	MSM5128-12RS	12	24
IC 12E	SN74273N	10	20
IC 12F	SN74LS04N	7	14
IC 12G	SN74LS164N	7	14
IC 12H	SN7404N	7	14
IC 12J	SN74LS74AN	7	14
IC 12K	SN74LS04N	7	14
IC 12N	SN74LS04N	7	14






TP1 K-10
TP2 H-12
TP3 J-12
TP4 E-9
TP5 P-11
TP6 F-12
TP7 N-8
TP8 P-11

TPE1 A-2
TPE2 P-1
TPE3 G-7
TPE4 A-12
TPE5 P-12







MY-17 (VIDEO TBC)

Ref. No.	Type	Pin No.	
		GND	+5V
IC 1A	SN74LS164N	7	14
IC 1B	SN74LS164N	7	14
IC 1C	SN74LS164N	7	14
IC 1D	SN74LS166AN	8	16
IC 1E	SN74LS374N	10	20
IC 1F	SN74LS164N	7	14
IC 1G	SN74LS166AN	8	16
IC 1H	SN74LS161AN	8	16
IC 1J	SN74LS161AN	8	16
IC 1M	SN7408N	7	14
IC 2A	SN74LS374N	10	20
IC 2B	SN74LS374N	10	20
IC 2C	SN74LS164N	7	14
IC 2D	MSM5128-12RS	12	24
IC 2E	SN74LS164N	7	14
IC 2F	SN74LS166AN	8	16
IC 2G	MSM5128-12RS	12	24
IC 2H	SN74LS157N	8	16
IC 2J	SN74LS161AN	8	16
IC 2K	SN74LS161AN	8	16
IC 2L	SN74LS221N	8	16
IC 2M	SN74LS164N	7	14
IC 2N	SN74LS164N	7	14
IC 3A	SN74LS166AN	8	16
IC 3B	SN74LS166AN	8	16
IC 3C	SN74LS164N	7	14
IC 3E	SN74LS374N	10	20
IC 3F	SN74LS166AN	8	16
IC 3H	SN74LS157N	8	16
IC 3J	SN74LS175N	8	16
IC 3K	SN74LS175N	8	16
IC 3L	SN74LS161AN	8	16
IC 3M	SN74LS74AN	7	14
IC 3N	SN74LS74AN	7	14
IC 4A	SN74LS166AN	8	16
IC 4B	SN74LS166AN	8	16
IC 4C	SN74LS374N	10	20
IC 4D	MSM5128-12RS	12	24
IC 4E	SN74LS166AN	8	16
IC 4F	SN74LS166AN	8	16
IC 4G	MSM5128-12RS	12	24
IC 4H	SN74LS157N	8	16
IC 4J	SN74LS175N	8	16
IC 4K	SN74LS163AN	8	16
IC 4L	SN74LS151N	8	16
IC 4M	SN74LS30N	7	14
IC 4N	SN74LS74AN	7	14
IC 5A	SN74LS166AN	8	16
IC 5B	SN74LS166AN	8	16
IC 5C	SN74LS374N	10	20
IC 5D	MSM5128-12RS	12	24
IC 5E	SN74LS164N	7	14
IC 5F	SN74LS374N	10	20
IC 5G	MSM5128-12RS	12	24
IC 5H	SN74LS157N	8	16
IC 5J	SN74LS163AN	8	16
IC 5K	SN74LS85N	8	16
IC 5L	SN74LS393N	7	14
IC 5M	SN74LS04N	7	14
IC 5N	SN74LS04N	7	14
IC 6A	SN74LS166AN	8	16
IC 6B	SN74LS166AN	8	16
IC 6C	SN74LS164N	7	14
IC 6E	SN74LS164N	7	14
IC 6F	SN74LS164N	7	14
IC 6H	SN74LS161AN	8	16
IC 6J	SN74LS161AN	8	16
IC 6K	SN74LS191N	8	16
IC 6L	SN74LS00N	7	14
IC 6M	SN74LS74AN	7	14
IC 6P	SN74LS00N	7	14
IC 7A	SN74LS166AN	8	16
IC 7B	SN74LS166AN	8	16
IC 7C	SN74LS164N	7	14
IC 7D	MSM5128-12RS	12	24
IC 7E	SN74LS166AN	8	16
IC 7F	SN74LS166AN	8	16
IC 7G	MSM5128-12RS	12	24
IC 7H	SN74LS157N	8	16
IC 7J	SN74LS157N	8	16
IC 7K	SN74LS161AN	8	16
IC 7L	SN74LS08N	7	14
IC 7M	SN74LS221N	8	16
IC 7N	SN74LS123N	8	16
IC 7P	SN74LS164N	7	14


Ref. No.	Type	Pin No.	
		GND	+5V
IC 8A	SN74LS166AN	8	16
IC 8B	SN74LS166AN	8	16
IC 8C	SN74LS374N	10	20
IC 8E	SN74LS374N	10	20
IC 8F	SN74LS164N	7	14
IC 8H	SN74LS157N	8	16
IC 8J	SN74LS157N	8	16
IC 8K	SN74LS161AN	8	16
IC 8L	SN74LS191N	8	16
IC 8M	SN74LS00N	7	14
IC 8N	SN7404N	7	14
IC 8P	SN7404N	7	14
IC 9A	SN74LS166AN	8	16
IC 9B	SN74LS166AN	8	16
IC 9C	SN74LS164N	7	14
IC 9D	MSM5128-12RS	12	24
IC 9E	SN74LS166AN	8	16
IC 9F	SN74LS164N	7	14
IC 9G	MSM5128-12RS	12	24
IC 9H	SN74LS163AN	8	16
IC 9J	MBM2149L-55	9	18
IC 9K	SN74LS123N	8	16
IC 9L	SN74LS161AN	8	16
IC 9M	SN74LS04N	7	14
IC 9N	SN74LS161AN	8	16
IC 9P	SN74LS00N	7	14
IC 10A	SN74LS166AN	8	16
IC 10B	SN74LS166AN	8	16
IC 10C	SN74LS374N	10	20
IC 10D	MSM5128-12RS	12	24
IC 10E	SN74LS166AN	8	16
IC 10F	SN74LS374N	10	20
IC 10G	MSM5128-12RS	12	24
IC 10H	SN74LS163AN	8	16
IC 10J	MBM2149L-55	9	18
IC 10L	SN74LS74AN	7	14
IC 10M	SN7400N	7	14
IC 10N	SN74LS161AN	8	16
IC 10P	SN74LS161AN	8	16
IC 11A	SN74LS166AN	8	16
IC 11B	SN74LS166AN	8	16
IC 11C	SN74LS374N	10	20
IC 11E	SN74LS374N	10	20
IC 11F	SN74LS374N	10	20
IC 11H	SN74LS163AN	8	16
IC 11J	SN74LS374N	10	20
IC 11K	SN74LS02N	7	14
IC 11L	SN74LS374N	10	20
IC 11M	SN74LS374N	10	20
IC 11N	SN74LS04N	7	14
IC 12A	SN74LS374N	10	20
IC 12B	SN74LS374N	10	20
IC 12C	SN74LS164N	7	14
IC 12D	MSM5128-12RS	12	24
IC 12E	SN74273N	10	20
IC 12F	SN74LS04N	7	14
IC 12G	SN74LS164N	7	14
IC 12H	SN7404N	7	14
IC 12J	SN74LS74AN	7	14
IC 12K	SN74LS04N	7	14
IC 12N	SN74LS04N	7	14






TP1 K-10
TP2 H-12
TP3 J-12
TP4 E-9
TP5 P-11
TP6 F-12
TP7 N-8
TP8 P-11

TPE1 A-2
TPE2 P-1
TPE3 G-7
TPE4 A-12
TPE5 P-12





16-LINE CHROMA & CHROMA DO MEMORY




PR-48 (VIDEO TBC)


Ref. No.	Type	Pin No.					
		-11V	-5V	GND	+5V	+11V	+12V
IC 1	BX365A	9		4, 7		3	
IC 2	HI1-201-5	4		5		13	
IC 3	TL082CP		14, 19, 23	4, 13, 15, 20, 22		8	
IC 4	CX20052				1, 16		
IC 5	HD10105						
IC 7	HD10125		8	16	9		
IC 8	HD10125		8	16	9		
IC 9	PC4557C	4		4, 7		3	
IC 10	BX365A						
IC 11	TL082CP	4		5		8	
IC 12	HI1-201-5	4				13	
IC 13	TL082CP		4, 19, 23	4, 13, 15, 20, 22		8	
IC 14	CX20052				1, 16		
IC 15	HD10105						
IC 17	HD10125		8	16	9		
IC 18	HD10125		8	16	9		
IC 19	BX365A	9		4, 7		3	
IC 20	PC319C	6				11	
IC 21	BX365A	9		4, 7		3	
IC 22	PC319C			3, 8		11	
IC 23	HA1-4905-5	5			1	13	
IC 24	TL084CN	11				4	
IC 25	HI1-201-5	4		5		13	
IC 26	SN74LS123N			8	16		
IC 27	HI1-201-5	4		5		13	
IC 28	SN74LS221N			8	16		
IC 29	SN75454BP			4	8		
IC 30	HA1-4905-5	5		9	1	13	
IC 31	TL084CN	11			1	4	
IC 32	HA1-4905-5	5		9	1	13	
IC 33	HI1-201-5	4		5		13	
IC 34	SN74LS00N			7	14		
IC 35	SN74LS74AN			7	14		
IC 36	SN74LS221N			8	16		
IC 37	SN74LS20N			7	14		
IC 38	TC4528BP			8	16		
IC 39	SN74LS221N			8	16		
IC 40	TC4022BP			8	16		
IC 41	BX365A	9		4, 7		3	
IC 42	BX365A	9		4, 7		3	
IC 43	BX365A	9		4, 7		3	
IC 44	CX20051A			1, 3, 15, 24, 27	14, 21, 22, 28		
IC 45	CX20051A			1, 3, 15, 24, 27	14, 21, 22, 28		
IC 46	CX20051A			1, 3, 15, 24, 27	14, 21, 22, 28		
IC 47	PC4557C	4				8	
IC 48	TL082CP	4				8	
IC 49	TL607CP	5		1		8	
IC 50	TL607CP	5		1		8	
IC 51	TL082CP	4				8	
IC 52	PC4557C				1, 16		
IC 53	MC10198L		8				
IC 54	SN74S32N		7		14		
IC 55	SN74LS163AN		8		16		
IC 56	SN74273N		10		20		
IC 57	MBM2149L-55		9		18		
IC 58	MBM2149L-55		9		18		
IC 59	MBM2149L-55		9		18		
IC 60	MBM2149L-55		9		18		
IC 61	SN74273N		10		20		
IC 62	SN74LS04N		7		14		
IC 63	SN74LS113AN		7		14		
IC 64	SN74LS374N		10		20		
IC 65	SN74LS163AN		8		16		
IC 66	SN74LS273N		10		20		
IC 67	SN74LS273N		10		20		
IC 68	SN74LS273N		10		20		
IC 69	SN74LS374N		10		20		
IC 72	PC7905H			3			1






D1	P-3	IC41	G-1	RV1	O-2
D2	P-3	IC42	E-1	RV2	O-3
D3	P-3	IC43	C-1	RV3	M-1
D4	P-3	IC44	G-2	RV4	M-2
D5	P-3	IC45	E-2	RV5	M-2
D6	O-3	IC46	B-2	RV6	F-4
D7	P-4	IC47	F-4	RV7	B-4
D8	L-1	IC48	E-4	RV8	A-4
D9	L-2	IC49	E-4	RV9	G-5
D10	N-3	IC50	D-4		
D11	N-3	IC51	C-4	T1	P-4
D12	N-3	IC52	B-4	T2	N-4
D13	N-3	IC53	A-3		
D14	N-3	IC54	F-5	TP1	P-1
D15	M-3	IC55	E-5	TP2	P-3
D16	N-4	IC56	D-5	TP3	P-5
D17	N-3	IC57	D-5	TP4	P-7
D18	K-1	IC58	C-5	TP5	N-1
D19	H-1	IC59	C-5	TP6	M-3
D20	I-2	IC60	B-5	TP7	M-5
D21	J-2	IC61	A-5	TP8	K-3
D22	H-2	IC62	F-6	TP9	F-1
D23	K-5	IC63	E-6	TP10	F-1
D24	J-5	IC64	D-6	TP11	F-2
D25	J-5	IC65	D-6	TP12	C-3
D26	L-4	IC66	C-6	TP13	D-1
D27	K-1	IC67	C-6	TP14	C-2
D28	H-1	IC68	B-6	TP15	B-1
		IC69	A-6	TP16	A-2
DL1	L-3	IC70	H-7	TP17	A-2
DL2	P-6			TP18	F-3
DL3	M-6			TP19	G-4
		LPF1	P-1	TP20	J-6
IC1	P-2	LPF2	N-2	TP21	K-3
IC2	O-3	LPF3	G-2	TP22	K-7
IC3	O-4	LPF4	E-2		
IC4	O-5	LPF5	B-2		
IC5	P-6			TPE1	O-1
IC7	O-6	Q1	O-1	TPE2	P-7
IC8	O-6	Q2	P-3	TPE3	H-1
IC9	L-2	Q3	P-3	TPE4	G-6
IC10	N-2	Q4	P-3	TPE5	F-1
IC11	M-3	Q5	P-3	TPE6	B-7
IC12	L-3	Q6	P-4	TPE7	O-2
IC13	L-4	Q7	P-4	TPE8	N-7
IC14	M-5	Q8	O-4	TPE9	F-1
IC15	N-6	Q9	P-4	TPE10	F-7
IC17	M-6	Q10	P-4		
IC18	L-6	Q11	M-1		
IC19	L-2	Q12	L-2		
IC20	K-2	Q13	N-3		
IC21	J-2	Q14	M-3		
IC22	I-2	Q15	M-3		
IC23	I-2	Q16	M-3		
IC24	K-3	Q17	M-4		
IC25	J-3	Q18	M-4		
IC26	I-3	Q19	M-4		
IC27	I-3	Q20	N-4		
IC28	K-4	Q21	N-4		
IC29	K-4	Q22	K-1		
IC30	J-4	Q23	K-1		
IC31	I-4	Q24	K-1		
IC32	I-4	Q25	J-1		
IC33	H-4	Q26	J-1		
IC34	K-5	Q27	I-1		
IC35	K-5	Q28	F-2		
IC36	J-5	Q29	D-2		
IC37	I-5	Q30	A-2		
IC38	I-5				
IC39	H-5				
IC40	G-5				







PR-48(1/3)
BVW-10P


Ref. No.	Type	Pin No.					
		-11V	-5V	GND	+5V	+11V	+12V
IC 1	BX365A	9		4, 7		3	
IC 2	HI1-201-5	4		5		8	
IC 3	TL082CP		14, 19, 23	4, 13, 15, 20, 22			
IC 4	CX20052		8		1, 16		
IC 5	HD10105						
IC 7	HD10125		8	16	9		
IC 8	HD10125		8	16	9		
IC 9	PC4557C	4				8	
IC 10	BX365A	9		4, 7		3	
IC 11	TL082CP	4		5		8	
IC 12	HI1-201-5	4		5		8	
IC 13	TL082CP		4, 19, 23	4, 13, 15, 20, 22			
IC 14	CX20052		8		1, 16		
IC 15	HD10105						
IC 17	HD10125		8	16	9		
IC 18	HD10125		8	16	9		
IC 19	BX365A	9		4, 7		3	
IC 20	PC319C	6				11	
IC 21	BX365A	9		4, 7		3	
IC 22	PC319C	6		3, 8		11	
IC 23	HA1-4905-5	5		9	1	13	
IC 24	TL084CN	11				4	
IC 25	HI1-201-5	4		5		8	
IC 26	SN74LS123N			8	16		
IC 27	HI1-201-5	4		5		8	
IC 28	SN74LS22N			8	16		
IC 29	SN75454BP			4	8		
IC 30	HA1-4905-5	5		9	1	13	
IC 31	TL084CN	11				4	
IC 32	HA1-4905-5	5		9	1	13	
IC 33	HI1-201-5	4		5		8	
IC 34	SN74LS00N			7	14		
IC 35	SN74LS74AN			8	16		
IC 36	SN74LS22N			8	16		
IC 37	SN74LS20N			7	14		
IC 38	TC4528BP			8	16		
IC 39	SN74LS22N			8	16		
IC 40	TC4022BP			8	16		
IC 41	BX365A	9		4, 7		3	
IC 42	BX365A	9		4, 7		3	
IC 43	BX365A	9		4, 7		3	
IC 44	CX20051A			1, 3, 15, 24, 27	14, 21, 22, 28		
IC 45	CX20051A			1, 3, 15, 24, 27	14, 21, 22, 28		
IC 46	CX20051A			1, 3, 15, 24, 27	14, 21, 22, 28		
IC 47	PC4557C	4				8	
IC 48	TL082CP	4				8	
IC 49	TL607CP	5		1		8	
IC 50	TL607CP	5		1		8	
IC 51	TL082CP	4				8	
IC 52	PC4557C	4				8	
IC 53	MC10198L			8	1, 16		
IC 54	SN74LS32N			7	14		
IC 55	SN74LS163AN			8	16		
IC 56	SN74273N			10	20		
IC 57	MBM2149L-55			9	18		
IC 58	MBM2149L-55			9	18		
IC 59	MBM2149L-55			9	18		
IC 60	MBM2149L-55			9	18		
IC 61	SN74273N			10	20		
IC 62	SN74LS04N			7	14		
IC 63	SN74LS113AN			7	14		
IC 64	SN74LS374N			10	20		
IC 65	SN74LS163AN			8	16		
IC 66	SN74LS273N			10	20		
IC 67	SN74LS273N			10	20		
IC 68	SN74LS273N			10	20		
IC 69	SN74LS374N			10	20		
IC 72	PC7905H			3			1






D1	P-3	IC41	G-1	RV1	O-2
D2	P-3	IC42	E-1	RV2	O-3
D3	P-3	IC43	C-1	RV3	M-1
D4	P-3	IC44	G-2	RV4	M-2
D5	P-3	IC45	E-2	RV5	M-2
D6	O-3	IC46	B-2	RV6	F-4
D7	P-4	IC47	F-4	RV7	B-4
D8	L-1	IC48	E-4	RV8	A-4
D9	L-2	IC49	E-4	RV9	G-5
D10	N-3	IC50	D-4		
D11	N-3	IC51	C-4	T1	P-4
D12	N-3	IC52	B-4	T2	N-4
D13	N-3	IC53	A-3		
D14	N-3	IC54	F-5	TP1	P-1
D15	N-3	IC55	E-5	TP2	P-3
D16	N-4	IC56	D-5	TP3	P-5
D17	N-3	IC57	D-5	TP4	P-7
D18	K-1	IC58	C-5	TP5	N-1
D19	H-1	IC59	C-5	TP6	M-3
D20	I-2	IC60	B-5	TP7	M-5
D21	J-2	IC61	A-5	TP8	K-3
D22	H-2	IC62	F-6	TP9	F-1
D23	K-5	IC63	E-6	TP10	F-1
D24	J-5	IC64	D-6	TP11	F-2
D25	L-4	IC65	D-6	TP12	C-3
D26	L-4	IC66	C-6	TP13	D-1
D27	K-1	IC67	C-6	TP14	C-2
D28	H-1	IC68	B-6	TP15	B-1
		IC69	A-6	TP16	A-2
DL1	L-3	IC70	H-7	TP17	A-2
DL2	P-6			TP18	F-3
DL3	M-6			TP19	G-4
IC1	P-2			TP20	J-6
IC2	O-3			TP21	K-3
IC3	O-4			TP22	K-7
IC4	O-5				
IC5	P-6			TP1	O-1
IC6	O-6			TP2	P-7
IC7	O-6			TP3	H-1
IC8	O-6			TP4	G-6
IC9	L-2			TP5	F-1
IC10	N-2			TP6	B-7
IC11	M-3			TP7	O-2
IC12	L-3			TP8	N-7
IC13	L-4			TP9	F-1
IC14	M-5			TP10	F-7
IC15	N-6				
IC16	M-6				
IC17	L-6				
IC18	L-2				
IC19	K-2				
IC20	J-2				
IC21	I-2				
IC22	I-2				
IC23	I-2				
IC24	K-3				
IC25	J-3				
IC26	I-3				
IC27	I-3				
IC28	K-4				
IC29	K-4				
IC30	J-4				
IC31	I-4				
IC32	I-4				
IC33	H-4				
IC34	K-5				
IC35	K-5				
IC36	J-5				
IC37	I-5				
IC38	I-5				
IC39	H-5				
IC40	G-5				







PR-48 (VIDEO TBC)


Ref. No.	Type	Pin No.					
		-11V	-5V	GND	+5V	+11V	+12V
IC 1	BX365A	9		4,7		3	
IC 2	HI1-201-5	4		5		13	
IC 3	TL082CP	4				8	
IC 4	CX20052		14, 19, 23	4, 13, 15, 20, 22	1, 16		
IC 5	HD10105		8				
IC 7	HD10125		8	16	9		
IC 8	HD10125		8	16	9		
IC 9	PC4557C	4				8	
IC 10	BX365A	9		4,7		3	
IC 11	TL082CP	4		5		13	
IC 12	TL082CP	4				8	
IC 13	CX20052		4, 19, 23	4, 13, 15, 20, 22	1, 16		
IC 15	HD10105		8				
IC 17	HD10125		8	16	9		
IC 18	HD10125		8	16	9		
IC 19	BX365A	9		4,7		3	
IC 20	PC319C	6				11	
IC 21	BX365A	9		4,7		3	
IC 22	PC319C	6		3,8		11	
IC 23	HA1-4905-5	5		9	1	13	
IC 24	TL084CN	11				4	
IC 25	HI1-201-5	4		5	16	13	
IC 26	SN74LS123N	4		8			
IC 27	HI1-201-5	4		5	16	13	
IC 28	SN74LS221N	4		8	16		
IC 29	SN75454BP	5		4	8		
IC 30	HA1-4905-5	5		9	1	13	
IC 31	TL084CN	11				4	
IC 32	HA1-4905-5	5		9	1	13	
IC 33	HI1-201-5	4		5	16	13	
IC 34	SN74LS00N			7	14		
IC 35	SN74LS74AN			7	14		
IC 36	SN74LS221N			8	16		
IC 37	SN74LS20N			7	14		
IC 38	TC4528BP			8	16		
IC 39	SN74LS221N			8	16		
IC 40	TC4022BP			8	16		
IC 41	BX365A	9		4,7		3	
IC 42	BX365A	9		4,7		3	
IC 43	BX365A	9		4,7		3	
IC 44	CX20051A		1, 3, 15, 24, 27	14, 21, 22, 28			
IC 45	CX20051A		1, 3, 15, 24, 27	14, 21, 22, 28			
IC 46	CX20051A		1, 3, 15, 24, 27	14, 21, 22, 28			
IC 47	PC4557C	4				8	
IC 48	TL082CP	4		5		13	
IC 49	TL607CP	5		1		8	
IC 50	TL607CP	5		1		8	
IC 51	TL082CP	4				8	
IC 52	PC4557C			8	1, 16		
IC 53	MC10198L			7	14		
IC 54	SN74LS32N			8	16		
IC 55	SN74LS163AN			10	20		
IC 56	SN74273N			10	20		
IC 57	MBM2149L-55			9	18		
IC 58	MBM2149L-55			9	18		
IC 59	MBM2149L-55			9	18		
IC 60	MBM2149L-55			9	18		
IC 61	SN74273N			10	20		
IC 62	SN74LS04N			7	14		
IC 63	SN74LS113AN			7	14		
IC 64	SN74LS374N			7	20		
IC 65	SN74LS163AN			8	16		
IC 66	SN74LS273N			10	20		
IC 67	SN74LS273N			10	20		
IC 68	SN74LS273N			10	20		
IC 69	SN74LS374N			10	20		
IC 72	PC7905H			3		1	







D1	P-3	IC41	G-1	RV1	O-2
D2	P-3	IC42	E-1	RV2	O-3
D3	P-3	IC43	C-1	RV3	M-1
D4	P-3	IC44	G-2	RV4	M-2
D5	P-3	IC45	E-2	RV5	M-2
D6	O-3	IC46	B-2	RV6	F-4
D7	P-4	IC47	F-4	RV7	B-4
D8	L-1	IC48	E-4	RV8	A-4
D9	L-2	IC49	E-4	RV9	G-5
D10	N-3	IC50	D-4		
D11	N-3	IC51	C-4	T1	P-4
D12	N-3	IC52	B-4	T2	N-4
D13	N-3	IC53	A-3		
D14	N-3	IC54	F-5	TP1	P-1
D15	M-3	IC55	E-5	TP2	P-3
D16	N-4	IC56	D-5	TP3	P-5
D17	N-3	IC57	D-5	TP4	P-7
D18	K-1	IC58	C-5	TP5	N-1
D19	H-1	IC59	C-5	TP6	M-3
D20	I-2	IC60	B-5	TP7	M-5
D21	J-2	IC61	A-5	TP8	K-3
D22	H-2	IC62	F-6	TP9	F-1
D23	K-5	IC63	E-6	TP10	F-1
D24	J-5	IC64	D-6	TP11	F-2
D25	L-5	IC65	D-6	TP12	C-3
D26	I-4	IC66	C-6	TP13	D-1
D27	K-1	IC67	C-6	TP14	C-2
D28	H-1	IC68	B-6	TP15	B-1
		IC69	A-6	TP16	A-2
DL1	L-3	IC70	H-7	TP17	A-2
DL2	P-6			TP18	F-3
DL3	M-6			TP19	G-4
		LPF1	P-1	TP20	J-6
		LPF2	N-2	TP21	K-3
		LPF3	G-2	TP22	K-7
		LPF4	E-2		
		LPF5	B-2	TPE1	O-1
IC1	P-2			TPE2	P-7
IC2	O-3			TPE3	H-1
IC3	O-4			TPE4	G-6
IC4	O-5			TPE5	F-1
IC5	P-6			TPE6	B-7
IC6	O-6			TPE7	O-2
IC7	O-6			TPE8	N-7
IC8	O-6			TPE9	F-1
IC9	L-2			TPE10	F-7
IC10	N-2				
IC11	M-3				
IC12	L-3				
IC13	L-4				
IC14	M-5				
IC15	N-6				
IC16	M-6				
IC17	M-6				
IC18	L-6				
IC19	L-2				
IC20	K-2				
IC21	J-2				
IC22	I-2				
IC23	I-2				
IC24	K-3				
IC25	J-3				
IC26	I-3				
IC27	I-3				
IC28	K-4				
IC29	K-4				
IC30	J-4				
IC31	I-4				
IC32	I-4				
IC33	H-4				
IC34	K-5				
IC35	L-5				
IC36	J-5				
IC37	I-5				
IC38	I-5				
IC39	H-5				
IC40	G-5				





A B C D E F G H I J K L M N







1A~30A--- COMPONENT SIDE
1B~30B--- SOLDERING SIDE


EN-20 -SOLDERING SIDE-
1-608-820-12
BVW-10P

CV601	A - 1	IC616	C - 2	SW501	G - 1
		IC617	B - 1	SW502	G - 1
D201	N - 3	IC618	C - 2		
D202	O - 3	IC619	D - 2	TP201	N - 5
D401	H - 2	IC620	A - 5	TP202	N - 3
D601	A - 4	IC701	K - 3	TP203	N - 1
D602	A - 4	IC702	K - 2	TP204	P - 5
D701	K - 1	IC703	K - 2	TP205	O - 5
D702	M - 1	IC704	K - 2	TP206	O - 3
		IC706	M - 3	TP207	P - 1
DL501	F - 5	IC707	M - 2	TP208	P - 4
DL601	B - 4	IC708	L - 2	TP211	M - 6
		IC709	M - 2	TP212	O - 6
E107	L - 6	IC711	K - 5	TP213	P - 6
E201	P - 1			TP401	H - 3
E206	P - 7	LV501	G - 3	TP402	H - 3
E403	H - 1	LV601	C - 1	TP403	J - 1
E408	H - 7			TP404	H - 2
E504	D - 1	Q201	N - 3	TP405	J - 5
E509	G - 6	Q202	N - 1	TP406	J - 5
E605	B - 1	Q203	O - 3	TP407	J - 4
E610	A - 7	Q204	P - 2	TP408	J - 4
E702	K - 1	Q205	P - 2	TP409	H - 6
		Q206	O - 1	TP410	H - 6
FL601	A - 3	Q501	E - 6	TP411	H - 6
		Q503	G - 4	TP412	H - 6
IC201	N - 6	Q504	F - 2	TP501	E - 6
IC202	N - 5	Q505	G - 2	TP502	E - 3
IC203	N - 5	Q506	G - 2	TP503	E - 3
IC204	N - 4	Q507	G - 2	TP504	E - 1
IC205	N - 2	Q508	E - 5	TP505	F - 1
IC206	O - 6	Q601	C - 5	TP506	F - 1
IC207	O - 5	Q602	D - 5	TP507	F - 1
IC208	O - 5	Q603	C - 4	TP508	G - 6
IC209	O - 4	Q604	B - 3	TP509	G - 4
IC210	O - 2	Q605	B - 1	TP510	G - 3
IC211	P - 5	Q606	B - 4	TP601	B - 7
IC212	P - 5	Q607	D - 1	TP602	A - 7
IC213	P - 3	Q608	C - 1	TP603	C - 7
IC214	P - 3	Q701	K - 1	TP604	D - 7
IC215	P - 1	Q703	L - 1	TP605	D - 5
IC401	H - 4			TP606	B - 4
IC402	H - 3	RV201	M - 3	TP607	A - 2
IC403	H - 2	RV202	N - 1	TP608	A - 2
IC404	I - 2	RV203	O - 3	TP609	C - 2
IC405	I - 2	RV204	O - 2	TP701	L - 3
IC406	J - 3	RV205	O - 1	TP710	B - 2
IC407	I - 2	RV206	P - 6	TP704	K - 4
IC408	I - 3	RV207	P - 4	TP705	M - 2
IC409	I - 3	RV208	P - 3	TP711	K - 4
IC410	J - 4	RV209	P - 2	TP712	L - 4
IC411	J - 6	RV210	P - 1	TP713	L - 4
IC412	I - 6	RV401	I - 2		
IC501	F - 3	RV402	I - 5	X401	J - 2
IC502	F - 2	RV403	I - 5	X601	B - 1
IC503	F - 2	RV501	F - 3		
IC504	G - 5	RV502	E - 3		
IC505	F - 5	RV503	G - 5		
IC506	E - 2	RV504	G - 4		
IC601	B - 5	RV601	A - 6		
IC602	B - 6	RV602	C - 6		
IC603	B - 6	RV603	C - 6		
IC605	C - 6	RV604	C - 5		
IC607	D - 6	RV605	C - 5		
IC608	B - 5	RV606	D - 3		
IC609	B - 6	RV607	A - 4		
IC610	C - 6	RV608	D - 1		
IC611	C - 3	RV609	C - 2		
IC612	D - 3	RV610	D - 2		
IC613	A - 2	RV611	A - 5		
IC614	A - 3	RV701	K - 1		
IC615	B - 4	RV703	L - 1		
		RV706	K - 5		


N-20 (1/3) (VIDEO ENCODER)









EN-20 (VIDEO ENCODER)







1A~30A---COMPONENT SIDE
1B~30B---SOLDERING SIDE


CN5

1A~30A---COMPONENT SIDE
1B~30B---SOLDERING SIDE

CN6

18-89


DU-45 -SOLDERING SIDE-
1-610-459-11
RVW-top




CV601 A-1	IC616 C-2	SW501 G-1
D201 N-3	IC617 B-1	SW502 G-1
D202 O-3	IC618 C-2	
D401 H-2	IC619 D-2	TP201 N-5
D601 A-4	IC620 A-5	TP202 N-3
D701 K-1	IC701 K-3	TP203 N-1
D702 M-1	IC702 K-2	TP204 P-5
	IC703 K-2	TP205 O-5
	IC704 K-2	TP206 O-3
	IC706 M-3	TP207 P-4
DL501 F-5	IC707 M-2	TP208 P-4
DL601 B-4	IC708 L-2	TP211 M-6
	IC709 M-2	TP212 O-6
E107 L-6	IC711 K-5	TP213 P-6
E201 P-1		TP401 H-3
E206 P-7	LV501 G-3	TP402 H-3
E403 H-1	LV601 C-1	TP403 J-1
E408 H-7		TP404 H-2
E504 D-1	Q201 N-3	TP405 J-5
E509 G-6	Q202 N-1	TP406 J-4
E605 B-1	Q203 O-3	TP407 J-4
E610 A-7	Q204 P-2	TP408 J-4
E702 K-1	Q205 P-2	TP409 H-6
	Q206 O-1	TP410 H-6
FL601 A-3	Q501 E-6	TP411 H-6
	Q503 G-4	TP412 H-6
IC201 N-6	Q504 F-2	TP501 E-6
IC202 N-5	Q505 G-2	TP502 E-3
IC203 N-5	Q506 G-2	TP503 E-3
IC204 N-4	Q507 G-2	TP504 E-1
IC205 N-2	Q508 E-5	TP505 F-1
IC206 O-6	Q601 C-5	TP506 F-1
IC207 O-5	Q602 D-5	TP507 F-1
IC208 O-5	Q603 C-4	TP508 G-6
IC209 O-4	Q604 B-3	TP509 G-4
IC210 O-2	Q605 B-1	TP510 G-3
IC211 P-5	Q606 B-4	TP601 B-7
IC212 P-5	Q607 D-1	TP602 A-7
IC213 P-3	Q608 C-1	TP603 C-7
IC214 P-3	Q701 K-1	TP604 D-7
IC215 P-1	Q703 L-1	TP605 D-5
IC401 H-4		TP606 B-4
IC402 H-3	RV201 M-3	TP607 A-2
IC403 H-2	RV202 N-1	TP608 A-2
IC404 I-2	RV203 O-3	TP609 C-2
IC405 I-2	RV204 O-2	TP610 B-3
IC406 J-3	RV205 O-1	TP701 L-2
IC407 I-2	RV206 P-6	TP704 K-4
IC408 I-3	RV207 P-4	TP705 M-2
IC409 I-3	RV208 P-3	TP711 K-4
IC410 J-4	RV209 P-2	TP712 L-4
IC411 J-6	RV210 P-1	TP713 L-4
IC412 I-6	RV401 I-2	
IC501 F-3	RV402 I-5	X401 J-2
IC502 F-2	RV403 I-5	X601 B-1
IC503 F-2	RV501 F-3	
IC504 G-5	RV502 E-3	
IC505 F-5	RV503 G-5	
IC506 E-2	RV504 G-4	
IC601 B-5	RV601 A-6	
IC602 B-6	RV602 C-6	
IC603 B-6	RV603 C-6	
IC605 C-6	RV604 C-5	
IC607 D-6	RV605 C-5	
IC608 B-5	RV606 D-3	
IC609 B-6	RV607 A-4	
IC610 C-6	RV608 D-1	
IC611 C-3	RV609 C-2	
IC612 D-3	RV610 D-2	
IC613 A-2	RV611 A-5	
IC614 A-3	RV701 K-1	
IC615 B-4	RV703 L-1	
	RV706 K-5	

1A~30A---COMPONENT SIDE
1B~30B---SOLDERING SIDE


EN-20 - SOLDERING SIDE -
1-608-820-12
BVW-10P




DU-45 - SOLDERING SIDE -
1-610-459-11
BVW-10P





DU-48 - SOLDERING SIDE -
1-610-480-11
BVW-10P







18-95






AU-37 (AUDIO PB SYSTEM)






AU-37
1-608-578-12
B/W-10
B/W-12P

SV-51 (1/5) (SERVO SYSTEM)






SV-51


1-607-975-12

1A~30A ---- COMPONENT SIDE
1B~30B ---- SOLDERING SIDE

1A~30A ---- COMPONENT SIDE
1B~30B ---- SOLDERING SIDE




D1	T-4	IC1	B-1	IC61	B-5	RV501	E-4
D2	R-4	IC2	C-1	IC62	J-5	RV502	E-4
D3	J-4	IC3	D-1	IC63	L-5	RV503	D-4
D4	J-4	IC4	E-1	IC64	A-5	RV504	D-4
D5	R-3	IC5	F-1	IC65	B-5	RV505	F-5
D6	K-5	IC6	G-1	IC66	D-5	RV506	G-5
D7	K-5	IC7	H-1	IC67	E-5	RV507	H-5
D8	M-5	IC8	J-1	IC68	G-5	RV508	H-5
D9	M-5	IC9	K-1	IC69	H-5	RV509	A-2
D10	P-5	IC10	L-1	IC70	D-5	RV510	A-3
D11	T-4	IC11	M-1	IC71	H-8	RV511	A-3
D12	T-4	IC12	N-1	IC72	Q-5	RV512	C-3
D13	T-5	IC13	P-1	IC73	N-5	RV513	C-3
D14	T-5	IC14	Q-1	IC74	Q-1	RV514	C-3
D15	M-2	IC15	R-1	IC75	P-2	RV515	C-3
D16	M-1	IC16	S-1	IC76		RV516	C-3
D17	R-3	IC17	T-1	IC77		RV517	C-3
D18	T-3	IC18	A-2	IC78		RV518	C-3
D19	T-3	IC19	B-2	IC79		RV519	C-3
D20	M-3	IC20	C-2	Q1	K-4		
D21	G-2	IC21	D-2	Q2	J-5	TP1	T-4
D22	T-2	IC22	E-2	Q3	L-5	TP2	T-4
D23	S-1	IC23	F-2	Q4	R-3	TP3	T-6
D24	T-2	IC24	G-2	Q5	T-2	TP4	T-5
D25	M-4	IC25	H-2	Q6	P-5	TP5	R-2
D26	M-4	IC26	I-2	Q7	P-5	TP6	S-3
D27	O-4	IC27	K-2	Q8	P-5	TP7	Q-4
D28	O-4	IC28	L-2	Q9	P-5	TP8	R-4
D29	O-4	IC29	M-2	Q10	P-5	TP9	Q-4
D30	L-4	IC30	N-2	Q11	R-3	TP10	R-4
D31	N-4	IC31	P-2	Q12	L-4	TP11	Q-4
D32	L-4	IC32	Q-2	Q13	L-4	TP12	R-4
D33	M-2	IC33	R-2	Q14	L-4	TP13	Q-4
D34	M-2	IC34	S-2	Q15	L-4	TP14	T-5
D35	M-1	IC35	T-2	Q16	M-4	TP15	G-5
D36	M-1	IC36	A-3	Q17	K-4	TP16	H-3
D37	O-1	IC37	B-3	Q18	S-2	TP17	K-5
D38	O-2	IC38	D-3	Q19	S-2	TP18	M-5
D39	E-3	IC39	E-3	Q20	K-4	TP19	T-4
D40	C-3	IC40	F-3	Q21	L-4	TP20	T-2
D41	C-4	IC41	G-3	Q22	L-4	TP21	T-2
D42	C-4	IC42	H-3	Q23	Q-3	TP22	T-5
D43	B-4	IC43	J-3	Q24	F-4	TP23	L-3
D44	C-5	IC44	K-3	Q25	E-4	TP24	M-4
D45	C-5	IC45	L-3	Q26	E-4	TP25	M-4
D46	A-4	IC46	M-3	Q27	E-4	TP26	T-1
D47	G-2	IC47	N-3	Q28	E-4	TP27	T-2
D48	F-2	IC48	O-3	Q29	E-4	TP28	S-1
D49	H-3	IC49	R-3	Q30	E-4	TP29	L-1
D50	G-3	IC50	S-3	Q31	E-4	TP30	N-1
D51	F-3	IC51	T-3	Q32	E-4	TP31	N-1
D52	E-2	IC52	A-4	Q33	E-4	TP32	P-1
D53	A-4	IC53	B-4	Q34	E-4	TP33	F-5
D54	A-3	IC54	C-4	Q35	E-4	TP34	F-4
D55	S-5	IC55	D-4	Q36	E-4	TP35	F-4
E1	S-5	IC56	E-4	Q37	E-4	TP36	B-3
E2	N-4	IC57	F-4	Q38	E-4	TP37	C-5
E3	F-5	IC58	G-4	Q39	E-4	TP38	C-5
E4	H-2	IC59	H-4	Q40	E-4	TP39	G-3
		IC60	I-4	Q41	E-4	TP40	A-4
			J-4	Q42	E-4	TP41	F-4
			K-4	Q43	E-4	TP42	F-4
			L-4	Q44	E-4	TP43	F-4
			M-4	Q45	E-4	TP44	F-4
			N-4	Q46	E-4	TP45	F-4
			O-4	Q47	E-4	TP46	F-4
			P-4	Q48	E-4	TP47	F-4
			Q-4	Q49	E-4	TP48	F-4
			R-4	Q50	E-4	TP49	F-4
			S-4	Q51	E-4	TP50	F-4



DU-44 - SOLDERING SIDE-
1-610-458-11
BVW-10P


SV-51 (SERVO SYSTEM)

Ref. No.	Type	Pin No.					
		-15V	-5V	GND	+5V	+12V	+15V
IC 1	TC4081BP, MB84081B	7	14				
IC 2	TC4081BP, MB84081B	7	14				
IC 3	HD14538BP	8	16				
IC 4	TC4030BP	7	14				
IC 5	TC4089BP, MB84089B	7	14				
IC 6	TC4075BP	7	14				
IC 7	MSM4094RS	8	16				
IC 8	TC4021BP	7	14				
IC 9	TC4071BP	7	14				
IC 10	TC4030BP	7	14				
IC 11	TC4001BP, MB84001B	7	14				
IC 12	TC4053BP, MB84053B	8	16				
IC 13	TC4073BP	7	14				
IC 14	TC4516BP	8	16				
IC 15	TC4030BP	7	14				
IC 16	PC358C, LM358P	4	8				
IC 17	PC4558C, NJM4558D	8	16				
IC 18	TC4532BP	8	16				
IC 19	TC4532BP	8	16				
IC 20	TC4081BP, MB84081B	7	14				
IC 21	TC4073BP	7	14				
IC 22	TC4081BP, MB84081B	7	14				
IC 23	HD14538BP	8	16				
IC 24	TC4071BP	7	14				
IC 25	MSM4094RS	8	16				
IC 26	TC4049BP, MB84049B	8	16				
IC 27	TC4018BP, MB84018B	7	14				
IC 28	TC4053BP, MB84053B	8	16				
IC 29	TC4049BP, MB84049B	8	16				
IC 30	TC4049BP, MB84049B	8	16				
IC 31	TC4001BP, MB84001B	7	14				
IC 32	TC4516BP	8	16				
IC 33	TC4081BP, MB84081B	7	14				
IC 34	NJM2903D	4	8				
IC 35	NJM2903D	4	8				
IC 36	TC4081BP, MB84081B	8	16				
IC 37	TC4051BP, MB84051B	8	16				
IC 38	TC4053BP, MB84053B	8	16				
IC 39	HD14538BP	8	16				
IC 40	TC4030BP	7	14				
IC 41	TC4013BP, MB84013B	7	14				
IC 42	HD14538BP	8	16				
IC 43	TC4049BP, MB84049B	8	16				
IC 44	HD14538BP	8	16				
IC 45	TC4049BP, MB84049B	8	16				
IC 46	HD14538BP	8	16				
IC 47	TC4050BP	8	16				
IC 48	NJM2903D	4	8				
IC 49	TC4068BP	7	14				
IC 50	TC4049BP, MB84049B	8	16				
IC 51	BX3915A			Refer to Schematic			
IC 52	TC067BP	4	8				
IC 53	PC358C, LM358P	4	8				
IC 54	PC358C, LM358P	4	8				
IC 55	PC339C	12	3				
IC 56	TC4013BP, MB84013B	7	14				
IC 57	PC4558C, NJM4558D	4	8				
IC 58	PC4558C, NJM4558D	4	8				
IC 59	NJM4558D-D	4	8				
IC 60	CX194B			Refer to Schematic			
IC 61	NJM4558D-FA	4	8				
IC 62	BX1154			Refer to Schematic			
IC 63	BX1155			Refer to Schematic			
IC 64	PC339C	11					
IC 65	PC358C, LM358P	4	8				
IC 66	PC324C	11	4				
IC 67	NJM2903D	4	8				
IC 68	PC4558C, NJM4558D	4	8				
IC 69	PC4558C, NJM4558D	4	8				
IC 70	PC4558C, NJM4558D	4	8				
IC 71							
IC 72							
IC 73							
IC 74	TA78L005P, NJM78L05A			Refer to Schematic			
IC 75	PC4558C, NJM4558D	4	8				
IC 76	HD14538BP	8	16				
IC 77	HD14538BP	8	16				
IC 78	TC4053BP, MB84053B	8	16				
IC 79	TC4068BP	7	14				




1A ~ 30A ---- COMPONENT SIDE
1B ~ 30B ---- SOLDERING SIDE

1A ~ 30A ---- COMPONENT SIDE
1B ~ 30B ---- SOLDERING SIDE





D1	T-4	IC1	B-1	Q1	K-4	TP1	T-4
D2	R-4	IC2	C-1	Q2	J-5	TP2	T-4
D3	J-4	IC3	D-1	Q3	L-5	TP3	T-5
D4	J-4	IC4	E-1	Q4	R-3	TP4	T-5
D5	R-3	IC5	F-1	Q5	T-2	TP5	R-2
D6	K-5	IC6	G-1	Q6	P-5	TP6	S-3
D7	K-5	IC7	H-1	Q7	P-5	TP7	S-3
D8	M-5	IC8	J-1	Q8	P-5	TP8	S-3
D9	M-5	IC9	K-1	Q9	P-5	TP9	S-3
D10	P-5	IC10	L-1	Q10	P-5	TP10	Q-4
D11	T-4	IC11	M-1	Q11	R-3	TP11	Q-4
D12	T-4	IC12	N-1	Q12	L-4	TP12	R-4
D13	T-5	IC13	P-1	Q13	M-4	TP13	Q-4
D14	T-5	IC14	Q-1	Q14	K-4	TP14	T-5
D17	M-2	IC15	R-1	Q15	S-2	TP15	G-3
D18	M-1	IC16	S-1	Q16	S-2	TP16	H-3
D20	R-3	IC17	T-1	Q17	K-4	TP17	K-5
D21	T-3	IC18	A-2	Q18	S-2	TP18	M-5
D22	T-3	IC19	B-2	Q19	S-2	TP19	T-4
D23	M-3	IC20	C-2	Q20	F-4	TP20	T-2
D101	G-2	IC21	D-2	Q21	E-4	TP21	T-5
D201	T-2	IC22	E-2	Q22	C-4	TP22	L-3
D202	S-1	IC23	F-2	Q23	C-4	TP23	M-4
D203	T-2	IC24	G-2	Q24	E-4	TP24	N-3
D204	M-4	IC25	H-2	Q25	C-4	TP25	T-1
D208	Q-4	IC26	I-2	Q26	C-4	TP26	T-1
D209	Q-4	IC27	K-2	Q27	C-4	TP27	T-2
D210	Q-4	IC28	L-2	Q28	C-4	TP28	S-1
D211	L-4	IC29	M-2	Q29	C-4	TP29	S-2
D301	N-4	IC30	N-2	Q30	C-4	TP30	S-2
D302	L-4	IC31	P-2	Q31	C-4	TP31	S-2
D303	M-2	IC32	Q-2	Q32	C-4	TP32	S-2
D304	M-2	IC33	R-2	Q33	C-4	TP33	S-2
D305	M-1	IC34	S-2	Q34	C-4	TP34	S-2
D306	M-1	IC35	T-2	Q35	C-4	TP35	S-2
D307	Q-1	IC36	A-3	Q36	C-4	TP36	S-2
D308	Q-2	IC37	B-3	Q37	C-4	TP37	S-2
D309	E-3	IC38	D-3	Q38	C-4	TP38	S-2
D504	C-3	IC39	E-3	Q39	C-4	TP39	S-2
D505	C-4	IC40	F-3	Q40	C-4	TP40	S-2
D506	C-4	IC41	G-3	Q41	C-4	TP41	S-2
D507	B-4	IC42	H-3	Q42	C-4	TP42	S-2
D508	C-5	IC43	J-3	Q43	C-4	TP43	S-2
D509	C-5	IC44	K-3	Q44	C-4	TP44	S-2
D510	A-4	IC45	L-3	Q45	C-4	TP45	S-2
D511	G-2	IC46	M-3	Q46	C-4	TP46	S-2
D512	F-2	IC47	N-3	Q47	C-4	TP47	S-2
D513	H-3	IC48	Q-3	Q48	C-4	TP48	S-2
D514	G-3	IC49	R-3	Q49	C-4	TP49	S-2
D515	F-3	IC50	S-3	Q50	C-4	TP50	S-2
D516	E-2	IC51	T-3	Q51	C-4	TP51	S-2
D517	A-4	IC52	A-4	Q52	C-4	TP52	S-2
D518	A-3	IC53	B-4	Q53	C-4	TP53	S-2
E1	S-5	IC54	E-4	Q54	C-4	TP54	S-2
E2	N-4	IC55	G-4	Q55	C-4	TP55	S-2
E3	F-5	IC56	H-4	Q56	C-4	TP56	S-2
E4	H-2	IC57	J-4	Q57	C-4	TP57	S-2
		IC58	L-4	Q58	C-4	TP58	S-2
		IC59	N-4	Q59	C-4	TP59	S-2
		IC60	S-4	Q60	C-4	TP60	S-2
		IC61	B-5	Q61	C-4	TP61	S-2
		IC62	J-5	Q62	C-4	TP62	S-2
		IC63	L-5	Q63	C-4	TP63	S-2
		IC64	A-5	Q64	C-4	TP64	S-2
		IC65	B-5	Q65	C-4	TP65	S-2
		IC66	D-5	Q66	C-4	TP66	S-2
		IC67	E-5	Q67	C-4	TP67	S-2
		IC68	G-5	Q68	C-4	TP68	S-2
		IC69	H-5	Q69	C-4	TP69	S-2
		IC70	D-5	Q70	C-4	TP70	S-2
		IC71	H-4	Q71	C-4	TP71	S-2
		IC72	Q-5	Q72	C-4	TP72	S-2
		IC73	N-5	Q73	C-4	TP73	S-2
		IC74	Q-1	Q74	C-4	TP74	S-2
		IC75	P-2	Q75	C-4	TP75	S-2



(SERVO SYSTEM)

Type	Pin No.				
	-15V	-5V	GND	+5V	+15V
TC4081BP, MB84081B			7	14	
TC4081BP, MB84081B			7	14	
HI 3BP			8	16	
TC 3BP			7	14	
TC 3BP, MB84069UB			7	14	
TC 3BP			7	14	
MSM4094RS			8	16	
TC4021BP			8	16	
TC4071BP			7	14	
TC4030BP			7	14	
TC 3BP, MB84001B			7	14	
TC 3BP, MB84053B			8	16	
TC 3BP			7	14	
TC 3BP			8	16	
TC 3BP			7	14	
μPC358C, LM358P			4		8
μPC4558C, NJM4558D			4		8
TC4323BP			8	16	
TC 3BP			8	16	
TC 3BP, MB84081B			7	14	
TC 3BP			7	14	
TC 3BP, MB84081B			7	14	
HL 3BP			8	16	
TC4071BP			7	14	
MSM4094RS			8	16	
TC 3BP, MB84049UB			8	1	
TC 3BP, MB84001B			7	14	
TC 3BP, MB84053B			8	16	
TC 3BP, MB84049UB			8	1	
TC 3BP, MB84001B			7	14	
TC4516BP			8	16	
TC4081BP, MB84081B			7	14	
NJM2903D			4		8
NJM2903D			4		8
TC 3BP, MB84051B			8	16	
TC 3BP, MB84051B			8	16	
TC 3BP, MB84053B			8	16	
HI 3BP			8	16	
TC4030BP			7	14	
TC4013BP, MB84013B			7	14	
HD1453BP			8	16	
TC4049BP, MB84049UB			8	1	
HI 3BP			8	16	
TC 3BP, MB84049UB			8	1	
HI 3BP			8	16	
TC 3BP			8	16	
NJM2903D			4	8	
TC4069BP			7		14
TC4049BP, MB84049UB			8	1	
EX4015A			Refer to Schematic		
TI 7BP			8	16	
μI 3C, LM358P	4		4		8
μI 3C, LM358P			4	8	
μI 3C			12		3
TC4013BP, MB84013B			7	14	
μPC4558C, NJM4558D			4		8
μPC4558C, NJM4558D			4		8
NJM4558D-D			4		8
C 3B			Refer to Schematic		
N 5SD-FA	4		1	1	8
B 4			Refer to Schematic		
B 5			Refer to Schematic		
μPC339C		11			4
μPC358C, LM358P	4				8
μPC324C			11		4
N 103D			4	8	
μI 58C, NJM4558D			4		8
μI 58C, NJM4558D			4		8
TA78L005P, NJM78L05A			Refer to Schematic		
μPC4558C, NJM4558D	4			8	
HI 3BP			8	16	
HI 3BP			8	16	
T 3BP, MB84053B			8	16	
T 6BP			7	14	








D1	T-4	IC1	B-1	Q1	K-4	TP1	T-4
D2	R-4	IC2	C-1	Q2	J-5	TP2	T-4
D3	J-4	IC3	D-1	Q3	L-5	TP3	T-5
D4	J-4	IC4	E-1	Q4	R-3	TP4	T-5
D5	R-3	IC5	F-1	Q5	T-2	TP5	R-2
D6	K-5	IC6	G-1	Q6	P-5	TP6	S-3
D7	K-5	IC7	H-1	Q7	P-5	TP7	S-3
D8	M-5	IC8	J-1	Q8	P-5	TP8	R-4
D9	M-5	IC9	K-1	Q9	P-5	TP9	S-3
D10	P-5	IC10	L-1	Q10	P-5	TP10	S-3
D11	T-4	IC11	M-1	Q11	R-3	TP11	S-3
D12	T-4	IC12	N-1	Q12	L-4	TP12	R-4
D13	T-5	IC13	P-1	Q13	L-4	TP13	R-4
D14	T-5	IC14	Q-1	Q14	L-4	TP14	T-5
D15	M-2	IC15	R-1	Q15	L-4	TP15	G-3
D16	M-1	IC16	S-1	Q16	L-4	TP16	H-3
D17	M-2	IC17	T-1	Q17	L-4	TP17	K-5
D18	M-1	IC18	A-2	Q18	L-4	TP18	M-5
D19	R-3	IC19	B-2	Q19	L-4	TP19	T-2
D20	R-3	IC20	C-2	Q20	L-4	TP20	T-5
D21	T-3	IC21	D-2	Q21	L-4	TP21	L-3
D22	T-3	IC22	E-2	Q22	L-4	TP22	M-4
D23	M-3	IC23	F-2	Q23	L-4	TP23	N-3
D24	M-2	IC24	G-2	Q24	L-4	TP24	O-4
D25	M-4	IC25	H-2	Q25	L-4	TP25	P-4
D26	O-4	IC26	K-2	Q26	L-4	TP26	R-4
D27	O-4	IC27	L-2	Q27	L-4	TP27	S-3
D28	O-4	IC28	M-2	Q28	L-4	TP28	T-2
D29	O-4	IC29	N-2	Q29	L-4	TP29	T-2
D30	N-4	IC30	P-2	Q30	L-4	TP30	T-2
D31	N-4	IC31	Q-2	Q31	L-4	TP31	T-2
D32	L-4	IC32	R-2	Q32	L-4	TP32	T-2
D33	M-2	IC33	S-2	Q33	L-4	TP33	T-2
D34	M-2	IC34	T-2	Q34	L-4	TP34	T-2
D35	M-1	IC35	A-3	Q35	L-4	TP35	T-2
D36	M-1	IC36	B-3	Q36	L-4	TP36	T-2
D37	O-1	IC37	C-3	Q37	L-4	TP37	T-2
D38	O-2	IC38	D-3	Q38	L-4	TP38	T-2
D39	E-3	IC39	E-3	Q39	L-4	TP39	T-2
D40	C-3	IC40	F-3	Q40	L-4	TP40	T-2
D41	G-3	IC41	G-3	Q41	L-4	TP41	T-2
D42	H-3	IC42	H-3	Q42	L-4	TP42	T-2
D43	J-3	IC43	J-3	Q43	L-4	TP43	T-2
D44	K-3	IC44	K-3	Q44	L-4	TP44	T-2
D45	L-3	IC45	L-3	Q45	L-4	TP45	T-2
D46	M-3	IC46	M-3	Q46	L-4	TP46	T-2
D47	N-3	IC47	N-3	Q47	L-4	TP47	T-2
D48	O-3	IC48	O-3	Q48	L-4	TP48	T-2
D49	R-3	IC49	R-3	Q49	L-4	TP49	T-2
D50	S-3	IC50	S-3	Q50	L-4	TP50	T-2
D51	F-3	IC51	T-3	Q51	L-4	TP51	T-2
D52	E-2	IC52	A-4	Q52	L-4	TP52	T-2
D53	A-4	IC53	B-4	Q53	L-4	TP53	T-2
D54	A-3	IC54	E-4	Q54	L-4	TP54	T-2
D55	S-5	IC55	G-4	Q55	L-4	TP55	T-2
D56	N-4	IC56	J-4	Q56	L-4	TP56	T-2
D57	F-5	IC57	L-4	Q57	L-4	TP57	T-2
D58	H-2	IC58	N-4	Q58	L-4	TP58	T-2
E1	S-5	IC59	P-4	Q59	L-4	TP59	T-2
E2	N-4	IC60	S-4	Q60	L-4	TP60	T-2
E3	F-5	IC61	B-5	Q61	L-4	TP61	T-2
E4	H-2	IC62	J-5	Q62	L-4	TP62	T-2
		IC63	L-5	Q63	L-4	TP63	T-2
		IC64	A-5	Q64	L-4	TP64	T-2
		IC65	B-5	Q65	L-4	TP65	T-2
		IC66	D-5	Q66	L-4	TP66	T-2
		IC67	E-5	Q67	L-4	TP67	T-2
		IC68	G-5	Q68	L-4	TP68	T-2
		IC69	H-5	Q69	L-4	TP69	T-2
		IC70	D-5	Q70	L-4	TP70	T-2
		IC71	H-4	Q71	L-4	TP71	T-2
		IC72	O-5	Q72	L-4	TP72	T-2
		IC73	N-5	Q73	L-4	TP73	T-2
		IC74	Q-1	Q74	L-4	TP74	T-2
		IC75	P-2	Q75	L-4	TP75	T-2
		IC76		Q76	L-4	TP76	T-2
		IC77		Q77	L-4	TP77	T-2
		IC78		Q78	L-4	TP78	T-2
		IC79		Q79	L-4	TP79	T-2


SV-51 (SERVO SYSTEM)

Ref. No.	Type	Pin No.					
		-15V	-5V	GND	+5V	+12V	+15V
IC 1	TC4081BP, MB84081B		7	14			
IC 2	TC4081BP, MB84081B		7	14			
IC 3	HD14538BP		8	16			
IC 4	TC4080BP		7	14			
IC 5	TC4069UBP, MB84069UB		7	14			
IC 6	TC4075BP		7	14			
IC 7	MSM4054RS		8	16			
IC 8	TC4021BP		8	16			
IC 9	TC4071BP		7	14			
IC 10	TC4030BP		7	14			
IC 11	TC4001BP, MB84001B		7	14			
IC 12	TC4053BP, MB84053B		8	16			
IC 13	TC4073BP		7	14			
IC 14	TC4516BP		8	16			
IC 15	TC4030BP		7	14			
IC 16	PC358C, LM358P		4	8			
IC 17	PC4558C, NJM4558D		4	8			
IC 18	TC4532BP		8	16			
IC 19	TC4532BP		8	16			
IC 20	TC4081BP, MB84081B		7	14			
IC 21	TC4073BP		7	14			
IC 22	TC4081BP, MB84081B		7	14			
IC 23	HD14538BP		8	16			
IC 24	TC4071BP		7	14			
IC 25	MSM4054RS		8	16			
IC 26	TC4049BP, MB84049UB		8	1			
IC 27	TC4001BP, MB84001B		7	14			
IC 28	TC4053BP, MB84053B		8	16			
IC 29	TC4053BP, MB84053B		8	16			
IC 30	TC4049BP, MB84049UB		8	1			
IC 31	TC4001BP, MB84001B		7	14			
IC 32	TC4516BP		8	16			
IC 33	TC4081BP, MB84081B		7	14			
IC 34	NJM2903D		4	8			
IC 35	NJM2903D		4	8			
IC 36	TC4051BP, MB84051B		8	16			
IC 37	TC4051BP, MB84051B		8	16			
IC 38	TC4053BP, MB84053B		8	16			
IC 39	HD14538BP		8	16			
IC 40	TC4030BP		7	14			
IC 41	TC4013BP, MB84013B		7	14			
IC 42	HD14538BP		8	16			
IC 43	TC4049BP, MB84049UB		8	1			
IC 44	HD14538BP		8	16			
IC 45	TC4049BP, MB84049UB		8	1			
IC 46	HD14538BP		8	16			
IC 47	TC4050BP		8	1			
IC 48	NJM2903D		4	8			
IC 49	TC4066BP		7	14			
IC 50	TC4049BP, MB84049UB		8	1			
IC 51	BX3915A						
IC 52	TC5067BP						
IC 53	PC358C, LM358P		4	8			
IC 54	PC358C, LM358P		4	8			
IC 55	PC339C		12	3			
IC 56	TC4013BP, MB84013B		7	14			
IC 57	PC4558C, NJM4558D		4	8			
IC 58	PC4558C, NJM4558D		4	8			
IC 59	NJM4558D-D		4	8			
IC 60	CX194B						
IC 61	NJM4558D-FA						
IC 62	BX1154						
IC 63	BX1155						
IC 64							
IC 65	PC339C		11	4			
IC 66	PC358C, LM358P		4				
IC 67	PC324C		11	4			
IC 68	NJM2903D		4	8			
IC 69	PC4558C, NJM4558D		4	8			
IC 70	PC4558C, NJM4558D		4	8			
IC 71							
IC 72							
IC 73							
IC 74	TA78L005P, NJM78L05A						
IC 75	PC4558C, NJM4558D		4	8			
IC 76	HD14538BP		8	16			
IC 77	HD14538BP		8	16			
IC 78	TC4053BP, MB84053B		8	16			
IC 79	TC4066BP		7	14			








D1	T-4	IC1	B-1	Q1	K-4	TP1	T-4
D2	R-4	IC2	C-1	Q2	J-5	TP2	T-4
D3	J-4	IC3	D-1	Q3	L-5	TP3	T-5
D4	J-4	IC4	E-1	Q4	R-3	TP4	T-5
D5	R-3	IC5	F-1	Q5	T-2	TP5	R-2
D6	K-5	IC6	G-1	Q6	P-5	TP6	S-3
D7	K-5	IC7	H-1	Q7	P-5	TP10	Q-4
D8	M-5	IC8	J-1	Q10	P-5	TP12	R-4
D9	M-5	IC9	K-1	Q11	R-3	TP13	Q-4
D10	P-5	IC10	L-1	Q201	L-4	TP14	T-5
D11	T-4	IC11	M-1	Q202	L-4	TP15	G-3
D12	T-4	IC12	N-1	Q203	M-4	TP16	H-3
D13	T-5	IC13	P-1	Q204	K-4	TP17	K-5
D14	T-5	IC14	Q-1	Q205	S-2	TP18	M-5
D17	M-2	IC15	R-1	Q206	S-2	TP20	T-4
D18	M-1	IC16	S-1	Q207	K-4	TP21	T-2
D20	R-3	IC17	T-1	Q209	L-4	TP22	T-5
D21	T-3	IC18	A-2	Q301	Q-3	TP201	L-3
D22	T-3	IC19	B-2	Q502	F-4	TP202	M-4
D23	M-3	IC20	C-2	Q503	E-4	TP203	N-3
D101	G-2	IC21	D-2	Q505	C-4	TP205	T-1
D201	T-2	IC22	E-2	Q506	C-4	TP206	T-1
D202	S-1	IC23	F-2	Q507	C-5	TP207	T-2
D203	T-2	IC24	G-2	Q508	C-5	TP208	S-1
D204	M-4	IC25	H-2	Q509	D-2	TP209	S-2
D208	Q-4	IC27	K-2	Q510	E-4	TP210	L-1
D209	Q-4	IC28	L-2			TP211	L-1
D210	Q-4	IC29	M-2	RB101	H-1	TP212	R-2
D211	L-4	IC30	N-2	RB102	H-2	TP301	N-1
D301	N-4	IC31	P-2			TP302	P-1
D302	L-4	IC32	Q-2	RV1	T-4	TP501	F-5
D303	M-2	IC33	R-2	RV2	T-5	TP502	F-4
D304	M-2	IC34	S-2	RV3	R-4	TP503	F-4
D305	M-1	IC35	T-2	RV4	Q-5	TP504	H-4
D306	M-1	IC36	A-3	RV5	K-4	TP505	H-4
D307	Q-1	IC37	B-3	RV6	J-3	TP506	A-3
D308	Q-2	IC38	D-3	RV7	Q-5	TP507	B-3
D501	E-3	IC39	E-3	RV8	Q-5	TP508	F-5
D504	C-3	IC40	F-3	RV201	M-3	TP509	C-5
D505	C-4	IC41	G-3	RV202	N-3	TP510	G-3
D506	C-4	IC42	H-3	RV203	T-1	TP511	A-4
D507	B-4	IC43	J-3	RV204	S-2	TP512	F-4
D508	C-5	IC44	K-3	RV205	T-3	TP513	F-5
D509	C-5	IC45	L-3	RV206	R-2		
D510	A-4	IC46	M-3	RV501	E-4	X1	R-5
D511	G-2	IC47	N-3	RV502	E-4		
D512	F-2	IC48	O-3	RV503	D-4		
D513	H-3	IC49	R-3	RV504	D-4		
D514	G-3	IC50	S-3	RV505	F-5		
D515	F-3	IC51	T-3	RV506	G-5		
D516	E-2	IC52	A-4	RV507	H-5		
D517	A-4	IC53	B-4	RV508	H-5		
D518	A-3	IC54	E-4	RV509	A-2		
		IC55	G-4	RV510	A-3		
E1	S-5	IC56	J-4	RV511	A-3		
E2	N-4	IC57	L-4	RV513	C-3		
E3	F-5	IC58	N-4	RV515	C-3		
E4	H-2	IC59	P-4	RV516	C-3		
		IC60	S-4	RV517	C-3		
		IC61	B-5	RV519	C-3		
		IC62	J-5				
		IC63	L-5				
		IC65	A-5				
		IC66	B-5				
		IC67	D-5				
		IC68	E-5				
		IC69	G-5				
		IC70	H-5				
		IC74	D-5				
		IC75	H-4				
		IC76	Q-5				
		IC77	N-5				
		IC78	Q-1				
		IC79	P-2				




SV-51 (5/5) (SERVO SYSTEM)



Ref. No.	Type	Pin No.				
		-15V	-5V	GND	+5V	+15V
IC 1	TC4081BP, MB84081B			7	14	
IC 2	TC4081BP, MB84081B			7	14	
IC 3	HD14538BP			8	16	
IC 4	TC4030BP			7	14	
IC 5	TC4089UBP, MB84069UB			7	14	
IC 6	TC4075BP			7	14	
IC 7	MSM4094RS			8	16	
IC 8	TC4021BP			8	16	
IC 9	TC4071BP			7	14	
IC 10	TC4030BP			7	14	
IC 11	TC4001BP, MB84001B			7	14	
IC 12	TC4053BP, MB84053B			8	16	
IC 13	TC4073BP			7	14	
IC 14	TC4516BP			8	16	
IC 15	TC4030BP			7	14	
IC 16	μPC358C, LM358P			4		8
IC 17	μC4558C, NJM4558D			4		8
IC 18	TC4532BP			8	16	8
IC 19	TC4532BP			8	16	
IC 20	TC4081BP, MB84081B			7	14	
IC 21	TC4073BP			7	14	
IC 22	TC4081BP, MB84081B			7	14	
IC 23	HD14538BP			8	16	
IC 24	TC4071BP			7	14	
IC 25	MSM4094RS			8	16	
IC 26						
IC 27	TC4049BP, MB84049UB			8	1	
IC 28	TC4001BP, MB84001B			7	14	
IC 29	TC4053BP, MB84053B			8	16	
IC 30	TC4049BP, MB84049UB			8	1	
IC 31	TC4001BP, MB84001B			7	14	
IC 32	TC4516BP			8	16	
IC 33	TC4081BP, MB84081B			7	14	
IC 34	NJM2903D			4		8
IC 35	NJM2903D			4		8
IC 36	TC4051BP, MB84051B			8	16	
IC 37	TC4051BP, MB84051B			8	16	
IC 38	TC4053BP, MB84053B			8	16	
IC 39	HD14538BP			8	16	
IC 40	TC4030BP			7	14	
IC 41	TC4013BP, MB84013B			7	14	
IC 42	HD14538BP			8	16	
IC 43	TC4030BP, MB84040UB			8	1	
IC 44	HD14538BP			8	16	
IC 45	TC4049BP, MB84049UB			8	1	
C 46	HD14538BP			8	16	
C 47	TC4050BP			8	1	
C 48	NJM2903D			4		8
C 49	TC4068BP			8	1	14
IC 50	TC4049BP, MB84049UB			8	1	
IC 51	BX3915A			Refer to Schematic		
IC 52	TC5067BP			4	8	16
IC 53	μPC358C, LM358P			4		8
C 54	μPC358C, LM358P			4		8
C 55	μPC393C			12		3
C 56	TC4013BP, MB84013B			7	14	
C 57	μC4558C, NJM4558D			4		8
IC 58	μC4558C, NJM4558D			4		8
IC 59	NJM4558D-FA			8		8
IC 60	CX194B			Refer to Schematic		
C 61	NJM4558D-FA			4		8
C 62	BX1154			1		12
C 63	BX1155			Refer to Schematic		
C 64				Refer to Schematic		
C 65	μPC393C			11		4
IC 66	μPC358C, LM358P			4		8
IC 67	μPC324C			11		4
IC 68	NJM2903D			4	8	
IC 69	μC4558C, NJM4558D			4		8
C 70	μC4558C, NJM4558D			4		8
C 71						
C 72						
C 73						
IC 74	TA768L005P, NJM78L05A			Refer to Schematic		
IC 75	TC4055C, NJM4558D			4		8
IC 76	HD14538BP			8	16	
IC 77	HD14538BP			8	16	
IC 78	TC4053BP, MB84053B			8	16	
IC 79	TC4068BP			7	14	







D1	T-4	IC1	B-1	Q1	K-4	TP1	T-4
D2	R-4	IC2	C-1	Q2	J-5	TP2	T-4
D3	J-4	IC3	D-1	Q3	L-5	TP3	T-5
D4	J-4	IC4	E-1	Q4	R-3	TP4	T-5
D5	R-3	IC5	F-1	Q6	T-2	TP5	R-2
D6	K-5	IC6	G-1	Q8	P-5	TP9	S-3
D7	K-5	IC7	H-1	Q9	P-5	TP10	Q-4
D8	M-5	IC8	J-1	Q10	P-5	TP12	R-4
D9	M-5	IC9	K-1	Q11	R-3	TP13	Q-4
D10	P-5	IC10	L-1	Q201	L-4	TP14	T-5
D11	T-4	IC11	M-1	Q202	L-4	TP15	G-3
D12	T-4	IC12	N-1	Q203	M-4	TP16	H-3
D13	T-5	IC13	P-1	Q204	K-4	TP17	K-5
D14	T-5	IC14	Q-1	Q205	S-2	TP18	M-5
D17	M-2	IC15	R-1	Q206	S-2	TP20	T-4
D18	M-1	IC16	S-1	Q207	K-4	TP21	T-2
D20	R-3	IC17	T-1	Q209	L-4	TP22	T-5
D21	T-3	IC18	A-2	Q301	Q-3	TP201	L-3
D22	T-3	IC19	B-2	Q502	F-4	TP202	M-4
D23	M-3	IC20	C-2	Q503	E-4	TP203	N-3
D101	G-2	IC21	D-2	Q505	C-4	TP205	T-1
D201	T-2	IC22	E-2	Q506	C-4	TP206	T-1
D202	S-1	IC23	F-2	Q507	C-5	TP207	T-2
D203	T-2	IC24	G-2	Q508	C-5	TP208	S-1
D204	M-4	IC25	H-2	Q509	D-2	TP209	S-2
D208	Q-4	IC27	K-2	Q510	E-4	TP210	L-1
D209	Q-4	IC28	L-2			TP211	L-1
D210	Q-4	IC29	M-2	RB101	H-1	TP212	R-2
D211	L-4	IC30	N-2	RB102	H-2	TP301	N-1
D301	N-4	IC31	P-2			TP302	P-1
D302	L-4	IC32	Q-2	RV1	T-4	TP501	F-5
D303	M-2	IC33	R-2	RV2	T-5	TP502	F-4
D304	M-2	IC34	S-2	RV3	R-4	TP503	F-4
D305	M-1	IC35	T-2	RV4	Q-5	TP504	H-4
D306	M-1	IC36	A-3	RV5	K-4	TP505	H-4
D307	Q-1	IC37	B-3	RV6	J-3	TP506	A-3
D308	Q-2	IC38	D-3	RV7	Q-5	TP507	B-3
D501	E-3	IC39	E-3	RV8	Q-5	TP508	F-3
D504	C-3	IC40	F-3	RV201	M-3	TP509	C-5
D505	C-4	IC41	G-3	RV202	N-3	TP510	G-3
D506	C-4	IC42	H-3	RV203	T-1	TP511	A-4
D507	B-4	IC43	J-3	RV204	S-2	TP512	F-4
D508	C-5	IC44	K-3	RV205	T-3	TP513	F-5
D509	C-5	IC45	L-3	RV206	R-2		
D510	A-4	IC46	M-3	RV501	E-4		
D511	G-2	IC47	N-3	RV502	E-4		
D512	F-2	IC48	Q-3	RV503	D-4		
D513	H-3	IC49	R-3	RV504	D-4		
D514	G-3	IC50	S-3	RV505	F-5		
D515	F-3	IC51	T-3	RV506	G-5		
D516	E-2	IC52	A-4	RV507	H-5		
D517	A-4	IC53	B-4	RV508	H-5		
D518	A-3	IC54	E-4	RV509	A-2		
		IC55	G-4	RV510	A-3		
E1	S-5	IC56	J-4	RV511	A-3		
E2	N-4	IC57	L-4	RV512	C-3		
E3	F-5	IC58	N-4	RV515	C-3		
E4	H-2	IC59	P-4	RV516	C-3		
		IC60	S-4	RV517	C-3		
		IC61	B-5	RV519	C-3		
		IC62	J-5				
		IC63	L-5				
		IC65	A-5				
		IC66	B-5				
		IC67	D-5				
		IC68	E-5				
		IC69	G-5				
		IC70	H-5				
		IC74	D-5				
		IC75	H-4				
		IC76	Q-5				
		IC77	N-5				
		IC78	Q-1				
		IC79	P-2				

SY-91 (SYSTEM CONTROL)


Ref. No.	Type	Pin No.	
		GND	+5V
IC 1	TC40H240P	10	20
IC 2	TC40H240P	10	20
IC 3	TC40H244P	10	20
IC 4	TC40H244P	10	20
IC 5	TC40H240P	10	20
IC 6	TC40H244P	10	20
IC 7	TC40H244P	10	20
IC 8	TC40H244P	10	20
IC 9	TC40H244P	10	20
IC 10	TC40H244P	10	20
IC 11	TC40H138P	8	16
IC 12	LH0080	29	11
IC 13	TC40H245P	10	20
IC 14	TC40H244P	10	20
IC 15	TC40H244P	10	20
IC 16	TC40H138P	8	16
IC 17	TC40H032P	7	14
IC 18	TC40H004P	7	14
IC 19	TC40H032P	7	14
IC 20	TC40H139P	8	16
IC 21	TC40H368P	8	16
IC 22	TC4020BP	8	16
IC 23	TC40H074P	7	14
IC 24	TC40H368P	8	16
IC 25	TC40H273P	10	20
IC 26	TC40H273P	10	20
IC 27	TC40H273P	10	20
IC 28	TC40H273P	10	20
IC 29	TC40H273P	10	20
IC 30	TC40H273P	10	20
IC 31	TC40H273P	10	20
IC 32	TC40H273P	10	20
IC 33	TC40H138P	8	16
IC 34	TC40H244P	10	20
IC 35	TC40H138P	8	16
IC 36	MSM2128-1	12	24
IC 37			
IC 38	MBM2732-BW103	12	24
IC 39	MBM2732-BW102	12	24
IC 40			
IC 41	MBM2732-BW101	12	24
IC 42	LH0084	31	9
IC 43	LH0082	5	24
IC 44	LH0082	5	24
IC 45	TC40H011P	7	14
IC 46	TC4050BP	8	1
IC 47	TC4050BP	8	1
IC 48	M54529P	7	14
IC 49	SN74LS05N	7	14
IC 50	TC4021BP	8	16
IC 51	TC4021BP	8	16
IC 52	TC4021BP	8	16
IC 53	TC4021BP	8	16
IC 54	TC4050BP	8	1
IC 55	AM26LS32PC	8	16
IC 56	M54529P	7	14
IC 57	TC4011BP, MB84011B	7	14
IC 58	TC4071BP	7	14
IC 59	TC4081BP, MB84081B	7	14
IC 60			
IC 61	TC4081BP, MB84081B	7	14
IC 62	TC4069UBP, MB84069U	7	14
IC 63	HD14538BP	8	16
IC 64	TC4093BP	7	14
IC 65	MSM4094RS	8	16
IC 66	MSM4094RS	8	16
IC 67	MSM4094RS	8	16
IC 68	MSM4094RS	8	16
IC 69	μPD4584BC	7	14
IC 70	AM26LS32PC	8	16
IC 71	TC4001BP, MB84001B	7	14
IC 72	TC4081BP, MB84081B	7	14
IC 73	M54529P	7	14
IC 74	HD14538BP	8	16
IC 75	TC4081BP, MB84081B	7	14
IC 76	TC4050BP	8	1
IC 77	TC40H368P	8	16
IC 78	SN74LS37N	7	14
IC 79	M54529P	7	14
IC 80	TC4024BP	7	14







CN1	G-4	IC71	N-4
CN2	X-4	IC72	P-4
D1	AA-3	IC73	O-4
D2	AA-3	IC74	S-4
D3	K-3	IC75	T-4
D4	L-4	IC76	U-4
D5	C-3	IC77	X-4
		IC78	Z-4
		IC79	AB-4
		IC80	AB-4
IC1	A-1	RB1	H-1
IC2	B-1	RB2	H-1
IC3	C-1	RB3	K-1
IC4	D-1	RB4	N-1
IC5	E-1	RB5	P-1
IC6	F-1	RB6	K-2
IC7	G-1	RB7	D-3
IC8	H-1	RB8	L-3
IC9	J-1	RB9	N-3
IC10	K-1	RB10	A-4
IC11	L-1	RB11	A-4
IC12	M-1	RB12	K-4
IC13	N-1	RB13	P-4
IC14	P-1	RB14	W-4
IC15	O-1		
IC16	R-1		
IC17	S-1		
IC18	T-1	S1	L-1
IC19	U-1	S2	L-1
IC20	V-1	S3	K-1
IC21	X-1	S4	F-1
IC22	Y-1		
IC23	Z-1	RV1	W-3
IC24	AA-1		
IC25	A-2	TP1	V-1
IC26	B-2	TP2	V-1
IC27	C-2	TP3	W-1
IC28	D-2	TP4	W-1
IC29	E-2	TP5	W-1
IC30	F-2	TP6	W-1
IC31	G-2	TP7	W-1
IC32	H-2	TP8	W-1
IC33	J-2	TP9	X-1
IC34	K-2	TP10	X-1
IC35	L-2	TP11	X-1
IC36	N-2	TP12	Y-1
IC39	S-2	TP13	U-1
IC40	U-2	TPE	Y-1
IC41	V-2		
IC42	W-2	X1	AB-1
IC43	X-2		
IC44	Z-2		
IC45	AA-2		
IC46	A-3		
IC47	B-3		
IC48	C-3		
IC49	D-3		
IC50	E-3		
IC51	F-3		
IC52	G-3		
IC53	H-3		
IC54	J-3		
IC55	N-3		
IC56	P-3		
IC57	Q-3		
IC58	R-3		
IC59	S-3		
IC61	U-3		
IC62	V-3		
IC63	W-3		
IC64	Z-3		
IC65	D-4		
IC66	E-4		
IC67	F-4		
IC68	G-4		
IC69	H-4		
IC70	M-4		

(3) (SYSTEM CONTROL)







SY-91(1/3)
1-607-974-11,12,13
BVW-10
BVW-10P



CN1	G-4	IC71	N-4
CN2	X-4	IC72	P-4
D1	AA-3	IC73	Q-4
D2	AA-3	IC74	S-4
D3	K-3	IC75	T-4
D4	L-4	IC76	U-4
D5	C-3	IC77	X-4
		IC78	Z-4
		IC79	AB-4
		IC80	AB-4
IC1	A-1	RB1	H-1
IC2	B-1	RB2	H-1
IC3	C-1	RB3	K-1
IC4	D-1	RB4	N-1
IC5	E-1	RB5	P-1
IC6	F-1	RB6	K-2
IC7	G-1	RB7	D-3
IC8	H-1	RB8	L-3
IC9	J-1	RB9	N-3
IC10	K-1	RB10	A-4
IC11	L-1	RB11	A-4
IC12	M-1	RB12	K-4
IC13	N-1	RB13	P-4
IC14	P-1	RB14	W-4
IC15	Q-1		
IC16	R-1		
IC17	S-1		
IC18	T-1	S1	L-1
IC19	U-1	S2	L-1
IC20	V-1	S3	K-1
IC21	X-1	S4	F-1
IC22	Y-1		
IC23	Z-1		
IC24	AA-1	RV1	W-3
IC25	A-2	TP1	V-1
IC26	B-2	TP2	V-1
IC27	C-2	TP3	V-1
IC28	D-2	TP4	W-1
IC29	E-2	TP5	W-1
IC30	F-2	TP6	W-1
IC31	G-2	TP7	W-1
IC32	H-2	TP8	W-1
IC33	J-2	TP9	X-1
IC34	K-2	TP10	X-1
IC35	L-2	TP11	X-1
IC36	N-2	TP12	Y-1
IC39	S-2	TP13	U-1
IC40	U-2	TPE	Y-1
IC41	V-2		
IC42	W-2	X1	AB-1
IC43	X-2		
IC44	Z-2		
IC45	AA-2		
IC46	A-3		
IC47	B-3		
IC48	C-3		
IC49	D-3		
IC50	E-3		
IC51	F-3		
IC52	G-3		
IC53	H-3		
IC54	J-3		
IC55	N-3		
IC56	P-3		
IC57	Q-3		
IC58	R-3		
IC59	S-3		
IC61	U-3		
IC62	V-3		
IC63	W-3		
IC64	Z-3		
IC65	D-4		
IC66	E-4		
IC67	F-4		
IC68	G-4		
IC69	H-4		
IC70	M-4		







SY-91(2/3)
1-607-974-11,12,13
8VW-10
8VW-10P

SY-91 (SYSTEM CONTROL)


Ref. No.	Type	Pin No.	
		GND	+5V
IC 1	TC40H240P	10	20
IC 2	TC40H240P	10	20
IC 3	TC40H244P	10	20
IC 4	TC40H244P	10	20
IC 5	TC40H240P	10	20
IC 6	TC40H244P	10	20
IC 7	TC40H244P	10	20
IC 8	TC40H244P	10	20
IC 9	TC40H244P	10	20
IC 10	TC40H244P	10	20
IC 11	TC40H138P	8	16
IC 12	LH0080	29	11
IC 13	TC40H245P	10	20
IC 14	TC40H244P	10	20
IC 15	TC40H244P	10	20
IC 16	TC40H138P	8	16
IC 17	TC40H032P	7	14
IC 18	TC40H004P	7	14
IC 19	TC40H032P	7	14
IC 20	TC40H138P	8	16
IC 21	TC40H368P	8	16
IC 22	TC4020BP	8	16
IC 23	TC40H074P	7	14
IC 24	TC40H368P	8	16
IC 25	TC40H273P	10	20
IC 26	TC40H273P	10	20
IC 27	TC40H273P	10	20
IC 28	TC40H273P	10	20
IC 29	TC40H273P	10	20
IC 30	TC40H273P	10	20
IC 31	TC40H273P	10	20
IC 32	TC40H273P	10	20
IC 33	TC40H138P	8	16
IC 34	TC40H244P	10	20
IC 35	TC40H138P	8	16
IC 36	MSM2128-1	12	24
IC 37			
IC 38			
IC 39	MBM2732-BW103	12	24
IC 40	MBM2732-BW102	12	24
IC 41	MBM2732-BW101	12	24
IC 42	LH0084	31	9
IC 43	LH0082	5	24
IC 44	LH0082	5	24
IC 45	TC40H011P	7	14
IC 46	TC4050BP	8	1
IC 47	TC4050BP	8	1
IC 48	M54529P	7	14
IC 49	SN74LS05N	7	14
IC 50	TC4021BP	8	16
IC 51	TC4021BP	8	16
IC 52	TC4021BP	8	16
IC 53	TC4021BP	8	16
IC 54	TC4050BP	8	1
IC 55	AM26LS31PC	8	16
IC 56	M54529P	7	14
IC 57	TC4011BP, MB84011B	7	14
IC 58	TC4071BP	7	14
IC 59	TC4081BP, MB84081B	7	14
IC 60			
IC 61	TC4081BP, MB84081B	7	14
IC 62	TC4068UP, MB84069U	7	14
IC 63	HD14538BP	8	16
IC 64	TC4093BP	7	14
IC 65	MSM4094RS	8	16
IC 66	MSM4094RS	8	16
IC 67	MSM4094RS	8	16
IC 68	MSM4094RS	8	16
IC 69	μPD4584BC	7	14
IC 70	AM26LS32PC	8	16
IC 71	TC4001BP, MB84001B	7	14
IC 72	TC4081BP, MB84081B	7	14
IC 73	M54529P	7	14
IC 74	HD14538BP	8	16
IC 75	TC4081BP, MB84081B	7	14
IC 76	TC4050BP	8	1
IC 77	TC40H368P	8	16
IC 78	SN74LS37N	7	14
IC 79	M54529P	7	14
IC 80	TC4024BP	7	14






CN1	G-4	IC71	N-4
CN2	X-4	IC72	P-4
D1	AA-3	IC73	Q-4
D2	AA-3	IC74	S-4
D3	K-3	IC75	T-4
D4	L-4	IC76	U-4
D5	C-3	IC77	X-4
		IC78	Z-4
		IC79	AB-4
		IC80	AB-4
IC1	A-1	RB1	H-1
IC2	B-1	RB2	H-1
IC3	C-1	RB3	K-1
IC4	D-1	RB4	N-1
IC5	E-1	RB5	P-1
IC6	F-1	RB6	K-2
IC7	G-1	RB7	D-3
IC8	H-1	RB8	L-3
IC9	J-1	RB9	N-3
IC10	K-1	RB10	A-4
IC11	L-1	RB11	A-4
IC12	M-1	RB12	K-4
IC13	N-1	RB13	P-4
IC14	P-1	RB14	W-4
IC15	Q-1		
IC16	R-1		
IC17	S-1	S1	L-1
IC18	T-1	S2	L-1
IC19	U-1	S3	K-1
IC20	V-1	S4	F-1
IC21	X-1		
IC22	Y-1	RV1	W-3
IC23	Z-1		
IC24	AA-1	TP1	V-1
IC25	A-2	TP2	V-1
IC26	B-2	TP3	V-1
IC27	C-2	TP4	W-1
IC28	D-2	TP5	W-1
IC29	E-2	TP6	W-1
IC30	F-2	TP7	W-1
IC31	G-2	TP8	W-1
IC32	H-2	TP9	X-1
IC33	J-2	TP10	X-1
IC34	K-2	TP11	X-1
IC35	L-2	TP12	Y-1
IC36	N-2	TP13	U-1
IC39	S-2		
IC40	U-2		
IC41	V-2		
IC42	W-2	X1	AB-1
IC43	X-2		
IC44	Z-2		
IC45	AA-2		
IC46	A-3		
IC47	B-3		
IC48	C-3		
IC49	D-3		
IC50	E-3		
IC51	F-3		
IC52	G-3		
IC53	H-3		
IC54	J-3		
IC55	N-3		
IC56	P-3		
IC57	Q-3		
IC58	R-3		
IC59	S-3		
IC61	U-3		
IC62	V-3		
IC63	W-3		
IC64	Z-3		
IC65	D-4		
IC66	E-4		
IC67	F-4		
IC68	G-4		
IC69	H-4		
IC70	M-4		


SY-91 (3/3) (SYSTEM CONTROL)






SY-91(3/3)
1-607-974-11,12,13
BVW-10
BVW-10P

TC-25 (TIME CODE READER) (MOTOR DRIVER)






TC-25 (TIME CODE READER)
(MOTOR DRIVER)





D1	E-5	RB1	D-1
D100	A-6	RV101	B-3
D101	A-6	RV102	G-4
D103	A-3	RV103	C-3
D104	C-4	RV104	B-2
D105	B-4		
D200	E-1	S1	D-1
D201	E-1		
D202	E-1	TP1	F-3
D203	F-1	TP2	F-3
D204	F-1	TP3	C-2
D205	F-1	TP4	B-1
D206	G-1	TP5	D-3
D301	D-5	TP6	C-1
D302	D-5	TP7	D-3
D303	E-5	TP100	B-5
D304	D-5	TP101	A-6
D305	C-6	TP102	B-5
D306	C-6	TP103	G-3
D307	C-6	TP104	A-3
D308	C-6	TP105	B-1
D309	C-6	TP106	A-1
D310	C-6	TP301	D-5
D311	C-5	TP302	D-4
D312	C-5	TP303	D-3
E1	G-1	TP304	C-5
E2	E-5		
E3	B-1	Q1	D-1
E4	C-3	Q100	A-5
		Q101	A-5
		Q102	A-5
		Q103	B-4
		Q104	B-4
		Q105	B-5
		Q106	B-5
		Q107	B-3
		Q108	B-3
		Q109	A-3
		Q110	A-3
		X1	C-2
IC1	E-2		
IC2	G-4		
IC3	F-4		
IC4	E-4		
IC5	F-3		
IC6	G-3		
IC7	C-2		
IC8	G-2		
IC9	F-2		
IC10	E-5		
IC11	G-3		
IC12	G-5		
IC13	F-5		
IC100	B-6		
IC200	G-2		
IC201	G-5		
IC202	G-4		
IC203	B-2		
IC204	A-2		
IC205	A-1		
IC301	D-6		
IC302	D-4		
IC303	C-4		
IC304	C-5		
IC305	C-5		

**PS-16 (DC REGULATOR)
(TAPE/HUMID SENSOR)
(MOTOR/SOLENOID DRIVER)**



D1	A-5
D2	B-4
D3	B-5
D4	B-6
D5	A-6
D6	G-6
D7	G-6
D101	D-4
D102	D-5
D103	D-4
D104	D-4
E1	A-6
IC1	A-5
IC2	A-6
IC3	C-4
IC104	E-5
IC105	E-4
IC106	D-5
IC107	E-4
IC108	E-4
L101	B-8
L102	B-4
Q1	B-3
Q2	E-3
Q3	C-3
Q4	B-6
Q5	F-2
Q6	G-5
Q7	E-2
Q8	F-6
Q9	G-3
Q10	C-2
Q11	F-4
Q12	B-2
Q13	F-4
Q14	F-4
Q15	A-5
RV1	C-5
RV2	C-4
RV3	A-4
RV101	A-6
RV102	A-4
TP1	A-6
TP2	A-4
TP3	B-6
TP4	G-6
TP5	G-6
TP6	F-6
TP101	C-3
TP102	B-5

PS-16 (DC REGULATOR)
(TAPE/HUMID SENSOR)
(MOTOR/SOLENOID DRIVER)



REF NO.	TYPE	UNREG +15V	+12V	-12V	UNREG GND	GND
IC 1	μPC358C			4		8
IC 2	μPC358C		8			4
IC 101	BX343		13			7
IC 102	BX342		1,10			4
IC 103	BX342		1,10			4
IC 104	M54523P	1, 8			4, 5, 12, 13	
IC 105	TC4049BP		1			8
IC 106	TC4049BP		1			8
IC 107	M54523P		9			8
IC 108	M54523P	9			8	

PS-16
1-608-712-12
BVW-10
BYW-10P




CP-52 (FRONT PANEL)

SW-85


VR-8

HP-7

LA-4

**LA-4** - SOLDERING SIDE-1-608-057-11
BVW-10
BVW-10P**SW-85** - SOLDERING SIDE-1-608-050-11
BVW-10
BVW-10P

CP-52 (FRONT PANEL)




CP-52
BVW-10
BVW-10P(1)


CP-56 (REAR PANEL)
SW-86

CP-56, SW-86

CP-56, SW-86





CP-56 - SOLDERING SIDE -
1-608-581-11,12
BVW-10
BVW-10P



SW-86
-SOLDERING SIDE-
1-608-064-12
BVW-10
BVW-10P


CP-56 (REAR PANEL)






ST-22 - SOLDERING SIDE -
1-608-067-13,14
BVW-10P


ST-22 (SUB CONTROL PANEL)



KY-32 (KEY PANEL)
DP-30 (TIME COUNTER DISPLAY)




DP-30 - COMPONENT SIDE -
1-607-973-11
BVW-10
BVW-10P





D1	G-3	IC1	G-3	Q1	B-2	S1	F-3
D2	G-3	IC2	G-3	Q2	B-1	S2	F-1
D3	G-3	IC3	F-3	Q3	C-1	S3	F-3
D4	G-3	IC4	F-2	Q4	B-1	S4	E-3
D5	G-3	IC5	F-2	Q5	C-1	S5	D-3
D6	G-3	IC6	E-3	Q6	B-1	S6	C-3
D7	G-3	IC7	F-2	Q7	B-1	S7	B-3
D8	G-3	IC8	F-1	Q8	B-1	S8	C-1
D9	G-3	IC9	E-2				
D10	G-3	IC10	E-1	RB1	G-2	TP1	F-1
D11	F-3	IC11	E-2	RB2	G-2	TP2	E-1
D12	B-2	IC12	E-1	RB3	E-1	TP3	F-1
D13	B-2	IC13	D-1	RB4	C-1	TP4	E-3
D14	A-1	IC14	D-3			TP5	F-1
D15	F-3	IC15	D-2				
		IC16	D-1				
E1	E-2	IC17	D-2				
		IC18	D-1				
		IC19	C-3				

KY-32 - SOLDERING SIDE -
1-607-972-12
BVW-10
BVW-10P


KY-32 (KEY PANEL)




PC-9 (SEARCH DIAL)
PC-14



RE-6 (REMOTE CONNECTOR PANEL)



RE-6 - SOLDERING SIDE-
1-608-063-12
BVW-10
BVW-10P



DE-12, DE-11, SS-8


DE-12
1-607-971-11

DE-12 -SOLDERING SIDE-
1-607-971-11
BW-10
BVW-10P



SS-8 -SOLDERING SIDE-


1-586-946-12
 BVW-10
 BVW-10P




HE-5
PH-16
LE-19
SS-8

HE-5, PH-16, LE-19, SS-8


HE-5, PH-16, LE-19, SS-8




HE-5 -SOLDERING SIDE-
1-608-056-11,12
BVW-10
BVW-10P




LE-19 -SOLDERING SIDE-
1-608-053-11
BVW-10
BVW-10P




PH-16 -SOLDERING SIDE-
1-608-054-11
BVW-10
BVW-10P




SS-8 -SOLDERING SIDE-
1-586-946-12
BVW-10
BVW-10P




CL-7 (CASSETTE UP COMPARTMENT)
 PC-17
 PC-18




CL-7 - COMPONENT SIDE -
 1-608-052-11
 BVW-10
 BVW-10P





PC-17 - SOLDERING SIDE -
 1-608-070-12
 BVW-10
 BVW-10P





PC-18 - SOLDERING SIDE -
 1-608-071-12
 BVW-10
 BVW-10P










LM-4 -SOLDERING SIDE-
1-585-913-11
BVW-10
BVW-10P






PD-20 -SOLDERING SIDE-
1-608-069-11
BVW-10
BVW-10P





TR-14-SOLDERING SIDE-
1-608-055-11, 12, 13
BVW-10
BVW-10P

TE-2






TR-14



18-185




18-186




TR-14-SOLDERING SIDE-


1-608-055-11, 12, 13
BVW-10
BVW-10P



AC-40-SOLDERING SIDE-
1-607-968-11,12,13
BVW-10
BVW-10P




















NOTE: The shaded and ⚠-marked components are critical to safety.
Replace only with same components as specified.



PR-48


MY-17


CK-14



MB-41


1-608-579-12,13
BW-10
BW-10P






MB-41 -SOLDERING SIDE-
1-608-579-12,13
BVW-10
BVW-10P

MB-42 (MOTHER BOARD)




MB-42 - SOLDERING SIDE -
1-608-580-12,13
BVW-10
BVW-10P

MB-42 (MOTHER BOARD)



MB-42 - SOLDERING SIDE -
1-608-580-12, 13
BVW-10
BVW-10P

MB-42 (MOTHER BOARD)



CD-25

A		CN4		B	
		1	GND		
		2			
		3	+15V IN		□ +15V
		4	+12V IN		△ +12V
		5	+5V IN		○ +5V
		6			
R-Y/B-Y OUT (X)	7	DEM0D'ED R-Y/B-Y OUT (X)		5-7B	
R-Y/B-Y OUT (G)	8	DEM0D'ED R-Y/B-Y OUT (G)		5-8B	
	9				
DET PULSE OUT (X)	10	C-DROPOUT DET PULSE OUT (X)		214-3	
DET PULSE OUT (G)	11	C-DROPOUT DET PULSE OUT (G)		214-4	
	12	DUB R-Y/B-Y OUT (X)		MB-41, 6-21B	
OUT	13	DUB R-Y/B-Y OUT (G)		MB-41, 6-20B	
	14				
CONTROL IN	15				
	16	C-SW'ING PULSE IN		210-10	
FWD IN	17				
	18				
RF CH-A IN (G)	19	GND			
RF CH-A IN (Y)	20	GND			
RF CH-A IN (X)	21	GND			
RF CH-B IN (G)	22	GND			
RF CH-B IN (Y)	23	GND			
RF CH-B IN (X)	24	GND			
	25	GND			
	26				
	27	-12V IN		▲ -12V	
	28	-15V IN		■ -15V	
	29				
	30	GND			

CF-12

A		CN5		B	
		1	GND		
		2			
		3	+15V IN		□ +15V
		4	+12V IN		△ +12V
		5	+5V IN		○ +5V
		6			
214-1	DEM0D'ED R-Y/B-Y OUT (X)	7	DEM0D'ED R-Y/B-Y IN (X)	4-7A	4-7B
214-2	DEM0D'ED R-Y/B-Y OUT (G)	8	DEM0D'ED R-Y/B-Y IN (G)	4-8A	4-8B
		9	DELAY'ED TDM C OUT (X)	MB-41, 8-23A	
		10	DELAY'ED TDM C OUT (G)	MB-41, 8-24A	
		11			
		12			
		13			
		14			
		15			
		16			
3-17A	210-1	L; NORMAL FWD IN			
4-17A					
		18			
		19			
		20			
		21			
		22			
214-6	R-Y/B-Y OUT (X)	23	R-Y/B-Y OUT (X)	214-6	
214-5	R-Y/B-Y OUT (G)	24	R-Y/B-Y OUT (G)	214-5	
		25			
		26	REG -11V IN		▲ -11V
		27	-12V IN		▲ -12V
		28	-15V IN		■ -15V
		29			
		30	GND		

TC-25


A		CN6		B	
		1	GND		
		2			
		3	+15V IN		□ +15V
		4	+12V IN		△ +12V
		5	+5V IN		○ +5V
		6			
210-50	TIME CODE DATA 0 OUT	7	TIME CODE DATA 1 OUT	210-49	
210-48	TIME CODE DATA 2 OUT	8	TIME CODE DATA 3 OUT	210-47	
210-45	TIME CODE DATA 4 OUT	9	TIME CODE DATA 5 OUT	210-44	
210-43	TIME CODE DATA 6 OUT	10	TIME CODE DATA 7 OUT	210-41	
210-40	TIME CODE ADDRESS 0 IN	11	TIME CODE ADDRESS 1 IN	210-39	
210-37	TIME CODE ADDRESS 2 IN	12	TIME CODE ADDRESS 3 IN	210-36	
210-35	TC DATA OUTPUT SELECT OUT	13	H; TC BUSY OUT	210-33	
210-3	EDIT CTL IN	14	TAPE ROLL PULSE IN	210-4	
210-7	TAPE DIRECTION (F/R) IN	15	PB TIME CODE OUT (X)	211-2	
		16	PB TIME CODE OUT (G)	211-3	
		17			
213-4	THREADING MOTOR (-)	18	H; THREADING IN	210-25	
213-3	THREADING MOTOR (+)	19	H; UNTHREADING IN	210-22	
213-2	CASSETTE UP MOTOR (+)	20	H; CASSETTE DOWN IN	210-30	
213-1	CASSETTE UP MOTOR (-)	21	H; CASSETTE UP IN	210-28	
UNREG	UNREG GND	22	UNREG GND	UNREG	
223-3	TIME CODE HEAD (X)	24	TIME CODE HEAD (Y)	223-2	
223-1	TIME CODE HEAD (G)	25			
		26			
		27	-12V IN		▲ -12V
		28	-15V IN		■ -15V
		29			
		30	GND		

MB-42


1-608-580-12,13
BVW-10
BVW-10P


A		CN4		B	
1	DEM0D'ED R-Y/B-Y OUT (G)	5-8A		4-10B	
2	DEM0D'ED R-Y/B-Y OUT (X)	4-10A		4-11B	
3	C-DROPOUT DET PULSE OUT (X)	5-24A		5-24B	
4	C-DROPOUT DET PULSE OUT (G)	5-23A		5-23B	
5	R-Y/B-Y OUT (X)	3-11A		3-11B	
6	R-Y/B-Y OUT (G)	3-10A		3-10B	
7	Y-DROPOUT DET PULSE OUT (X)	3-9A		3-9B	
8	Y-DROPOUT DET PULSE OUT (G)	3-7A		3-7B	
9	DEM0D'ED Y OUT (G)				
10	DEM0D'ED Y OUT (X)				
CN215					
1	CH-1 HEADPHONES OUT (G)	2-11A			
2	CH-1 HEADPHONES OUT (X)	2-10A			
3	CH-2 HEADPHONES OUT (G)	2-16A			
4	CH-2 HEADPHONES OUT (X)	2-15A			
5	AUDIO CH-2 METER OUT	2-18B			
6	AUDIO CH-1 METER OUT	2-18B			
7	MONITOR IN (G)	2-14B			
8	MONITOR IN (X)	2-13B			
9	GND				
10	-15V OUT				■ -15V
11	+12V OUT				△ +12V
12	+5V OUT				○ +5V
CN216					
1	CH-1 PB LEVEL CONTROL (X)	2-12A			
2	CH-1 PB LEVEL CONTROL (Y)	2-13A			
3	CH-1 PB LEVEL CONTROL (G)	2-14A			
4	CH-2 PB LEVEL CONTROL (X)	2-17A			
5	CH-2 PB LEVEL CONTROL (Y)	2-18A			
6	CH-2 PB LEVEL CONTROL (G)	2-19A			
CN217					
1	TAPE END SENSOR (X)	1-26A			
2	TAPE END SENSOR (G)	1-25A			
3	TAPE BEGINNING SENSOR (X)	1-26B			
4	TAPE BEGINNING SENSOR (G)	1-25B			
5	L; HEATER ON OUT	1-23B			
6	+15V OUT				□ +15V
7	+12V OUT				△ +12V
8	GND				
CN218					
1	T-BRAKE SOL. STARTER	1-17B			
2	MAIN SOL. STARTER	1-16B			
3	PINCH SOL. STARTER	1-15B			
4	S-BRAKE SOL. HOLDER	1-22B			
5	T-BRAKE SOL. HOLDER	1-21B			
6	MAIN SOL. HOLDER	1-20B			
7	PINCH SOL. HOLDER	1-19B			
8	+15V OUT				□ +15V
9	+12V OUT				△ +12V
10	+15V OUT				□ +15V
11	+12V OUT				△ +12V
12	S-BRAKE SOL. STARTER	1-18B			
CN219					
1	GND				
2	S-REEL MOTOR (+) OUT	1-14A			
3	S-REEL MOTOR (-) OUT	1-13A			
4	GND				
5	T-REEL MOTOR (+) OUT	1-12A			
6	T-REEL MOTOR (-) OUT	1-11A			
CN220					
1	CH-2 AUDIO HEAD (X)	2-25A			
2	CH-2 AUDIO HEAD (Y)	2-24A			
3	CH-2 AUDIO HEAD (G)	2-23A			
4	CH-1 AUDIO HEAD (X)	2-22A			
5	CH-1 AUDIO HEAD (Y)	2-21A			
6	CH-1 AUDIO HEAD (G)	2-20A			
CN221					
1	Y RF CH-B IN (X)	3-24A			
2	Y RF CH-B IN (Y)	3-23A			
3	Y RF CH-B IN (G)	3-22A			
4	Y RF CH-A IN (X)	3-21A			
5	Y RF CH-A IN (Y)	3-20A			
6	Y RF CH-A IN (G)	3-19A			
CN222					
1	R-Y/B-Y RF CH-B IN (X)	4-24A			
2	R-Y/B-Y RF CH-B IN (Y)	4-23A			
3	R-Y/B-Y RF CH-B IN (G)	4-22A			
4	R-Y/B-Y RF CH-A IN (X)	4-21A			
5	R-Y/B-Y RF CH-A IN (Y)	4-20A			
6	R-Y/B-Y RF CH-A IN (G)	4-19A			
CN223					
1	TIME CODE HEAD (G)	6-25A			
2	TIME CODE HEAD (Y)	6-24B			
3	TIME CODE HEAD (X)	6-24A			

FRAME (1/2) FRAME (1/2)



WIRING (2/2)





SECTION 19

SPARE PARTS AND FIXTURE

19-1. PARTS INFORMATION

1. Safety Related Component Warning

Components identified by shading marked with **Δ** on the schematic diagrams, exploded views and electrical spare parts list are critical to safe operation. Replace these components with Sony parts whose parts numbers appear as shown in this manual or in service bulletins and service manual supplements published by Sony.

2. Replacement Parts supplied from Sony Parts Center will sometimes have different shape and outside view from the parts which actually in use. This is due to "accommodating the improved parts and/or engineering changes" or "standardization of genuine parts".

- This manual's exploded views and electrical spare parts lists are indicating the parts numbers of "the standardized genuine parts at present".
- Regarding engineering parts changes in our engineering department, refer Sony service bulletins and service manual supplements.

3. Printed Components in Bold-Face type on the exploded views and electrical spare parts list are normally stocked for replacement purposes. The remaining parts are not normally required for routine service work. Orders for parts not shown in Bold-Face type will be processed, but allow for additional delivery time.

4. Item with no part number and/or no description are not stocked because they are seldom required for routine service.

5. (T) after a spring description is shown on the exploded views in order to indicate the number of a spring turn required for the use.

(Example) Spring, tension (24T); This spring must be cut at its 24th turn for actual use.

19-2. EXPLODED VIEW



- Exploded views are composed of the following blocks.

- (1) Take-up Side Reel Chassis
take-up reel table
take-up side brake
reel motor
tape beginning sensor
- (2) Supply Side Reel Chassis
supply reel table
supply side brake
reel motor

- (3) Head Drum, Stationary Heads and Tape Guides Block
head drum ass'y
CTL/full erase heads
audio/TC heads
tape guide
capstan motor
- (4) Threading Ring Block
threading ring
- (5) Pinch Press Mechanism Block
pinch press mechanism
- (6) Supply Tension Regulator Block
supply tension regulator
- (7) Gear Box Block
gear box
- (8) Level Control Chassis Block
level control chassis
- (9) Function Control Chassis Block
function control chassis
search dial
hinge
- (10) Connector Panel Block
connector panel
ventilation fan
- (11) TBC Control Block
TBC control block
hours meter
- (12) Chassis Block (1)
mother board
- (13) Switching Regulator Block
- (14) Cassette-up Compartment Block
cassette-up compartment
- (15) Ornamental Panel Block (1)
function control panel
level control panel
- (16) Ornamental Panel Block (2)
side panel
top panel
- (17) Printed Circuit Board Block (1)
printed circuit board
- (18) Printed Circuit Board Block (2)
shield case
heat sink
- (19) Extension Board Block
extension board

SCREW

SECTION 18 SPARE PARTS AND FIXTURE

	HEXAGON SOCKET SCREW	HEXAGON SET SCREW	(-) SET SCREW FLAT POINT	(-) SET SCREW CONE POINT
				
2.6 x 3	—	7-621-734-09	—	—
2.6 x 4	7-621-996-24	7-621-735-09	—	—
2.6 x 5	—	7-621-736-09	—	—
2.6 x 6	7-683-412-05	—	—	7-621-712-55
2.6 x 8	7-683-413-05	—	—	7-621-712-65
2.6 x 10	—	—	—	7-621-712-75
3 x 4	—	7-683-238-01	—	—
3 x 5	—	—	7-683-175-01	—
3 x 6	7-683-403-04	—	7-683-176-01	7-683-176-21
3 x 8	7-683-404-04	—	—	7-683-177-21
3 x 10	7-683-405-04	—	—	7-683-178-21
3 x 12	—	—	—	7-683-179-21

EXPLODED VIEW

- 1. Take-up Side Wheel (100)
- 2. Take-up Side Wheel (100)
- 3. Take-up Side Wheel (100)
- 4. Take-up Side Wheel (100)
- 5. Take-up Side Wheel (100)
- 6. Take-up Side Wheel (100)
- 7. Take-up Side Wheel (100)
- 8. Take-up Side Wheel (100)
- 9. Take-up Side Wheel (100)
- 10. Take-up Side Wheel (100)
- 11. Take-up Side Wheel (100)
- 12. Take-up Side Wheel (100)
- 13. Take-up Side Wheel (100)
- 14. Take-up Side Wheel (100)
- 15. Take-up Side Wheel (100)
- 16. Take-up Side Wheel (100)
- 17. Take-up Side Wheel (100)
- 18. Take-up Side Wheel (100)
- 19. Take-up Side Wheel (100)
- 20. Take-up Side Wheel (100)
- 21. Take-up Side Wheel (100)
- 22. Take-up Side Wheel (100)
- 23. Take-up Side Wheel (100)
- 24. Take-up Side Wheel (100)
- 25. Take-up Side Wheel (100)
- 26. Take-up Side Wheel (100)
- 27. Take-up Side Wheel (100)
- 28. Take-up Side Wheel (100)
- 29. Take-up Side Wheel (100)
- 30. Take-up Side Wheel (100)
- 31. Take-up Side Wheel (100)
- 32. Take-up Side Wheel (100)
- 33. Take-up Side Wheel (100)
- 34. Take-up Side Wheel (100)
- 35. Take-up Side Wheel (100)
- 36. Take-up Side Wheel (100)
- 37. Take-up Side Wheel (100)
- 38. Take-up Side Wheel (100)
- 39. Take-up Side Wheel (100)
- 40. Take-up Side Wheel (100)
- 41. Take-up Side Wheel (100)
- 42. Take-up Side Wheel (100)
- 43. Take-up Side Wheel (100)
- 44. Take-up Side Wheel (100)
- 45. Take-up Side Wheel (100)
- 46. Take-up Side Wheel (100)
- 47. Take-up Side Wheel (100)
- 48. Take-up Side Wheel (100)
- 49. Take-up Side Wheel (100)
- 50. Take-up Side Wheel (100)
- 51. Take-up Side Wheel (100)
- 52. Take-up Side Wheel (100)
- 53. Take-up Side Wheel (100)
- 54. Take-up Side Wheel (100)
- 55. Take-up Side Wheel (100)
- 56. Take-up Side Wheel (100)
- 57. Take-up Side Wheel (100)
- 58. Take-up Side Wheel (100)
- 59. Take-up Side Wheel (100)
- 60. Take-up Side Wheel (100)
- 61. Take-up Side Wheel (100)
- 62. Take-up Side Wheel (100)
- 63. Take-up Side Wheel (100)
- 64. Take-up Side Wheel (100)
- 65. Take-up Side Wheel (100)
- 66. Take-up Side Wheel (100)
- 67. Take-up Side Wheel (100)
- 68. Take-up Side Wheel (100)
- 69. Take-up Side Wheel (100)
- 70. Take-up Side Wheel (100)
- 71. Take-up Side Wheel (100)
- 72. Take-up Side Wheel (100)
- 73. Take-up Side Wheel (100)
- 74. Take-up Side Wheel (100)
- 75. Take-up Side Wheel (100)
- 76. Take-up Side Wheel (100)
- 77. Take-up Side Wheel (100)
- 78. Take-up Side Wheel (100)
- 79. Take-up Side Wheel (100)
- 80. Take-up Side Wheel (100)
- 81. Take-up Side Wheel (100)
- 82. Take-up Side Wheel (100)
- 83. Take-up Side Wheel (100)
- 84. Take-up Side Wheel (100)
- 85. Take-up Side Wheel (100)
- 86. Take-up Side Wheel (100)
- 87. Take-up Side Wheel (100)
- 88. Take-up Side Wheel (100)
- 89. Take-up Side Wheel (100)
- 90. Take-up Side Wheel (100)
- 91. Take-up Side Wheel (100)
- 92. Take-up Side Wheel (100)
- 93. Take-up Side Wheel (100)
- 94. Take-up Side Wheel (100)
- 95. Take-up Side Wheel (100)
- 96. Take-up Side Wheel (100)
- 97. Take-up Side Wheel (100)
- 98. Take-up Side Wheel (100)
- 99. Take-up Side Wheel (100)
- 100. Take-up Side Wheel (100)

SCREW

	PS 	PSW 	B (BZn-N) 	B (Cr-N) 	PTT 	PTTWH 
2.6 x 4	7-621-972-05	—	7-621-912-10	7-621-912-18	—	7-687-508-31
2.6 x 6	7-621-972-25	7-621-981-15	7-621-912-30	7-621-912-38	—	7-687-501-31
2.6 x 8	7-621-972-35	7-621-981-25	7-621-912-40	7-621-912-48	—	7-687-502-31
2.6 x 10	7-621-972-45	7-621-981-35	7-621-912-50	7-621-912-58	—	7-687-503-31
2.6 x 12	7-621-972-55	7-621-981-45	7-621-912-60	7-621-912-68	—	7-687-504-31
2.6 x 14	7-621-972-65	7-621-981-55	7-621-912-70	7-621-912-78	—	7-687-505-31
2.6 x 16	7-621-972-75	7-621-981-65	7-621-912-80	7-621-912-88	—	7-687-506-31
2.6 x 20	7-621-972-85	7-621-981-75	7-621-912-90	7-621-912-98	—	7-687-507-31
3 x 5	7-686-446-01	—	—	—	—	—
3 x 6	7-686-447-01	7-686-527-01	7-686-624-09	7-686-624-04	7-687-411-31	7-687-510-31
3 x 8	7-686-448-01	7-686-528-01	7-686-625-09	7-686-625-04	7-687-412-31	7-687-511-31
3 x 10	7-686-449-01	7-686-529-01	7-686-626-09	7-686-626-04	7-687-413-31	7-687-512-31
3 x 12	7-686-450-01	7-686-530-01	7-686-627-09	7-686-627-04	7-687-414-31	7-687-513-31
3 x 16	7-686-452-01	7-686-532-01	7-686-629-09	7-686-629-04	—	—
3 x 20	7-686-453-01	7-686-533-01	7-686-630-09	7-686-630-04	—	—
3 x 25	7-686-454-01	7-686-534-01	7-686-631-09	7-686-631-04	—	—
4 x 8	7-686-468-01	7-686-548-01	7-686-635-09	7-686-635-04	—	—
4 x 12	7-686-470-01	7-686-550-01	7-686-637-09	7-686-637-04	—	—
4 x 14	7-686-471-01	—	7-686-638-09	7-686-638-04	—	—
4 x 16	7-686-472-01	—	7-686-639-09	7-686-639-04	—	—
4 x 20	7-686-473-01	—	7-686-640-09	7-686-640-04	—	—

WASHER


	FLAT WASHER SMALL W. 	FLAT WASHER MIDDLE W. 	SPRING WASHER SW. 	TOOTHED WASHER TYPE B LW. 	HEXAGON NUT N. 
2.6 mm	7-688-002-01	7-688-002-12	7-623-207-22	7-623-421-07	7-622-207-05
3 mm	7-688-003-01	7-688-003-12	7-688-003-11	7-623-422-07	7-684-023-04
4 mm	7-688-004-01	7-688-004-12	7-623-210-22	7-623-423-07	7-684-024-04
5 mm	7-688-005-01	7-688-005-01	7-623-212-22	—	7-684-025-04

	STOP RING E TYPE E. 
2	7-624-104-04
2.3	7-624-105-04
3	7-624-106-04
4	7-624-108-04
5	7-624-109-04
6	7-624-110-04

REEL CHASSIS (1) REEL CHASSIS (1)

Take-up Side Reel Chassis

BVW-10
BVW-10P
BVW-10S



No.	Parts No.	Description
1	A-6737-113-B	MOTOR ASS'Y, REEL
2	A-6739-018-A	PC BOARD ASS'Y, DM
3	A-6741-044-A	BRAKE ASS'Y, T
4	X-3675-801-3	TABLE ASS'Y, REEL
5	X-3675-804-0	ARM ASS'Y, TB
6	X-3675-818-0	BRAKE ASS'Y, M
7	1-454-336-00	SOLENOID
8	1-459-051-00	HEAD, SENSING
9	1-586-946-00	PRINTED CIRCUIT BOARD, SS-8
10	3-489-310-XX	SPRING, TENSION (18T)
11	3-508-108-XX	SPRING, TENSION (17T)
12	3-575-358-00	SPRING, TENSION
13	3-630-035-01	SPACER, VIDEO HEAD (0.01T)
14	3-630-035-11	SPACER, VIDEO HEAD (0.02T)
15	3-630-035-21	SPACER, VIDEO HEAD (0.03T)
16	3-630-035-31	SPACER, VIDEO HEAD (0.04T)
17	3-648-452-00	SPRING, TENSION
18	3-654-617-03	RUBBER, T BRAKE
19	3-654-618-00	LIMITER, T BRAKE
20	3-654-619-00	CHASSIS, T BRAKE
21	3-675-815-00	JOINT, MB
22	3-675-816-00	TABLE, BRAKE, T
23	3-675-825-00	ARM, RELEASE
24	3-675-826-00	COVER, SHIELD, RM
25	3-675-833-00	HOLDER, MB
26	3-677-701-00	BRACKET, T SENSOR
27	3-677-702-00	HOLDER, T SENSOR
28	3-701-441-01	WASHER, POLY 4MM DIA. (0.13T)
29	3-701-441-11	WASHER, POLY 4MM DIA. (0.25T)
30	3-701-441-21	WASHER, POLY 4MM DIA. (0.5T)


NOTE:

- The shaded and -marked components are critical to safety. Replace only with same components as specified.
- Parts printed in Bold-Face type are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in Bold-Face type will be processed, but allow for additional delivery time.
- Item with no part number and/or no description are not stocked because they are seldom required for routine service.

REEL CHASSIS (2)

REEL CHASSIS (2)

Supply Side Reel Chassis



BVW-10
BVW-10P
BVW-10S

No.	Parts No.	Description
101	A-6737-113-B	MOTOR ASS'Y, REEL
102	A-6739-018-A	PC BOARD ASS'Y, DM
103	A-6741-045-A	BRAKE ASS'Y, S
104	X-3675-801-3	TABLE ASS'Y, REEL
105	X-3675-803-0	ARM ASS'Y, S BRAKE
106	X-3675-805-0	ARM ASS'Y, SB
107	X-3675-806-0	PLATE ASS'Y, ADJUSTMENT, R
108	X-3675-818-0	BRAKE ASS'Y, M
109	X-3675-833-0	ARM ASS'Y, TE
110	1-454-336-00	SOLENOID
111	1-454-337-00	SOLENOID
112	1-608-060-00	PRINTED CIRCUIT BOARD, TE-2
113	2-245-253-00	SPRING
114	3-534-558-00	SPRING, TENSION
115	3-568-814-00	SPRING, TENSION
116	3-575-358-00	SPRING, TENSION
117	3-630-035-01	SPACER, VIDEO HEAD (0.01T)
118	3-630-035-11	SPACER, VIDEO HEAD (0.02T)
119	3-630-035-21	SPACER, VIDEO HEAD (0.03T)
120	3-630-035-31	SPACER, VIDEO HEAD (0.04T)
121	3-648-452-00	SPRING, TENSION
122	3-675-803-00	LIMITER, S BRAKE
123	3-675-810-00	BASE, MB SOLENOID
124	3-675-815-00	JOINT, MB
125	3-675-818-00	BRACKET, DM
126	3-675-819-00	ARM, RING
127	3-675-820-00	HOOK, SPRING
128	3-675-821-00	BRACKET, TE
129	3-675-826-00	COVER, SHIELD, RM
130	3-675-833-00	HOLDER, MB
131	3-675-838-00	BASE, S BRAKE
132	3-701-441-01	WASHER, POLY 4MM DIA. (0.13T)
133	3-701-441-11	WASHER, POLY 4MM DIA. (0.25T)
134	3-701-441-21	WASHER, POLY 4MM DIA. (0.5T)

NOTE:

- The shaded and -marked components are critical to safety. Replace only with same components as specified.
- Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.
- Item with no part number and/or no description are not stocked because they are seldom required for routine service.

DRUM, HEAD, TAPE GUIDE

um, Stationary Heads and Tape Guides Block

PSW 2.6x6

PSW 2.6x6

226

208

212

B 2x8

W, 3mm dia.

B 2x8

Set Screw 2.6x6

Set Screw 2.6x6

225

PS 2x4

224

249

228

243

223

253

227

237

PTT 3x6

PSW 3x12

PSW 2.6x6

PSW 3x6

PSW 2.6x6

PSW 3x6

246

220

202

207

214

217

215

214

215

218

219

203

245

216

221

205

213

201

244

B 2x6

Set Screw 2.6x6

B 2x6

229

PS 2x4

230

251

W, 3mm dia.

212

208

235

PSW 2.6x6

204

PSW 3x8

PS 2x4

254

242

250

236

NOTE:

- The shaded and -marked components are critical to safety. Replace only with same components as specified.
- Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work.


1. The shaded and -marked components are critical to safety.
Replace only with same components as specified.
2. Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.
3. Item with no part number and/or no description are not stocked because they are seldom required for routine service.

BVW-10P
BVW-10S

THREADING RING

THREADING RING

Threading Ring Block




BVW-10P
BVW-10S

No.	Parts No.	Description
301	A-6750-153-A	RING ASS'Y, THREADING
302	X-3675-850-0	ARM ASS'Y, PINCH ROLLER
303	X-3675-807-0	RING SUB ASS'Y, THREADING
304	X-3675-809-0	ROLLER (A) ASS'Y, RING
305	X-3675-810-0	ROLLER (B) ASS'Y, RING
306	1-207-682-11	R, WIRE
307	1-608-053-00	PRINTED CIRCUIT BOARD, LE-19
308	1-608-054-00	PRINTED CIRCUIT BOARD, PH-16
309	1-608-056-00	PRINTED CIRCUIT BOARD, HE-5
310	2-217-533-00	SPRING, COMPRESSION
311	3-653-396-00	SPRING
312	3-653-487-00	BRACKET, RESISTOR
313	3-655-966-00	SPACER, STEP
314	3-669-443-00	BALL BEARING
315	3-675-823-00	FLANGE, PRECEDING GUIDE
316	3-675-849-00	STOPPER, TAPE
317	3-675-862-00	BRACKET, DETECTION, ROTOR
318	3-677-718-00	ROLLER, PRECEDING GUIDE
319	3-680-809-00	RETAINER, BEARING
320	3-680-810-00	ROLLER
321	3-680-811-00	FLANGE, UPPER
322	2-270-601-00	SUPPORT
323	3-680-803-00	LEVER
324	3-637-331-00	SPRING, COMPRESSION
325	3-680-812-00	FLANGE, LOWER

NOTE:

- The shaded and  -marked components are critical to safety. Replace only with same components as specified.
- Parts printed in Bold-Face type are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in Bold-Face type will be processed, but allow for additional delivery time.
- Item with no part number and/or no description are not stocked because they are seldom required for routine service.

Pinch Press Mechanism Block




No.	Parts No.	Description
401	A-6749-078-A	MECH ASS'Y, PINCH PRESS
403	1-454-338-00	SOLENOID
405	1-608-069-00	PRINTED CIRCUIT BOARD, PD-20
406	3-446-165-00	SPRING, TENSION
407	3-645-168-00	SPRING, TENSION
408	3-653-379-00	LEVER (A), PINCH COMPRESSION
409	3-653-380-02	LEVER (B), PINCH COMPRESSION
410	3-653-381-00	PIN, SOLENOID
411	3-653-383-00	STOPPER, SLACK SENSOR
412	3-701-441-21	WASHER, POLY 4MM DIA. (0.5T)

NOTE:


- The shaded and -marked components are critical to safety. Replace only with same components as specified.
- Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.
- Item with no part number and/or no description are not stocked because they are seldom required for routine service.

Supply Tension Regulator Block




BVW-10
BVW-10P
BVW-10S

Supply Tension Regulator Block



Gear Box Block




BVW-10
BVW-10P
BVW-10S

No.	Parts No.	Description
601	A-6750-141-A	BOX ASS'Y, GEAR
602	1-541-163-00	MOTOR
603	1-585-913-00	PRINTED CIRCUIT BOARD, LM-4
604	3-653-386-00	PULLEY (2), LM
605	3-653-387-00	BELT, LM
606	3-653-388-00	GEAR, DRIVE
607	3-703-074-00	CAP 3, SHAFT

- NOTE:
- The shaded and  -marked components are critical to safety. Replace only with same components as specified.
 - Parts printed in Bold-Face type are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in Bold-Face type will be processed, but allow for additional delivery time.
 - Item with no part number and/or no description are not stocked because they are seldom required for routine service.

Level Control Chassis Block



BVW-10
BVW-10P
BVW-10S


No.	Parts No.	Description
701	A-6728-526-A	MOUNTED CIRCUIT BOARD, CP-52
702	1-224-694-XX	R, VAR, CARBON 20K
703	1-226-616-00	R, VAR, CARBON 100K
704	1-228-218-00	R, VAR, CARBON 500/500
705	1-507-553-00	JACK
706	1-516-963-00	SWITCH, LEVER SLIDE
707	1-516-995-00	SWITCH, LEVER SLIDE
708	1-518-461-00	LAMP, PILOT

No.	Parts No.	Description
709	1-520-439-00	METER, VU
710	1-520-455-21	METER, RF
	711	1-554-256-00 SWITCH, ROCKER (AC POWER)
712	1-608-050-00	PRINTED CIRCUIT BOARD, SW-85
713	1-608-057-00	PRINTED CIRCUIT BOARD, LA-4
714	1-608-062-00	PRINTED CIRCUIT BOARD, HP-7

No.	Parts No.	Description
715	1-520-439-00	METER, VU
716	1-520-455-21	METER, RF
717	1-554-256-00	SWITCH, ROCKER (AC POWER)

LEVEL CONTROL LEVEL CONTROL

Level Control Chassis Block



No.	Parts No.	Description
701	A-6728-526-A	MOUNTED CIRCUIT BOARD, CP-52
702	1-224-694-XX	R, VAR, CARBON 20K
703	1-226-616-00	R, VAR, CARBON 100K
704	1-228-218-00	R, VAR, CARBON 500/500
705	1-507-553-00	JACK
706	1-516-963-00	SWITCH, LEVER SLIDE
707	1-516-995-00	SWITCH, LEVER SLIDE
708	1-518-461-00	LAMP, PILOT


No.	Parts No.	Description
709	1-520-439-00	METER, VU
710	1-520-455-21	METER, RF
711	1-554-256-00	SWITCH, ROCKER (AC POWER)
712	1-608-050-00	PRINTED CIRCUIT BOARD, SW-85
713	1-608-057-00	PRINTED CIRCUIT BOARD, LA-4
714	1-608-062-00	PRINTED CIRCUIT BOARD, HP-7

No.	Parts No.	Description
715	1-608-294-00	PRINTED CIRCUIT BOARD, VR-8
716	3-668-124-00	HOLDER, LED
717	3-677-141-00	CUSHION, METER

- NOTE:
- The shaded and -marked components are critical to safety. Replace only with same components as specified.
 - Parts printed in Bold-Face type are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in Bold-Face type will be processed, but allow for additional delivery time.
 - Item with no part number and/or no description are not stocked because they are seldom required for routine service.

FUNCTION CONTROL FUNCTION CONTROL

Function Control Chassis Block



BVW-10
BVW-10P
BVW-10S


No.	Parts No.	Description
801	A-6728-530-A	MOUNTED CIRCUIT BOARD, KY-32
802	A-6734-106-A	DIAL ASS'Y, SEARCH
803	A-6736-030-A	HINGE (LEFT) ASS'Y
804	A-6736-031-A	HINGE (RIGHT) ASS'Y
805	1-516-994-00	SWITCH, LEVER SLIDE
806	1-518-450-11	LAMP, PILOT
807	1-518-450-21	LAMP, PILOT
808	1-552-539-00	SWITCH, KEY BOARD
809	1-553-550-11	SWITCH, PUSH (12 CORNER)
810	1-553-550-31	SWITCH, PUSH (12 CORNER)
811	1-553-551-11	SWITCH, PUSH (17 CORNER)
812	1-553-551-32	SWITCH, PUSH (17 CORNER)
813	1-604-351-00	PRINTED CIRCUIT BOARD, PC-9
814	1-604-353-00	PRINTED CIRCUIT BOARD, PC-14
815	1-607-973-00	PRINTED CIRCUIT BOARD, DP-30
816	3-659-487-00	HOLDER, BUZZER
817	3-659-488-00	PIN, BUZZER HOLDER
818	3-668-123-00	HOLDER, LAMP
819	3-668-151-00	BRACKET, PC-14
820	3-668-407-00	NUT, LOCK
821	3-668-417-00	COVER, PROTECTION, PC-9
822	3-677-148-00	COVER, KEY PANEL
823	3-706-480-01	KEY TOP
824	3-706-480-22	KEY TOP
825	3-706-481-01	KEY TOP
826	3-706-481-22	KEY TOP

NOTE:

- The shaded and  marked components are critical to safety. Replace only with same components as specified.
- Parts printed in Bold-Face type are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in Bold-Face type will be processed, but allow for additional delivery time.
- Item with no part number and/or no description are not stocked because they are seldom required for routine service.

CONNECTOR PANEL CONNECTOR PANEL

Connector Panel Block



BVW-10P
BVW-10S


No.	Parts No.	Description
901	A-6728-588-A	MOUNTED CIRCUIT BOARD, CP-56
902	X-2068-004-0	TERMINAL ASS'Y
903	1-509-095-00	SOCKET, MULTI (8P)
904	1-509-176-00	RECEPTACLE, XLR, 3P (MALE)
906	1-509-546-00	3P INLET
908	1-516-777-XX	SWITCH, SLIDE
909	1-541-209-00	MOTOR, BRUSHLESS FAN
910	1-560-546-00	CONNECTOR, P (LIGHT ANGLE) 34P
911	1-561-028-00	CONNECTOR, 36P
912	1-561-045-00	CONNECTOR, (R-F)
913	1-561-655-00	CONNECTOR SOCKET, MINIATURE 9P
914	1-561-781-21	RECEPTACLE, BNC
915	1-607-968-00	PRINTED CIRCUIT BOARD, AC-40
916	1-608-063-00	PRINTED CIRCUIT BOARD, RE-6
917	1-608-064-00	PRINTED CIRCUIT BOARD, SW-86
918	2-068-008-00	WASHER
919	2-232-914-00	PLATE NUT, XLR
920	3-531-576-01	RIVET
922	3-659-682-00	HOLDER, PC BOARD
923	3-668-459-00	SCREW, CONNECTOR
924	3-668-460-00	SPRING
925	3-675-896-00	COVER, FUSE
926	3-675-897-00	BRACKET, FAN
927	3-675-898-00	PLATE, VENTILATION
928	3-675-899-00	BRACKET, RE
929	3-677-109-11	PLATE, ORNAMENTAL, REAR PANEL
931	3-677-774-00	BRACKET, FAN, N
932	3-815-122-00	BUSHING

NOTE:

- The shaded and **Δ**-marked components are critical to safety. Replace only with same components as specified.
- Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.
- Item with no part number and/or no description are not stocked because they are seldom required for routine service.

TBC CONTROL CHASSIS BLOCK (1)

TBC Control Block




BVW-10P

No.	Parts No.	Description
1001	1-228-770-00	R, VAR, CARBON 5K
1002	1-516-226-00	SWITCH, SLIDE
1003	1-548-100-11	TIMER
1004	1-608-067-00	PRINTED CIRCUIT BOARD, ST-22
1005	3-531-576-01	RIVET
1006	3-677-773-00	COVER (P), ST
1007	3-677-144-00	COVER, PROTECTION, ST PCB
1008	3-677-145-00	HOLDER, ST PC BOARD
1009	3-677-727-00	PLATE, SWITCH
1010	3-680-806-00	LABEL, DOLBY (C)

NOTE:

- The shaded and -marked components are critical to safety. Replace only with same components as specified.
- Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.
- Item with no part number and/or no description are not stocked because they are seldom required for routine service.

Chassis Block (1)




BVW-10
BVW-10P
BVW-10S

No.	Parts No.	Description	No.	Parts No.	Description
1101	A-6725-295-A	MOUNTED CIRCUIT BOARD, MB-41	1110	3-677-733-00	LABEL (1), PC BOARD
1102	A-6725-296-A	MOUNTED CIRCUIT BOARD, MB-42	1111	3-677-734-00	LABEL (2), PC BOARD
1103	X-4838-902-X	FOOT	1112	3-677-735-00	LABEL (3), PC BOARD
1104	1-560-919-31	CONNECTOR, CARD 60P	1113	3-677-736-00	LABEL (4), PC BOARD
1105	3-650-537-00	WASHER	1114	3-677-737-00	BRACKET, S-MB
1106	3-677-117-00	GUIDE, MOTHER	1115	3-677-738-00	HOLDER (SF), CONNECTOR
1107	3-677-120-00	BRACKET, HM	1116	3-677-739-00	HOLDER (SR), CONNECTOR
1108	3-677-123-00	GUIDE (L), PCB	1117	3-677-740-00	GUIDE (S), PC BOARD
1109	3-677-124-00	JOINT (B)			


NOTE:

- Th to Re
- Parts replac manu Order: proce
- Item stocke service

Chassis Block (1)




No.	Parts No.	Description
1101	A-6725-295-A	MOUNTED CIRCUIT BOARD, MB-41
1102	A-6725-296-A	MOUNTED CIRCUIT BOARD, MB-42
1103	X-4838-902-X	FOOT
1104	1-560-919-31	CONNECTOR, CARD 60P
1105	3-650-537-00	WASHER
1106	3-677-117-00	GUIDE, MOTHER
1107	3-677-120-00	BRACKET, HM
1108	3-677-123-00	GUIDE (L), PCB
1109	3-677-124-00	JOINT (B)



NOTE:


1. The shaded and  -marked components are critical to safety.
Replace only with same components as specified.
2. Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.
3. Item with no part number and/or no description are not stocked because they are seldom required for routine service.

Switching Regulator
Switching regulator (UR-06)
Switching regulator (UR-07)



BVW-10
BVW-10P
BVW-10S

No.	Parts No.	Description	No.	Parts No.	Description
1201	1-413-119-00	SWITCHING REGULATOR (UR-06)	1206	2-430-221-00	RUBBER, INSULATING
1202	1-413-120-00	SWITCHING REGULATOR (UR-07)	1207	2-430-679-00	RUBBER, INSULATING
1203	2-403-507-00	CASE	1208	2-430-828-00	RETAINER, SEMICONDUCTOR
1204	2-430-683-00	SPRING	1209	2-430-790-00	RETAINER, SEMICONDUCTOR
1205	2-430-684-00	INSULATOR	1210	2-430-964-00	HEAT SINK
			1211	3-703-044-26	LABEL, CAUTION





BVW-10
BVW-10P
BVW-10S

- NOTE:
- The shaded and **Δ**-marked components are critical to safety. Replace only with same components as specified.
 - Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.
 - Item with no part number and/or no description are not stocked because they are seldom required for routine service.

SWITCHING REGULATOR

SWITCHING REGULATOR




BVW-10
BVW-10P
BVW-10S

NOTE:

1. The shaded and -marked components are critical to safety. Replace only with same components as specified.
2. Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.
3. Item with no part number and/or no description are not stocked because they are seldom required for routine service.

SWITCHING REGULATOR

Switching Regulator
Switching regulator (UR-06)
Switching regulator (UR-07)




BVW-10
BVW-10P
BVW-10S

No.	Parts No.	Description	No.	Parts No.	Description
 1201	1-413-119-00	SWITCHING REGULATOR (UR-06)	1206	2-430-221-00	RUBBER, INSULATING
			1207	2-430-679-00	RUBBER, INSULATING
 1202	1-413-120-00	SWITCHING REGULATOR (UR-07)	1208	2-430-828-00	RETAINER, SEMICONDUCTOR
			1209	2-430-790-00	RETAINER, SEMICONDUCTOR
1203	2-403-507-00	CASE	1210	2-430-964-00	HEAT SINK
1204	2-430-683-00	SPRING			
1205	2-430-684-00	INSULATOR	1211	3-703-044-26	LABEL, CAUTION

19-26

SWITCHING REGULATOR SWITCH





BVW-10
BVW-10P
BVW-10S

NOTE:

1. The shaded and  -marked components are critical to safety.
Replace only with same components as specified.
2. Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.
3. Item with no part number and/or no description are not stocked because they are seldom required for routine service.

19-27



BVW-10
BVW-10P
BVW-10S


NOTE:

1. The shaded and -marked components are critical to safety. Replace only with same components as specified.
2. Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.
3. Item with no part number and/or no description are not stocked because they are seldom required for routine service.

CASSETTE-UP

CASSETTE-UP

Cassette-up Compartment



NOTE:

1. The shaded and Δ -marked components are critical to safety. Replace only with same components as specified.
2. Parts printed in Bold-Face type are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in Bold-Face type will be processed, but allow for additional delivery time.
3. Item with no part number and/or no description are not stocked because they are seldom required for routine service.


BVW-10
BVW-10P
BVW-10S

No.	Parts No.	Description	No.	Parts No.	Description	No.	Parts No.	Description	No.	Parts No.	Description
1301	A-6751-151-C	CASSETTE COMPARTMENT ASS'Y	1318	3-677-155-00	RETAINER, SPRING	1336	3-677-178-00	ROLLER, PRESS	1352	3-677-710-00	LID, CASSETTE
1303	X-3675-819-0	STAY ASS'Y, CASSETTE COMPARTMENT	1319	3-677-156-00	GEAR (R), DRIVING	1337	3-677-179-00	ARM, JOINT	1353	3-677-711-00	GEAR (L), DRIVING
1304	X-3675-820-0	BRACKET ASS'Y, LEVER	1320	3-677-157-00	STOPPER (R), CASSETTE	1338	3-677-180-00	WIRE, PRESS	1354	3-677-726-00	SPRING
1305	X-3675-821-2	BRACKET ASS'Y, WINDOW	1321	3-677-160-00	HINGE (LEFT)	1339	3-677-181-00	REFLECTOR	1355	3-677-748-00	COLLAR
1306	1-518-508-00	LAMP, PILOT	1322	3-677-161-00	HINGE (RIGHT)	1340	3-677-182-00	HOLDER, REFLECTOR	1358	3-701-439-21	WASHER, POLY 3MM DIA. 0.5T
1307	1-541-163-00	MOTOR	1325	3-677-165-03	GEAR, MIDWAY	1341	3-677-184-00	JOINT (M)	1359	3-677-770-00	LEVER
1308	1-608-052-00	PRINTED CIRCUIT BOARD, CL-7	1326	3-677-166-00	GEAR, JOINT	1342	3-677-185-00	STOPPER (L), CASSETTE	1360	3-677-771-00	COLLAR, GUIDE ROLLER
1309	1-608-070-00	PRINTED CIRCUIT BOARD, PC-17	1327	3-677-167-00	BEARING	1343	3-677-187-00	ROLLER, GUIDE	1361	3-677-779-00	GUARD, HARNESS
1310	1-608-071-00	PRINTED CIRCUIT BOARD, PC-18	1328	3-677-168-00	JOINT	1344	3-677-193-00	PIN, STOPPER	1362	3-646-214-00	SPRING
1311	3-465-159-XX	SPRING, TENSION (20T)	1329	3-677-171-00	LEVER (LEFT)	1345	3-677-197-00	SPRING (LEFT)			
1312	3-563-104-00	SPRING, TENSION	1330	3-677-172-00	LEVER (RIGHT)	1346	3-677-198-00	SPRING (R)			
1313	3-568-321-00	SPRING, TENSION	1331	3-677-173-00	LEVER, DETECTION, CASSETTE	1347	3-677-199-03	GEAR			
1314	3-646-214-00	SPRING	1332	3-677-174-00	LEVER, DETECTION, CASSETTE-DOWN	1348	3-677-704-03	LEVER			
1315	3-668-314-02	HOLDER, LAMP	1333	3-677-175-00	BRACKET, IN SWITCH	1349	3-677-706-00	ARM, DRIVING			
1316	3-677-153-00	HOLDER	1334	3-677-176-02	BRACKET, DOWN SWITCH	1350	3-677-707-00	JOINT (R)			
1317	3-677-154-00	PLATE, PREVENTION	1335	3-677-177-00	ARM	1351	3-677-708-00	JOINT (F)			

ORNAMENTAL PANEL (1)


ORNAMENTAL PANEL (1)

Ornamental Panel Block (1)



BVW-10
BVW-10P
BVW-10S

No.	Parts No.	Description
1401	X-3661-073-0	KNOB ASS'Y, CONTROL
1402	X-3668-075-0	KNOB ASS'Y, CONTROL
1403	X-3675-811-0	PANEL SUB ASS'Y, KEY
1404	X-3675-812-2	PANEL SUB ASS'Y, FRONT
1405	2-252-623-00	PLATE, SWITCH, LEVER
1406	3-657-986-00	GUARD, REC
1407	3-668-008-02	PUSH BUTTON (3x5)



BVW-10
BVW-10P
BVW-10S

No.	Parts No.	Description
1415	3-675-891-00	ESCUTCHEON, BUTTON (LARGE)
1416	3-675-892-00	ESCUTCHEON, BUTTON (SMALL)
1417	4-309-349-00	SPRING, COIL
1418	3-680-805-11	LABEL, MODEL NUMBER


NOTE:

- The shaded and -marked components are critical to safety. Replace only with same components as specified.
- Parts printed in Bold-Face type are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in Bold-Face type will be processed, but allow for additional delivery time.
- Item with no part number and/or no description are not stocked because they are seldom required for routine service.

ORNAMENTAL PANEL (2)

ORNAMENTAL PANEL (2)

Ornamental Panel Block (2)



BVW-10
BVW-10P
BVW-10S

No.	Parts No.	Description
1501	X-3642-018-0	HANDLE ASS'Y
1502	3-650-537-00	WASHER
1503	3-668-025-00	ESCUTCHEON, HINGE STOPPER
1504	3-668-335-00	ORNAMENT, SIDE PLATE
1505	3-675-895-00	SPACER, UPPER LID
1506	3-677-101-00	SPACER, M4
1507	3-677-102-00	RETAINER, PC
1508	3-677-103-00	SCREW, COIN, M4 UPPER LID
1509	3-677-105-00	PLATE, BOTTOM
1510	3-677-106-00	CABINET (RIGHT)
1511	3-677-107-00	CABINET (LEFT)
1512	3-677-108-00	LID, UPPER
	3-677-108-05	LID, UPPER
		S/N 10151 AND LATER
1513	3-677-729-00	CUSHION (LARGE)
1514	3-677-730-00	CUSHION (SMALL)
1515	3-677-781-00	COVER, INSULATING
		S/N 10151 AND LATER


NOTE:

- The shaded and  -marked components are critical to safety. Replace only with same components as specified.
- Parts printed in Bold-Face type are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in Bold-Face type will be processed, but allow for additional delivery time.
- Item with no part number and/or no description are not stocked because they are seldom required for routine service.

PRINTED CIRCUIT BOARD (1)

PRINTED CIRCUIT BOARD (1)

Printed Circuit Board Block (1)



BVW-10
BVW-10P
BVW-10S

No.	Parts No.	Description
1601	A-6715-158-A	MOUNTED CIRCUIT BOARD, DE-12
1603	1-556-458-00	WIRE ASS'Y, FLAT TYPE 16P
1604	3-668-424-00	RETAINER (REAR), FC
1605	3-677-150-00	COVER, DE-12
1606	3-677-733-00	LABEL (1), PC BOARD
1607	3-677-734-00	LABEL (2), PC BOARD
1608	3-677-735-00	LABEL (3), PC BOARD
1609	3-677-736-00	LABEL (4), PC BOARD
1610	3-677-741-00	GUARD, AIR
1611	3-677-742-00	SHEET, SIDE PLATE (M)

NOTE:


1. The shaded and  -marked components are critical to safety. Replace only with same components as specified.
2. Parts printed in **Bold-Face** type are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face** type will be processed, but allow for additional delivery time.
3. Item with no part number and/or no description are not stocked because they are seldom required for routine service.

PRINTED CIRCUIT BOARD (2)


PRINTED CIRCUIT BOARD (2)

Printed Circuit Board Block (2)


PR-48
MY-17
CK-14
EN-20
SV-51
SY-91




CF-12
CD-25
YD-15
AU-37
TC-25
PS-16



EN-20



BVW-10
BVW-10P



BVW-10
BVW-10P

No.	Parts No.	Description
1701	X-3675-813-0	PLATE ASS'Y, SHIELD, L
1702	X-3675-814-0	PLATE ASS'Y, SHIELD, S
1703	2-251-622-00	LEVER, PC BOARD
1704	3-660-978-00	SHEET, HEAT RESISTING
1705	3-675-867-00	HEAT SINK
1706	4-026-252-00	WASHER, INSULATING
1707	3-677-763-02	PLATE SHIELD, EN (1-2)


NOTE:

- The shaded and -marked components are critical to safety. Replace only with same components as specified.
- Parts printed in Bold-Face type are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in Bold-Face type will be processed, but allow for additional delivery time.
- Item with no part number and/or no description are not stocked because they are seldom required for routine service.

EXTENSION BOARD

EXTENSION BOARD

Extension Board Block



BVW-10
BVW-10P
BVW-10S

No.	Parts No.	Description
1801	A-6725-282-A	EXTENSION BOARD, EX-25 UP TO S/N 10050
	A-6725-308-A	EXTENSION BOARD, EX-30 S/N 10051 AND LATER
1802	A-6725-297-A	EXTENSION BOARD, EX-29 UP TO S/N 10050
	A-6725-309-B	EXTENSION BOARD, EX-31 S/N 10051 AND LATER
1804	1-560-919-21	CONNECTOR, CARD 60P
1805	2-251-622-00	LEVER, PC BOARD
1806	3-677-133-00	BRACKET, EX
1807	2-251-622-00	LEVER, PC BOARD UP TO S/N 10200
	3-680-804-00	LEVER, EX S/N 10201 AND LATER


NOTE:

- The shaded and -marked components are critical to safety. Replace only with same components as specified.
- Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.
- Item with no part number and/or no description are not stocked because they are seldom required for routine service.

19-3. ELECTRICAL PARTS LIST

Parts that are not listed in the "reference numbers order list" are shown in following table.
Reference numbers are omitted.

CERAMIC CAPACITOR 100pF through 0.01μF (B) 50WV




Parts NO. 1-102-□□□-00

Value	Parts No. -□□□-
100pF	106
120	107
150	108
180	109
220	110
270	111
330	112
390	113
470	114
560	115
680	116
820	117

Value	Parts No. -□□□-
0.001μF	074
0.0012	118
0.0015	119
0.0018	120
0.0022	121
0.0027	122
0.0033	123
0.0039	124
0.0047	125
0.0056	126
0.0068	127
0.0082	128
0.01	129

CERAMIC CAPACITOR 0.001μF through 0.1μF 50WV




Parts NO. 1-161-□□□-00

Value	Parts No. -□□□-	Substitute
0.001 μF	039	(1-102-074-00)
0.0012	040	
0.0015	041	
0.0018	042	
0.0022	043	(1-102-100-00)
0.0027	044	
0.0033	045	
0.0039	046	(1-102-124-00)
0.0047	047	
0.0056	048	
0.0068	049	
0.0082	050	

Value	Parts No. -□□□-	Substitute
0.01 μF	051	(1-101-118-00)
0.012	052	
0.015	053	
0.018	054	
0.022	055	(1-101-005-00)
0.027	056	
0.033	057	
0.039	058	
0.047	059	(1-101-006-00)
0.056	060	
0.068	061	
0.082	062	
0.1	063	


SILVERED MICA CAPACITOR

1 pF through 620 pF
± 5%, 50WV

Parts No. 1-107-□□□-00

Value	Parts No. -□□□-	Value	Parts No. -□□□-	Value	Parts No. -□□□-	Value	Parts No. -□□□-
1 pF	098	15 pF	065	51 pF	078	180 pF	091
2	099	16	066	56	079	200	092
3	100	18	067	62	080	220	093
4	101	20	068	68	081	240	094
5	102	22	069	75	082	270	095
6	103	24	070	82	083	300	096
7	104	27	071	91	084	330	097
8	105	30	072	100	085	360	231
9	106	33	073	110	086	390	232
10	061	36	074	120	087	430	233
11	062	39	075	130	088	470	234
12	063	43	076	150	089	510	235
13	064	47	077	160	090	560	236
						620	237

ELECTROLYTIC CAPACITOR


0.47 μ F through 470 μ F
6.3WV through 50 (63, 100)WV

Parts No. 1-123-□□□-00

Value	Parts No. -□□□-	Value	Parts No. -□□□-	Value	Parts No. -□□□-
0.47 μ F 50V		22 μ F 35V	342	100 μ F 50V	360
100	379	50		220	6.3
1	50	63	371	10	308
100	380	33	6.3	16	321
2.2	50	10		25	334
100	381	16	318	35	346
3.3	25	25		50	361
35		35	343	330	6.3
50		50		10	309
100	382	63	372	16	322
4.7	25	47	6.3	25	335
35		10	306	35	347
50		16		50	362
63	369	25	332	470	6.3
10	10	35		10	310
16		50	359	16	323
25		100	6.3	25	336
35		10	307	35	348
50	356	16		50	
22	16	25	333	63	377
25	330	35	345		

METAL FILM RESISTOR

± 1%, 1/4W
10Ω through 100kΩ




Parts No. 1-214-□□□-00

Value	Parts No. -□□□-	Value	Parts No. -□□□-	Value	Parts No. -□□□-	Value	Parts No. -□□□-
10Ω	084	100Ω	108	1.0kΩ	132	10kΩ	156
11	085	110	109	1.1	133	11	157
12	086	120	110	1.2	134	12	158
13	087	130	111	1.3	135	13	159
15	088	150	112	1.5	136	15	160
16	089	160	113	1.6	137	16	161
18	090	180	114	1.8	138	18	162
20	091	200	115	2.0	139	20	163
22	092	220	116	2.2	140	22	164
24	093	240	117	2.4	141	24	165
27	094	270	118	2.7	142	27	166
30	095	300	119	3.0	143	30	167
33	096	330	120	3.3	144	33	168
36	097	360	121	3.6	145	36	169
39	098	390	122	3.9	146	39	170
43	099	430	123	4.3	147	43	171
47	100	470	124	4.7	148	47	172
51	101	510	125	5.1	149	51	173
56	102	560	126	5.6	150	56	174
62	103	620	127	6.2	151	62	175
68	104	680	128	6.8	152	68	176
75	105	750	129	7.5	153	75	177
82	106	820	130	8.2	154	82	178
91	107	910	131	9.1	155	91	179
						100	180

CARBON RESISTOR (1/4W)

± 5%, 1/4W, non-special type
1 Ω through 1 M Ω




Parts No. 1-246-□□□-00

Value	Parts No. -□□□-	Value	Parts No. -□□□-	Value	Parts No. -□□□-	Value	Parts No. -□□□-
1 Ω	401	33 Ω	437	1 k Ω	473	33 k Ω	509
1.1	402	36	438	1.1	474	36	510
1.2	403	39	439	1.2	475	39	511
1.3	404	43	440	1.3	476	43	512
1.5	405	47	441	1.5	477	47	513
1.6	406	51	442	1.6	478	51	514
1.8	407	56	443	1.8	479	56	515
2	408	62	444	2	480	62	516
2.2	409	68	445	2.2	481	68	517
2.4	410	75	446	2.4	482	75	518
2.7	411	82	447	2.7	483	82	519
3	412	91	448	3.0	484	91	520
3.3	413	100 Ω	449	3.3	485	100 k Ω	521
3.6	414	110	450	3.6	486	110	522
3.9	415	120	451	3.9	487	120	523
4.3	416	130	452	4.3	488	130	524
4.7	417	150	453	4.7	489	150	525
5.1	418	160	454	5.1	490	160	526
5.6	419	180	455	5.6	491	180	527
6.2	420	200	456	6.2	492	200	528
6.8	421	220	457	6.8	493	220	529
7.5	422	240	458	7.5	494	240	530
8.2	423	270	459	8.2	495	270	531
9.1	424	300	460	9.1	496	300	532
10 Ω	425	330	461	10 k Ω	497	330	533
11	426	360	462	11	498	360	534
12	427	390	463	12	499	390	535
13	428	430	464	13	500	430	536
15	429	470	465	15	501	470	537
16	430	510	466	16	502	510	538
18	431	560	467	18	503	560	539
20	432	620	468	20	504	620	540
22	433	680	469	22	505	680	541
24	434	750	470	24	506	750	542
27	435	820	471	27	507	820	543
30	436	910	472	30	508	910	544
						1 M Ω	545

CARBON RESISTOR (1/8W)

±5%, 1/8W, non-special type
2.2Ω through 1MΩ



Parts No. 1-246-□□□-00

Parts No. 1-247-□□□-00

Value	Parts No. -□□□-
1Ω	—
1.1	—
1.2	—
1.3	—
1.5	—
1.6	—
1.8	—
2	—
2.2	751
2.4	812
2.7	752
3	813
3.3	753
3.6	814
3.9	754
4.3	815
4.7	755
5.1	816
5.6	756
6.2	817
6.8	757
7.5	818
8.2	758
9.1	819
10Ω	759
11	820
12	760
13	821
15	761
16	822
18	762
20	823
22	763
24	824
27	764
30	825

Value	Parts No. -□□□-
33Ω	765
36	826
39	766
43	827
47	767
51	828
56	768
62	829
68	769
75	830
82	770
91	831
100Ω	771
110	832
120	772
130	833
150	773
160	834
180	774
200	835
220	775
240	836
270	776
300	837
330	777
360	838
390	778
430	839
470	779
510	840
560	780
620	841
680	781
750	842
820	782
910	843


Value	Parts No. -□□□-
1kΩ	783
1.1	844
1.2	784
1.3	845
1.5	785
1.6	846
1.8	786
2	847
2.2	787
2.4	848
2.7	788
3.0	849
3.3	789
3.6	850
3.9	790
4.3	851
4.7	791
5.1	852
5.6	792
6.2	853
6.8	793
7.5	854
8.2	794
9.1	855
10kΩ	795
11	856
12	796
13	857
15	797
16	858
18	798
20	859
22	799
24	860
27	800
30	861

Value	Parts No. -□□□-
33kΩ	801
36	862
39	802
43	863
47	803
51	864
56	804
62	865
68	805
75	866
82	806
91	867
100kΩ	807
110	868
120	808
130	869
150	809
160	870
180	810
200	871
220	811

Value	Parts No. -□□□-
240kΩ	054
270	046
300	055
330	047
360	056
390	048
430	057
470	049
510	058
560	050
620	059
680	051
750	060
820	052
910	061
1MΩ	053

MICRO INDUCTOR

1 μ H through 470 μ H
 $\pm 5\%$




Parts No. 1-407- $\square\square\square$ -XX

Value	Parts No. - $\square\square\square$ -	Value	Parts No. - $\square\square\square$ -	Value	Parts No. - $\square\square\square$ -	Value	Parts No. - $\square\square\square$ -
1 μ H	178	4.7 μ H	186	22 μ H	161	100 μ H	169
1.2	179	5.6	187	27	162	120	170
1.5	180	6.8	188	33	163	150	171
1.8	181	8.2	189	39	164	180	172
2.2	182	10	157	47	165	220	173
2.7	183	12	158	56	166	270	174
3.3	184	15	159	68	167	330	175
3.9	185	18	160	82	168	390	176
						470	177

MICRO INDUCTOR

470 μ H through 33 mH
 $\pm 5\%$



Parts No. 1-407- $\square\square\square$ -00

Value	Parts No. - $\square\square\square$ -	Value	Parts No. - $\square\square\square$ -	Value	Parts No. - $\square\square\square$ -	Value	Parts No. - $\square\square\square$ -
470 μ H	488	1.5 mH	494	4.7 mH	500	15 mH	506
560	489	1.8	495	5.6	501	18	507
680	490	2.2	496	6.8	502	22	508
820	491	2.7	497	8.2	503	27	509
1 mH	492	3.3	498	10	504	33	510
1.2	493	3.9	499	12	505		

CONNECTOR




top-type receptacle

side-type receptacle

housing

plug

contact



2P	1-508-900-00
3P	1-508-901-00
4P	1-508-902-00
5P	1-508-903-00
6P	1-508-904-00
8P	1-508-905-00
10P	1-508-906-00
12P	1-508-949-00

2P	1-508-933-00
3P	1-508-934-00
4P	1-508-950-00
5P	1-508-935-00
6P	1-508-936-00
8P	1-508-937-00
10P	1-508-951-00
12P	1-508-997-00

2P	1-509-983-00
3P	1-509-984-00
4P	1-509-985-00
5P	1-509-986-00
6P	1-509-987-00
8P	1-509-988-00
10P	1-509-989-00
12P	1-561-056-00

1-509-982-00

ABBREVIATIONS

Ref. No.	Description	Ref. No.	Description	Ref. No.	Description
C□□, CV□□	CAPACITOR	H□□	HEAD	Q□□	TRANSISTOR
CN□□	CONNECTOR	IC□□	IC	R□□, RV□□	RESISTOR
D□□	DIODE	J□□	JACK	S□□, SW□□	SWITCH
DL□□	DELAY LINE	L□□	INDUCTOR	T□□	TRANSFORMER
DM□□	DME	M□□	MOTOR	TH□□	THERMISTOR
F□□	FUSE	PL□□	LAMP	X□□	CRYSTAL
FB□□	FERRITE BEAD	PH□□	PHOTO INTERRUPTER		
FL□□	FILTER	PM□□	SOLENOID		

All capacitors are in micro farads unless otherwise specified.

All inductors are in micro henries unless otherwise specified.

All resistors are in ohms.

Ref.No. Parts No. Description

AC-40 BOARD

1-553-037-XX HOLDER, FUSE
1-607-968-00 PRINTED CIRCUIT BOARD, AC-40

△ C1 1-130-917-00 FILM, 0.1 20% 250V

△ CN1 1-560-033-00 3P

△ F1 1-532-325-00 T6.3A 250V

△ L1 1-421-457-00 COIL, LINE FILTER

AU-37 BOARD

A-6713-148-A MOUNTED CIRCUIT BOARD, AU-37

C104 1-107-210-00 MICA 22PF 5% 500V
C105 1-108-583-00 MYLAR 0.015 5% 50V
C107 1-123-829-00 ELECT NONPOLAR 2.2 20% 50V
C138 1-108-607-00 MYLAR 0.15 5% 50V
C204 1-107-210-00 MICA 22PF 5% 500V

Ref.No. Parts No. Description

C205 1-108-583-00 MYLAR 0.015 5% 50V
C207 1-123-829-00 ELECT NONPOLAR 2.2 20% 50V
C238 1-108-607-00 MYLAR 0.15 5% 50V
C338 1-108-607-00 MYLAR 0.15 5% 50V

D101 8-719-709-25 1S1925-P
D102 8-719-200-02 10E-2
D108 8-719-200-47 10YD4.5B
D201 8-719-709-25 1S1925-P
D202 8-719-200-02 10E-2

D208 8-719-200-47 10YD4.5B
D302 8-719-200-02 10E-2
D401 8-719-100-57 RD10EB2
D402 8-719-100-57 RD10EB2
D404 8-719-815-55 1S1555
D405 8-719-100-30 RD5.1EB2

IC101 8-759-700-04 NJM2043D-D(JRC)
IC102 8-749-925-15 AFL25F15000G1(MURATA)
IC104 8-759-145-57 uPC4557C(NEC)
IC105 8-751-701-13 CX170-13(SONY)
IC202 8-749-925-15 AFL25F15000G1(MURATA)

IC205 8-751-701-13 CX170-13(SONY)
IC305 8-751-701-13 CX170-13(SONY)
IC401 8-759-171-05 uPC7805H(NEC)
IC402 8-759-179-05 uPC7905H(NEC)

NOTES:

1. The shaded and **△**-marked components are critical to safety. Replace only with same components as specified.

2. Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.

AU-37, CD-25

Ref.No. Parts No. Description

LV101 1-459-434-00 VAR, 22mH
LV201 1-459-434-00 VAR, 22mH

Q101 8-761-622-00 2SC1636
Q102 8-729-663-47 2SC1364
Q103 8-760-335-10 2SC1474
Q104 8-729-117-54 2SA1175
Q106 8-761-622-00 2SC1636

Q108 8-729-240-01 2SK240
Q201 8-761-622-00 2SC1636
Q202 8-729-663-47 2SC1364
Q203 8-760-335-10 2SC1474
Q204 8-729-117-54 2SA1175

Q206 8-761-622-00 2SC1636
Q208 8-729-240-01 2SK240
Q303 8-760-335-10 2SC1474
Q304 8-729-117-54 2SA1175
Q305 8-729-117-54 2SA1175

Q306 8-761-622-00 2SC1636
Q307 8-761-622-00 2SC1636
Q401 8-729-117-54 2SA1175
Q402 8-729-663-47 2SC1364
Q403 8-729-663-47 2SC1364

Q404 8-729-141-43 2SD414
Q405 8-729-154-83 2SB548

R106 1-212-706-00 METAL 150K 1/2W 1Z
R130 1-244-861-00 CARBON 330 1/2W 5Z
R206 1-212-706-00 METAL 150K 1/2W 1Z
R401 1-212-849-00 FUSIBLE 4.7 1/4W 5Z

RV101 1-228-458-00 VAR, 5K
RV102 1-228-293-00 VAR, 5K
RV103 1-228-295-00 VAR, 20K
RV104 1-228-292-00 VAR, 2K
RV105 1-228-293-00 VAR, 5K

RV106 1-228-463-00 VAR, 200K
RV201 1-228-458-00 VAR, 5K
RV202 1-228-293-00 VAR, 5K
RV203 1-228-295-00 VAR, 20K
RV204 1-228-292-00 VAR, 2K

RV205 1-228-293-00 VAR, 5K
RV206 1-228-463-00 VAR, 200K
RV305 1-228-293-00 VAR, 5K

S1 1-552-509-00 DIP

Ref.No. Parts No. Description

T101 1-423-225-00 OUTPUT
T201 1-423-225-00 OUTPUT
T301 1-423-225-00 OUTPUT

TH101 1-800-200-00 S-3K
TH201 1-800-200-00 S-3K

CD-25 BOARD

A-6711-386-A MOUNTED CIRCUIT BOARD, CD-25

C1 1-107-211-00 MICA 24PF 5Z 500V
C7 1-107-210-00 MICA 22PF 5Z 500V
C11 1-107-211-00 MICA 24PF 5Z 500V
C24 1-107-159-00 MICA 33PF 5Z 500V
C30 1-107-157-00 MICA 27PF 5Z 500V

C31 1-107-202-00 MICA 10PF 5Z 500V
C35 1-107-211-00 MICA 24PF 5Z 500V
C42 1-130-471-00 FILM 0.001 5Z 50V
C60 1-131-408-00 TANTALUM 1 20Z 35V
C61 1-131-408-00 TANTALUM 1 20Z 35V

C62 1-131-408-00 TANTALUM 1 20Z 35V
C63 1-131-408-00 TANTALUM 1 20Z 35V
C64 1-131-408-00 TANTALUM 1 20Z 35V
C70 1-109-692-00 DIPPED MICA 620PF 1Z 500V
C71 1-107-208-00 MICA 18PF 5Z 500V

C75 1-109-676-00 DIPPED MICA 130PF 1Z 500V
C80 1-109-673-00 DIPPED MICA 100PF 1Z 500V
C81 1-109-681-00 DIPPED MICA 220PF 1Z 500V
C86 1-131-408-00 TANTALUM 1 20Z 35V
C104 1-109-673-00 DIPPED MICA 100PF 1Z 500V
C127 1-130-473-00 FILM 0.0015 5Z 50V

D1 8-719-151-07 RD5.1E-B
D2 8-719-815-55 1S1555
D3 8-719-162-07 RD6.2E-B
D4 8-719-191-07 RD9.1E-B
D6 8-719-815-55 1S1555
D7 8-719-815-55 1S1555

DL1 1-415-162-00 1MHz 50nS

FL1 1-235-191-00 LPF

NOTES:

- The shaded and -marked components are critical to safety. Replace only with same components as specified.

- Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.

Ref.No.	Parts No.	Description
IC1	8-751-340-00	CX134A(SONY)
IC2	8-741-114-00	BX1140(SONY)
IC3	8-759-208-94	CX894(SONY)
IC4	8-759-951-07	SN75107AN(TI)
IC5	8-741-110-10	BX1101(SONY)
IC6	8-741-109-80	BX1098(SONY)
IC7	8-749-938-90	BX389(SONY)
IC8	8-749-938-90	BX389(SONY)
IC9	8-759-200-60	TA7060AP(TOSHIBA)
IC10	8-759-200-60	TA7060AP(TOSHIBA)
IC11	8-749-936-61	BX366A(SONY)
IC12	8-759-700-14	NJM78M09A(JRC)
LV1	1-407-568-00	VAR, 6.8
LV2	1-407-568-00	VAR, 6.8
LV11	1-407-568-00	VAR, 6.8
LV12	1-407-568-00	VAR, 6.8
Q1	8-724-375-01	2SC403C
Q2	8-724-375-01	2SC403C
Q3	8-724-375-01	2SC403C
Q4	8-724-375-01	2SC403C
Q5	8-724-375-01	2SC403C
Q6	8-761-622-00	2SC1636
Q7	8-724-375-01	2SC403C
Q8	8-729-384-47	2SA844
Q10	8-724-375-01	2SC403C
Q11	8-724-375-01	2SC403C
Q12	8-724-375-01	2SC403C
Q13	8-729-663-47	2SC1364
Q14	8-724-375-01	2SC403C
Q15	8-729-374-02	2SB740
Q16	8-724-375-01	2SC403C
Q20	8-724-375-01	2SC403C
Q21	8-724-375-01	2SC403C
Q22	8-724-375-01	2SC403C
Q23	8-724-375-01	2SC403C
Q25	8-729-190-12	2SC2901
RV1	1-228-292-00	VAR, 2K
RV2	1-228-292-00	VAR, 2K
RV3	1-228-292-00	VAR, 2K
RV4	1-228-291-00	VAR, 1K
RV5	1-228-295-00	VAR, 20K
RV6	1-228-295-00	VAR, 20K
RV7	1-228-293-00	VAR, 5K
RV11	1-228-292-00	VAR, 2K
RV12	1-228-292-00	VAR, 2K
RV70	1-228-291-00	VAR, 1K

Ref.No.	Parts No.	Description
RV71	1-228-290-00	VAR, 500
RV72	1-228-291-00	VAR, 1K
RV73	1-228-288-00	VAR, 100
RV74	1-228-288-00	VAR, 100
RV75	1-228-291-00	VAR, 1K
RV76	1-228-291-00	VAR, 1K
TH1	1-800-202-XX	S-10K
CF-12 BOARD		
A-6711-413-A	MOUNTED CIRCUIT BOARD, CF-12	WITH DU-43 BOARD
DU-43 BOARD		
1-610-457-00	PRINTED CIRCUIT BOARD, DU-43	
C134	1-107-158-00	MICA 30PF 5Z 500V
CN1	1-560-025-00	10P
CN2	1-560-025-00	10P
D4	8-719-911-19	1SS119
Q1	8-724-375-01	2SC403C
Q2	8-729-612-77	2SA1027R
RV20	1-228-293-00	VAR, 5K
CF-12 BOARD		
C5	1-130-495-00	FILM 0.1 5Z 50V
C14	1-107-159-00	MICA 33PF 5Z 500V
C16	1-107-157-00	MICA 27PF 5Z 500V
C18	1-107-157-00	MICA 27PF 5Z 500V
C25	1-130-495-00	FILM 0.1 5Z 50V
C42	1-107-211-00	MICA 24PF 5Z 500V
C43	1-107-211-00	MICA 24PF 5Z 500V
C47	1-107-211-00	MICA 24PF 5Z 500V
C48	1-107-211-00	MICA 24PF 5Z 500V
C119	1-107-159-00	MICA 33PF 5Z 500V
D1	8-719-143-07	RD4.3E-B
D2	8-719-143-07	RD4.3E-B
D3	8-719-911-19	1SS119
D105	8-719-709-25	1S1925P

NOTES:

- The shaded and -marked components are critical to safety. Replace only with same components as specified.

- Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.

Ref.No.	Parts No.	Description
IC1	8-759-201-40	TL8605P-S(TOSHIBA)
IC2	8-759-201-40	TL8605P-S(TOSHIBA)
IC3	8-759-708-08	NJM78L08A(JRC)
IC4	8-759-906-01	TL601CP(TI)
LVL1	1-407-569-00	VAR,10
Q1	8-724-375-01	2SC403C
Q2	8-724-375-01	2SC403C
Q3	8-765-212-20	2SA925
Q4	8-765-212-20	2SA925
Q5	8-724-375-01	2SC403C
Q6	8-729-612-77	2SA1027R
Q7	8-724-375-01	2SC403C
Q8	8-729-612-77	2SA1027R
Q9	8-724-375-01	2SC403C
Q10	8-724-375-01	2SC403C
Q11	8-729-612-77	2SA1027R
Q12	8-724-375-01	2SC403C
Q13	8-729-612-77	2SA1027R
Q14	8-724-375-01	2SC403C
Q15	8-729-612-77	2SA1027R
Q16	8-724-375-01	2SC403C
Q17	8-724-375-01	2SC403C
Q18	8-724-375-01	2SC403C
Q19	8-729-190-12	2SC2901
Q20	8-724-375-01	2SC403C
Q21	8-729-190-12	2SC2901
Q23	8-729-190-12	2SC2901
Q25	8-765-212-20	2SA925
Q27	8-765-212-20	2SA925
Q28	8-729-190-12	2SC2901
Q29	8-729-190-12	2SC2901
Q30	8-729-190-12	2SC2901
Q31	8-724-375-01	2SC403C
Q32	8-729-612-77	2SA1027R
Q33	8-765-212-20	2SA925
Q35	8-729-190-12	2SC2901
Q37	8-729-190-12	2SC2901
Q38	8-765-212-20	2SA925
Q39	8-765-212-20	2SA925
Q40	8-765-212-20	2SA925

Ref.No.	Parts No.	Description
Q41	8-765-212-20	2SA925
Q42	8-765-212-20	2SA925
Q43	8-765-212-20	2SA925
Q44	8-729-190-12	2SC2901
Q45	8-729-190-12	2SC2901
Q46	8-765-212-20	2SA925
Q47	8-729-190-12	2SC2901
Q48	8-729-190-12	2SC2901
Q49	8-729-190-12	2SC2901
Q50	8-765-212-20	2SA925
Q51	8-765-212-20	2SA925
Q52	8-729-190-12	2SC2901
Q53	8-724-375-01	2SC403C
Q54	8-729-612-77	2SA1027R
Q55	8-729-612-77	2SA1027R
Q56	8-724-375-01	2SC403C
RV1	1-228-292-00	VAR,2K
RV2	1-228-294-00	VAR,10K
RV3	1-228-295-00	VAR,20K
RV4	1-228-289-00	VAR,200
RV5	1-228-295-00	VAR,20K
RV6	1-228-292-00	VAR,2K
RV7	1-228-295-00	VAR,20K
RV8	1-228-295-00	VAR,20K
RV9	1-228-295-00	VAR,20K
RV12	1-228-295-00	VAR,20K
RV13	1-228-295-00	VAR,20K
RV14	1-228-292-00	VAR,2K
RV121	1-228-462-00	VAR,100K
RV122	1-228-462-00	VAR,100K
TH1	1-800-194-11	S-90
X1	1-567-076-00	10.700MHz

NOTES:

1. The shaded and -marked components are critical to safety. Replace only with same components as specified.

2. Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.

Ref.No. Parts No. Description

CK-14 BOARD

A-6711-430-A MOUNTED CIRCUIT BOARD,CK-14

C2	1-130-471-00	FILM 0.001 5Z 50V
C18	1-109-535-00	DIPPED MICA 100PF 5Z 100V
C23	1-109-537-00	DIPPED MICA 120PF 5Z 100V
C30	1-130-020-00	FILM 0.0015 5Z 50V
C33	1-109-526-00	DIPPED MICA 43PF 5Z 100V
C36	1-109-539-00	DIPPED MICA 150PF 5Z 100V
C43	1-131-345-00	TANTALUM 0.47 10Z 35V
C44	1-131-345-00	TANTALUM 0.47 10Z 35V
C48	1-130-471-00	FILM 0.001 5Z 50V
C51	1-131-347-00	TANTALUM 1.0 10Z 35V
C52	1-131-347-00	TANTALUM 1.0 10Z 35V
C53	1-130-020-00	FILM 0.0015 5Z 50V
C55	1-109-526-00	DIPPED MICA 43PF 5Z 100V
C60	1-130-489-00	FILM 0.033 5Z 50V
C63	1-130-471-00	FILM 0.001 5Z 50V
C76	1-131-373-00	TANTALUM 22 10Z 16V
C78	1-130-477-00	FILM 0.0033 5Z 50V
C89	1-109-545-00	DIPPED MICA 270PF 5Z 100V
C90	1-130-853-00	FILM 0.0047 5Z 100V
C123	1-109-549-00	DIPPED MICA 390PF 5Z 100V
C125	1-109-528-00	DIPPED MICA 51PF 5Z 100V
C126	1-109-531-00	DIPPED MICA 68PF 5Z 100V
C136	1-130-020-00	FILM 0.0015 5Z 50V
C139	1-131-349-00	TANTALUM 2.2 10Z 35V
C140	1-130-020-00	FILM 0.0015 5Z 50V
C141	1-109-525-00	DIPPED MICA 39PF 5Z 100V
C146	1-109-539-00	DIPPED MICA 150PF 5Z 100V
C157	1-130-471-00	FILM 0.001 5Z 50V
C159	1-131-347-00	TANTALUM 1.0 10Z 35V
C160	1-131-347-00	TANTALUM 1.0 10Z 35V
C163	1-109-525-00	DIPPED MICA 39PF 5Z 100V
C167	1-130-489-00	FILM 0.033 5Z 50V
C168	1-131-349-00	TANTALUM 2.2 10Z 35V
C169	1-131-349-00	TANTALUM 2.2 10Z 35V
C173	1-130-471-00	FILM 0.001 5Z 50V

Ref.No. Parts No. Description

C177	1-131-353-00	TANTALUM 10 10Z 35V
C179	1-130-853-00	FILM 0.0047 5Z 100V
C192	1-130-477-00	FILM 0.0033 5Z 50V
C203	1-109-545-00	DIPPED MICA 270PF 5Z 100V
C212	1-131-373-00	TANTALUM 22 10Z 16V
C221	1-107-204-00	MICA 12PF 5Z 500V
C224	1-131-353-00	TANTALUM 10 10Z 35V
C225	1-131-345-00	TANTALUM 0.47 10Z 35V
C234	1-107-157-00	MICA 27PF 5Z 500V
C251	1-131-347-00	TANTALUM 1.0 10Z 35V
C252	1-131-347-00	TANTALUM 1.0 10Z 35V
C258	1-130-491-00	FILM 0.047 5Z 50V
C277	1-109-539-00	DIPPED MICA 150PF 5Z 100V
C279	1-109-539-00	DIPPED MICA 150PF 5Z 100V
C286	1-109-561-00	DIPPED MICA 0.001 5Z 100V
C298	1-131-349-00	TANTALUM 2.2 10Z 35V
C299	1-131-353-00	TANTALUM 10 10Z 35V
C301	1-109-553-00	DIPPED MICA 470PF 5Z 100V
C304	1-130-483-00	FILM 0.01 5Z 50V
C525	1-130-483-00	FILM 0.01 5Z 50V

D1	8-719-901-33	1SS133
D2	8-719-901-33	1SS133
D3	8-719-901-33	1SS133
D4	8-719-901-33	1SS133
D5	8-719-901-33	1SS133
D7	8-719-901-33	1SS133
D8	8-719-901-33	1SS133
D9	8-719-901-33	1SS133
D10	8-719-901-33	1SS133
D11	8-719-901-33	1SS133
D12	8-719-901-33	1SS133
D13	8-719-901-33	1SS133
D14	8-719-901-33	1SS133
D15	8-719-901-33	1SS133
D16	8-719-901-33	1SS133
D17	8-719-901-33	1SS133
D19	8-719-901-33	1SS133
D20	8-719-901-33	1SS133
D21	8-719-901-33	1SS133
D22	8-719-901-33	1SS133
D23	8-719-101-97	1SS97
D24	8-719-815-80	1S1587
D25	8-719-901-33	1SS133
D26	8-719-901-33	1SS133
D27	8-719-901-33	1SS133

NOTES:

- The shaded and  -marked components are critical to safety. Replace only with same components as specified.

- Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.

Ref.No.	Parts No.	Description
D28	8-719-162-07	RD6.2E-B
D29	8-719-901-33	1SS133
D30	8-719-162-07	RD6.2E-B
D33	8-719-901-33	1SS133
D50	8-719-815-80	1S1587
IC1	8-759-900-74	SN74LS74AN(TI)
IC1B	8-759-902-74	SN74LS423N(TI)
IC1C	8-759-900-74	SN74LS74AN(TI)
IC1D	8-759-900-00	SN74LS00N(TI)
IC1E	8-759-900-11	SN74LS11N(TI)
IC1F	8-759-900-58	HA1-4905-5(HARRIS)
IC1GA	8-759-906-01	TL601CP(TI)
IC1GB	8-759-906-01	TL601CP(TI)
IC1HA	8-759-906-01	TL601CP(TI)
IC1HB	8-759-906-01	TL601CP(TI)
IC1I	8-759-901-23	SN74LS123N(TI)
IC1J	8-759-974-06	SN7406N(TI)
IC1K	8-759-103-19	uPC319C(NEC)
IC1L	8-759-900-74	SN74LS74AN(TI)
IC1M	8-759-900-00	SN74LS00N(TI)
IC1N	8-759-900-11	SN74LS11N(TI)
IC1P	8-759-900-58	HA1-4905-5(HARRIS)
IC2RA	8-759-906-01	TL601CP(TI)
IC2RB	8-759-906-01	TL601CP(TI)
IC2SA	8-759-906-01	TL601CP(TI)
IC2SB	8-759-906-01	TL601CP(TI)
IC1T	8-757-731-00	CX773A(SONY)
IC1U	8-759-300-25	HD10125(HITACHI)
IC1V	8-759-900-00	SN74LS00N(TI)
IC1X	8-757-903-00	CX7903(SONY)
IC1Y	8-759-103-19	uPC319C(NEC)
IC2A	8-759-301-24	HD10124(HITACHI)
IC2B	8-759-902-21	SN74LS221N(TI)
IC2C	8-759-901-63	SN74LS163AN(TI)
IC2D	8-759-902-21	SN74LS221N(TI)
IC2E	8-759-901-12	SN74LS112AN(TI)
IC2G	8-759-990-82	TL082CP(TI)
IC2H	8-759-990-84	TL084CN(TI)
IC2J	8-759-301-24	HD10124(HITACHI)
IC2K	8-759-902-21	SN74LS221N(TI)
IC2L	8-759-901-63	SN74LS163AN(TI)
IC2M	8-759-902-21	SN74LS221N(TI)
IC2N	8-759-901-12	SN74LS112AN(TI)
IC2R	8-759-990-82	TL082CP(TI)
IC2S	8-759-990-84	TL084CN(TI)

Ref.No.	Parts No.	Description
IC2T	8-759-943-65	SN74365AN(TI)
IC2U	8-759-974-04	SN7404N(TI)
IC2V	8-759-952-07	SN75207BN(TI)
IC2W	8-759-974-06	SN7406N(TI)
IC3A	8-759-001-98	MC10198L(MOTOROLA)
IC3B	8-759-901-63	SN74LS163AN(TI)
IC3C	8-759-914-00	SN7400N(TI)
IC3D	8-759-901-64	SN74LS164N(TI)
IC3E	8-759-900-08	SN74LS08N(TI)
IC3F	8-759-900-59	H11-201-5(HARRIS)
IC3G	8-749-938-10	BX381(SONY)
IC3H	8-759-900-59	H11-201-5(HARRIS)
IC3J	8-759-001-98	MC10198L(MOTOROLA)
IC3K	8-759-901-63	SN74LS163AN(TI)
IC3L	8-759-914-00	SN7400N(TI)
IC3M	8-759-901-64	SN74LS164N(TI)
IC3N	8-759-900-08	SN74LS08N(TI)
IC3P	8-759-900-59	H11-201-5(HARRIS)
IC3R	8-749-938-10	BX381(SONY)
IC3S	8-759-900-59	H11-201-5(HARRIS)
IC3T	8-759-901-64	SN74LS164N(TI)
IC3U	8-759-901-64	SN74LS164N(TI)
IC3V	8-759-902-21	SN74LS221N(TI)
IC3W	8-759-942-65	SN74265N(TI)
IC3X	8-749-938-10	BX381(SONY)
IC4A	8-759-001-98	MC10198L(MOTOROLA)
IC4B	8-759-911-63	SN74S163N(TI)
IC4C	8-759-900-74	SN74LS74AN(TI)
IC4D	8-759-901-23	SN74LS123N(TI)
IC4E	8-759-900-04	SN74LS04N(TI)
IC4F	8-759-145-57	uPC4557C(NEC)
IC4G	8-759-745-60	NJM4560D(JRC)
IC4H	8-759-952-07	SN75207BN(TI)
IC4J	8-759-001-98	MC10198L(MOTOROLA)
IC4K	8-759-911-63	SN74S163N(TI)
IC4L	8-759-900-74	SN74LS74AN(TI)
IC4M	8-759-901-23	SN74LS123N(TI)
IC4N	8-759-900-04	SN74LS04N(TI)
IC4P	8-759-145-57	uPC4557C(NEC)
IC4R	8-759-745-60	NJM4560D(JRC)
IC4S	8-759-952-07	SN75207BN(TI)
IC4T	8-759-901-64	SN74LS164N(TI)
IC4U	8-759-900-08	SN74LS08N(TI)
IC4V	8-759-974-04	SN7404N(TI)
IC4W	8-759-901-63	SN74LS163AN(TI)

NOTES:

1. The shaded and  -marked components are critical to safety. Replace only with same components as specified.

2. Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.

Ref.No.	Parts No.	Description
IC4Z	8-759-901-64	SN74LS164N(TI)
IC5A	8-759-300-25	HD10125(HITACHI)
IC5B	8-759-941-91	SN74191N(TI)
IC5C	8-759-901-74	SN74LS174N(TI)
IC5D	8-759-910-51	SN74S51N(TI)
IC5E	8-759-902-21	SN74LS221N(TI)
IC5F	8-759-902-21	SN74LS221N(TI)
IC5G	8-759-954-52	SN75452BP(TI)
IC5H	8-759-103-19	uPC319C(NEC)
IC5J	8-759-300-25	HD10125(HITACHI)
IC5K	8-759-941-91	SN74191N(TI)
IC5L	8-759-901-74	SN74LS174N(TI)
IC5M	8-759-910-51	SN74S51N(TI)
IC5N	8-759-902-21	SN74LS221N(TI)
IC5P	8-759-902-21	SN74LS221N(TI)
IC5R	8-759-954-52	SN75452BP(TI)
IC5S	8-759-103-19	uPC319C(NEC)
IC5T	8-759-901-64	SN74LS164N(TI)
IC5U	8-759-910-51	SN74S51N(TI)
IC5V	8-759-902-21	SN74LS221N(TI)
IC5W	8-759-901-63	SN74LS163AN(TI)
IC5X	8-759-911-63	SN74S163N(TI)
IC5Z	8-759-902-21	SN74LS221N(TI)
JP	1-560-733-00	PIN, SHORT
	1-561-832-00	SOCKET, SHORT
L1	1-408-409-00	MICRO 10
L2	1-408-409-00	MICRO 10
L3	1-421-329-00	10
L4	1-421-329-00	10
L5	1-421-329-00	10
L6	1-421-329-00	10
L7	1-408-409-00	MICRO 10
L8	1-408-409-00	MICRO 10
L9	1-408-409-00	MICRO 10
L10	1-408-409-00	MICRO 10
L11	1-408-409-00	MICRO 10
L12	1-408-409-00	MICRO 10
L13	1-421-329-00	10
L14	1-421-329-00	10
L15	1-408-409-00	MICRO 10
L16	1-407-932-00	MICRO 10
L18	1-408-409-00	MICRO 10
L19	1-408-409-00	MICRO 10
L20	1-408-409-00	MICRO 10
L21	1-408-409-00	MICRO 10

Ref.No.	Parts No.	Description
L22	1-408-409-00	MICRO 10
L24	1-407-923-00	MICRO 47
L27	1-421-329-00	10
L28	1-421-329-00	10
L29	1-408-409-00	MICRO 10
Q1	8-729-117-54	2SA1175
Q2	8-729-117-54	2SA1175
Q3	8-769-195-00	2SK43-5
Q4	8-729-117-54	2SA1175
Q5	8-729-672-43	2SC2724
Q6	8-729-117-54	2SA1175
Q7	8-724-375-01	2SC403C
Q8	8-724-375-01	2SC403C
Q9	8-724-375-01	2SC403C
RB1	1-231-521-00	3.3Kx4
RB2	1-231-521-00	3.3Kx4
RV1	1-228-293-00	VAR, 5K
RV2	1-228-294-00	VAR, 10K
RV3	1-228-292-00	VAR, 2K
RV5	1-228-291-00	VAR, 1K
RV6	1-228-294-00	VAR, 10K
RV7	1-228-293-00	VAR, 5K
RV8	1-228-293-00	VAR, 5K
RV9	1-228-292-00	VAR, 2K
RV12	1-228-294-00	VAR, 10K
RV13	1-224-940-00	VAR, 10K
RV14	1-228-293-00	VAR, 5K
RV20	1-224-940-00	VAR, METAL 10K
VC01W	1-527-729-00	VCO, 14.1875MHz
VC04X	1-567-088-00	VCO, 11.25MHz

CL-7 BOARD

1-608-052-00 PRINTED CIRCUIT BOARD, CL-7

NOTES:

1. The shaded and  -marked components are critical to safety. Replace only with same components as specified.

2. Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.

CP-52, CP-56, DE-11, DE-12, EN-20 (DU-33, DU-45, DU-48)

Ref.No.	Parts No.	Description
CP-52 BOARD		
	A-6728-526-A	MOUNTED CIRCUIT BOARD, CP-52
C5	1-108-603-00	MYLAR 0.1 5% 50V
Q1	8-729-663-47	2SC1364
Q2	8-729-805-13	2SC1475
Q3	8-729-805-13	2SC1475
R10	1-207-912-00	WIREWOUND 39 3W 10%
R11	1-207-912-00	WIREWOUND 39 3W 10%
R12	1-207-912-00	WIREWOUND 39 3W 10%
R17	1-244-865-00	CARBON 470 1/2W 5%
R21	1-244-865-00	CARBON 470 1/2W 5%
T1	1-427-284-00	OUTPUT
T2	1-427-284-00	OUTPUT

CP-56 BOARD		
	A-6728-588-A	MOUNTED CIRCUIT BOARD, CP-56
CN301	1-560-210-00	30P
CN302	1-560-190-00	20P

DE-11 BOARD		
	1-608-051-00	PRINTED CIRCUIT BOARD, DE-11
DM1	8-745-211-00	DM211
DM2	8-745-211-00	DM211

DE-12 BOARD		
	A-6715-158-A	MOUNTED CIRCUIT BOARD, DE-12
IC1	8-759-145-58	uPC4558C (NEC)
IC2	8-759-145-58	uPC4558C (NEC)

Ref.No.	Parts No.	Description
EN-20 BOARD		
	A-6711-412-B	MOUNTED CIRCUIT BOARD, EN-20 WITH DU-33, DU-45, DU-48 BOARD
DU-33 BOARD		
	1-609-652-00	PRINTED CIRCUIT BOARD, DU-33
CN601	1-560-035-00	5P
D603	8-719-815-55	1S1555
Q609	8-724-375-01	2SC403C
Q610	8-724-375-01	2SC403C

DU-45 BOARD		
	A-6710-452-A	MOUNTED CIRCUIT BOARD, DU-45
C1	1-127-447-00	ELECT 0.1 10% 25V
C2	1-127-447-00	ELECT 0.1 10% 25V
C5	1-107-208-00	MICA 18PF 5% 500V
CN1	1-560-469-00	6P
CN2	1-560-469-00	6P
IC1	8-759-902-21	SN74LS221N(TI)
IC2	8-759-902-21	SN74LS221N(TI)
IC3	8-759-900-74	SN74LS74AN(TI)
IC4	8-759-900-02	SN74LS02N(TI)
IC5	8-759-907-60	uA760HC(FSC)
IC6	8-759-103-19	uPC319C(NEC)
IC7	8-759-900-74	SN74LS74AN(TI)
RV1	1-228-473-00	VAR, 5K
RV2	1-228-473-00	VAR, 5K
RV4	1-228-473-00	VAR, 5K

DU-48 BOARD		
	1-610-460-00	PRINTED CIRCUIT BOARD, DU-48
IC1	8-759-902-21	SN74LS221N(TI)
RV1	1-228-459-00	VAR, 10K

NOTES:

- The shaded and  -marked components are critical to safety. Replace only with same components as specified.

- Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.

Ref.No. Parts No. Description

EN-20 BOARD

C210	1-107-159-00	MICA 33PF 5% 500V
C214	1-107-209-00	MICA 20PF 5% 500V
C224	1-107-203-00	MICA 11PF 5% 500V
C239	1-107-159-00	MICA 33PF 5% 500V
C241	1-107-209-00	MICA 20PF 5% 500V
C247	1-108-555-00	MYLAR 0.001 5% 50V
C254	1-108-555-00	MYLAR 0.001 5% 50V
C401	1-107-211-00	MICA 24PF 5% 500V
C414	1-130-491-00	FILM 0.047 5% 50V
C421	1-107-202-00	MICA 10PF 5% 500V
C427	1-107-202-00	MICA 10PF 5% 500V
C432	1-131-341-00	TANTALUM 0.1 10% 35V
C445	1-130-483-00	FILM 0.01 5% 50V
C446	1-130-483-00	FILM 0.01 5% 50V
C447	1-130-483-00	FILM 0.01 5% 50V
C448	1-130-483-00	FILM 0.01 5% 50V
C518	1-107-207-00	MICA 16PF 5% 500V
C524	1-107-209-00	MICA 20PF 5% 500V
C616	1-123-311-00	ELECT 1000 20% 10V
C624	1-107-209-00	MICA 20PF 5% 500V
C635	1-107-157-00	MICA 27PF 5% 500V
C649	1-108-555-00	MYLAR 0.001 5% 50V
C710	1-107-159-00	MICA 33PF 5% 500V
C739	1-107-159-00	MICA 33PF 5% 500V
C747	1-108-555-00	MYLAR 0.001 5% 50V
CV601	1-141-240-00	TRIMMER 20PF
D201	8-719-162-07	RD6.2E-B
D202	8-719-162-07	RD6.2E-B
D401	8-719-162-07	RD6.2E-B
D601	8-719-709-25	1S1925-P
D602	8-719-709-25	1S1925-P
D701	8-719-162-07	RD6.2E-B
D702	8-719-162-07	RD6.2E-B
DL501	1-415-184-00	100nS
DL601	1-415-096-00	0.3uS
FL601	1-231-578-00	LFP

Ref.No. Parts No. Description

IC201	8-749-936-51	BX365A(SONY)
IC202	8-759-906-01	TL601CP(TI)
IC203	8-759-145-57	uPC4557C(NEC)
IC204	8-759-930-54	CA3054(RCA)
IC205	8-759-907-93	uA796HC-B(FSC)
IC206	8-749-936-51	BX365A(SONY)
IC207	8-759-906-01	TL601CP(TI)
IC208	8-759-145-57	uPC4557C(NEC)
IC209	8-759-930-54	CA3054(RCA)
IC210	8-759-907-93	uA796HC-B(FSC)
IC211	8-759-902-21	SN74LS221N(TI)
IC212	8-759-951-10	SN75110AN(TI)
IC213	8-759-902-21	SN74LS221N(TI)
IC214	8-759-240-53	TC4053BP(TOSHIBA)
IC215	8-759-145-57	uPC4557C(NEC)
IC401	8-759-907-60	uA760HC(FSC)
IC402	8-759-900-10	SN74LS10N(TI)
IC403	8-749-938-10	BX381(SONY)
IC404	8-759-906-01	TL601CP(TI)
IC405	8-759-974-06	SN7406N(TI)
IC406	8-759-907-60	uA760HC(FSC)
IC407	8-759-901-63	SN74LS163AN(TI)
IC408	8-759-990-82	TL082CP(TI)
IC409	8-759-901-23	SN74LS123N(TI)
IC410	8-759-301-24	MC10124L(MOTOROLA)
IC411	8-759-301-31	HD10131(HITACHI)
IC412	8-759-001-13	MC10113L(MOTOROLA)
IC501	8-749-938-80	BX388(SONY)
IC502	8-749-936-61	BX366A(SONY)
IC503	8-749-936-61	BX366A(SONY)
IC504	8-759-220-04	TC40H004P(TOSHIBA)
IC505	8-759-974-06	SN7406N(TI)
IC506	8-749-936-51	BX365A(SONY)
IC601	8-749-936-61	BX366A(SONY)
IC602	8-749-936-51	BX365A(SONY)
IC603	8-749-936-61	BX366A(SONY)
IC605	8-749-936-61	BX366A(SONY)
IC607	8-749-936-61	BX366A(SONY)
IC608	8-759-906-07	TL607CP(TI)
IC609	8-759-906-07	TL607CP(TI)
IC610	8-759-906-07	TL607CP(TI)
IC611	8-741-109-90	BX1099(SONY)
IC612	8-749-938-80	BX388(SONY)
IC613	8-741-105-60	BX1056(SONY)
IC614	8-749-938-90	BX389(SONY)

NOTES:

- The shaded and  -marked components are critical to safety. Replace only with same components as specified.

- Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.

Ref.No.	Parts No.	Description
IC615	8-759-200-60	TA7060AP(TOSHIBA)
IC616	8-759-278-09	TA78L009AP(TOSHIBA)
IC617	8-759-208-94	CX894(SONY)
IC618	8-759-902-21	SN74LS221N(TI)
IC619	8-759-902-21	SN74LS221N(TI)
IC620	8-749-936-51	BX365A(SONY)
IC701	8-749-936-51	BX365A(SONY)
IC702	8-759-906-01	TL601CP(TI)
IC703	8-759-145-57	uPC4557C(NEC)
IC704	8-759-930-54	CA3054(RCA)
IC706	8-749-936-51	BX365A(SONY)
IC707	8-759-906-01	TL601CP(TI)
IC708	8-759-145-57	uPC4557C(NEC)
IC709	8-759-930-54	CA3054(RCA)
IC711	8-759-902-21	SN74LS221N(TI)
LV501	1-407-574-00	VAR, 68
LV601	1-407-573-00	VAR, 47
Q201	8-724-375-01	2SC403C
Q202	8-724-375-01	2SC403C
Q203	8-724-375-01	2SC403C
Q204	8-724-375-01	2SC403C
Q205	8-729-602-67	2SA1026-7
Q206	8-724-375-01	2SC403C
Q501	8-724-375-01	2SC403C
Q503	8-729-384-47	2SA844
Q504	8-761-622-00	2SC1636
Q505	8-761-622-00	2SC1636
Q506	8-761-622-00	2SC1636
Q507	8-729-384-47	2SA844
Q508	8-724-375-01	2SC403C
Q601	8-729-612-77	2SA1027R
Q602	8-729-612-77	2SA1027R
Q603	8-724-375-01	2SC403C
Q604	8-724-375-01	2SC403C
Q605	8-724-375-01	2SC403C
Q606	8-724-375-01	2SC403C
Q607	8-724-375-01	2SC403C
Q608	8-724-375-01	2SC403C
Q701	8-724-375-01	2SC403C
Q703	8-724-375-01	2SC403C

Ref.No.	Parts No.	Description
RV201	1-228-294-00	VAR, 10K
RV202	1-228-294-00	VAR, 10K
RV203	1-228-294-00	VAR, 10K
RV204	1-228-290-00	VAR, 500
RV205	1-228-294-00	VAR, 10K
RV206	1-228-293-00	VAR, 5K
RV207	1-228-293-00	VAR, 5K
RV208	1-228-292-00	VAR, 2K
RV209	1-228-293-00	VAR, 5K
RV210	1-228-293-00	VAR, 5K
RV401	1-228-291-00	VAR, 1K
RV402	1-228-292-00	VAR, 2K
RV403	1-228-297-00	VAR, 100K
RV501	1-228-291-00	VAR, 1K
RV502	1-228-291-00	VAR, 1K
RV503	1-228-293-00	VAR, 5K
RV504	1-228-291-00	VAR, 1K
RV601	1-228-293-00	VAR, 5K
RV602	1-228-291-00	VAR, 1K
RV603	1-228-291-00	VAR, 1K
RV604	1-228-291-00	VAR, 1K
RV605	1-228-291-00	VAR, 1K
RV606	1-228-290-00	VAR, 500
RV607	1-228-289-00	VAR, 200
RV608	1-228-293-00	VAR, 5K
RV609	1-228-294-00	VAR, 10K
RV610	1-228-293-00	VAR, 5K
RV611	1-228-458-00	VAR, 5K
RV701	1-228-294-00	VAR, 10K
RV703	1-228-294-00	VAR, 10K
RV706	1-228-293-00	VAR, 5K
SW501	1-552-509-00	SLIDE
SW502	1-552-509-00	SLIDE
X401	1-527-585-00	VCO 17.734475MHz
X601	1-527-374-00	5.357422MHz
EX-30 BOARD		
A-6725-308-A		EXTENSION BOARD, EX-30
1-560-919-21		CONNECTOR, 60P

NOTES:

- The shaded and -marked components are critical to safety. Replace only with same components as specified.

- Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.

EX-31, HE-5, HP-7, KY-32 (DP-30)

Ref.No. Parts No. Description

EX-31 BOARD

A-6725-309-B EXTENSION BOARD, EX-31
1-560-919-21 CONNECTOR, 60P

HE-5 BOARD

1-608-056-00 PRINTED CIRCUIT BOARD, HE-5

R2 1-217-074-00 WIREWOUND, 47 5W 10X

HP-7 BOARD

1-608-062-00 PRINTED CIRCUIT BOARD, HP-7

J1 1-507-553-00 JACK "HEADPHONES"

KY-32 BOARD

A-6728-530-A MOUNTED CIRCUIT BOARD, KY-32
WITH DP-30

DP-30 BOARD

1-607-973-00 PRINTED CIRCUIT BOARD, DP-30

D15 8-719-803-21 LED, 7-SEG TLR321
D16 8-719-803-21 LED, 7-SEG TLR321
D17 8-719-803-21 LED, 7-SEG TLR321
D18 8-719-803-21 LED, 7-SEG TLR321

S9 1-552-539-00 KEY "RESET"

KY-32 BOARD

CN1 1-560-902-00 16P
CN3 1-560-538-00 6P

Ref.No. Parts No. Description

D1 8-719-815-55 1S1555
D2 8-719-815-55 1S1555
D3 8-719-815-55 1S1555
D4 8-719-815-55 1S1555
D5 8-719-815-55 1S1555

D6 8-719-815-55 1S1555
D7 8-719-815-55 1S1555
D8 8-719-815-55 1S1555
D9 8-719-815-55 1S1555
D10 8-719-815-55 1S1555

D11 8-719-815-55 1S1555
D12 8-719-904-55 LED, GL-5HD5
D13 8-719-904-55 LED, GL-5HD5
D14 8-719-904-55 LED, GL-5HD5
D19 8-719-815-55 1S1555

IC1 8-759-145-84 uPD4584BC(NEC)
IC2 8-759-145-84 uPD4584BC(NEC)
IC3 8-759-145-19 uPD4519BC(NEC)
IC4 8-759-240-81 TC4081BP(TOSHIBA)
IC5 8-759-240-13 TC4013BP(TOSHIBA)

IC6 8-759-900-37 SN74LS37N(TI)
IC7 8-759-245-16 TC4516BP(TOSHIBA)
IC8 8-759-240-21 TC4021BP(TOSHIBA)
IC9 8-759-645-17 M54517P(MITSUBISHI)
IC10 8-759-940-94 MSM4094RS(OKI)

IC11 8-759-645-17 M54517P(MITSUBISHI)
IC12 8-759-940-94 MSM4094RS(OKI)
IC13 8-759-240-21 TC4021BP(TOSHIBA)
IC14 8-759-984-70 MB84070B(FUJITSU)
IC15 8-759-245-43 TC4543BP(TOSHIBA)

IC16 8-759-245-16 TC4516BP(TOSHIBA)
IC17 8-759-645-17 M54517P(MITSUBISHI)
IC18 8-759-200-18 TC40H042P(TOSHIBA)
IC19 8-759-240-50 TC4050BP(TOSHIBA)

PL1 1-518-386-00 5V, 30mA
PL2 1-518-386-00 5V, 30mA
PL3 1-518-386-00 5V, 30mA

Q1 8-729-374-02 2SB740
Q2 8-729-374-02 2SB740
Q3 8-729-374-02 2SB740
Q4 8-729-374-02 2SB740
Q5 8-729-374-02 2SB740

NOTES:

- The shaded and -marked components are critical to safety. Replace only with same components as specified.

- Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.

KY-32, LA-4, LE-19, LM-4, MB-41, MB-42

Ref.No. Parts No. Description

Q6 8-729-374-02 2SB740
Q7 8-729-374-02 2SB740
Q8 8-729-374-02 2SB740

RB1 1-231-407-00 2.2Kx8
RB2 1-231-407-00 2.2Kx8
RB3 1-231-410-00 10Kx8
RB4 1-231-410-00 10Kx8

S1 1-553-550-31 KEY,12 SQUARE "EJECT"
1-518-450-11 PILOT LAMP 5V 60mA
3-706-480-21 KEY TOP(BLUE)
S2 1-553-550-11 KEY,12 SQUARE "STANDBY"
1-518-450-11 PILOT LAMP 5V 60mA
3-706-480-01 KEY TOP(WHITE)
S3 1-553-551-11 KEY,17 SQUARE "REW"
1-518-450-21 PILOT LAMP 5V 60mA
3-706-481-01 KEY TOP(WHITE)
S4 1-553-551-11 KEY,17 SQUARE "PLAY"
1-518-450-21 PILOT LAMP 5V 60mA
3-706-481-01 KEY TOP(WHITE)
S5 1-553-551-11 KEY,17 SQUARE "F FWD"
1-518-450-21 PILOT LAMP 5V 60mA
3-706-481-01 KEY TOP(WHITE)
S6 1-553-551-32 KEY,17 SQUARE "STOP"
1-518-450-21 PILOT LAMP 5V 60mA
3-706-481-21 KEY TOP(BLUE)
S7 1-553-550-11 KEY,12 SQUARE "SEARCH"
1-518-450-11 PILOT LAMP 5V 60mA
3-706-480-01 KEY TOP(WHITE)
S8 1-516-994-00 SLIDE "COUNTER SELECT"

LA-4 BOARD

1-608-057-00 PRINTED CIRCUIT BOARD,LA-4

D1 8-719-812-44 LED,T10124 "AUTO OFF"

LE-19 BOARD

1-608-053-00 PRINTED CIRCUIT BOARD,LE-19

D1 8-719-103-01 LED,SE301A

Ref.No. Parts No. Description

LM-4 BOARD

1-585-913-00 PRINTED CIRCUIT BOARD,LM-4

L1 1-407-696-00 MICRO,18 10Z

L2 1-407-696-00 MICRO,18 10Z

MB-41 BOARD

A-6275-295-A MOUNTED CIRCUIT BOARD,MB-41

CN1 to 1-560-919-31 60P
CN12

CN115 1-555-700-21 FLAT CABLE ASS'Y,34P

CN116 1-560-564-00 6P

1-561-219-00 SOCKET

1-561-254-00 CONTACT

CN117 1-560-034-00 6P

1-561-219-00 SOCKET

1-561-254-00 CONTACT

CN118 1-560-034-00 6P

1-561-219-00 SOCKET

1-561-254-00 CONTACT

CN119 1-556-459-00 FLAT CABLE ASS'Y,50P

CN126 1-560-466-00 3P

CN130 1-560-902-00 HEADER,16P

MB-42 BOARD

A-6725-296-A MOUNTED CIRCUIT BOARD,MB-42

CN1 to 1-560-919-31 60P
CN6

CN207 1-560-564-00 6P

1-561-219-00 SOCKET

1-561-254-00 CONTACT

CN208 1-560-034-00 6P

1-561-219-00 SOCKET

1-561-254-00 CONTACT

CN209 1-560-034-00 6P

1-561-219-00 SOCKET

1-561-254-00 CONTACT

CN210 1-560-918-00 HEADER,50P

NOTES:

1. The shaded and -marked components are critical to safety. Replace only with same components as specified.

2. Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.

Ref.No. Parts No. Description

MY-17 BOARD

A-6711-416-A MOUNTED CIRCUIT BOARD, MY-17

C5	1-130-474-00	FILM 0.0018 5% 50V
C6	1-130-483-00	FILM 0.01 5% 50V
C27	1-130-471-00	FILM 0.001 5% 50V
C28	1-107-207-00	MICA 16PF 5% 500V
C29	1-107-207-00	MICA 16PF 5% 500V
C36	1-130-474-00	FILM 0.0018 5% 50V
C49	1-130-471-00	FILM 0.001 5% 50V
C50	1-130-471-00	FILM 0.001 5% 50V
IC1A	8-759-901-64	SN74LS164N(TI)
IC1B	8-759-901-64	SN74LS164N(TI)
IC1C	8-759-901-64	SN74LS164N(TI)
IC1D	8-759-901-66	SN74LS166AN(TI)
IC1E	8-759-903-74	SN74LS374N(TI)
IC1F	8-759-901-64	SN74LS164N(TI)
IC1G	8-759-901-66	SN74LS166AN(TI)
IC1H	8-759-901-61	SN74LS161AN(TI)
IC1J	8-759-901-61	SN74LS161AN(TI)
IC1M	8-759-974-08	SN7408N(TI)
IC2A	8-759-903-74	SN74LS374N(TI)
IC2B	8-759-903-74	SN74LS374N(TI)
IC2C	8-759-901-64	SN74LS164N(TI)
IC2D	8-759-901-28	MSM5128-12RS(OKI)
IC2E	8-759-901-64	SN74LS164N(TI)
IC2F	8-759-901-66	SN74LS166AN(TI)
IC2G	8-759-901-28	MSM5128-12RS(OKI)
IC2H	8-759-901-57	SN74LS157N(TI)
IC2J	8-759-901-61	SN74LS161AN(TI)
IC2K	8-759-901-61	SN74LS161AN(TI)
IC2L	8-759-902-21	SN74LS221N(TI)
IC2M	8-759-901-64	SN74LS164N(TI)
IC2N	8-759-901-64	SN74LS164N(TI)
IC3A	8-759-901-66	SN74LS166AN(TI)
IC3B	8-759-901-66	SN74LS166AN(TI)
IC3C	8-759-901-64	SN74LS164N(TI)
IC3E	8-759-901-64	SN74LS164N(TI)
IC3F	8-759-903-74	SN74LS374N(TI)
IC3H	8-759-901-57	SN74LS157N(TI)
IC3J	8-759-901-75	SN74LS175N(TI)
IC3K	8-759-901-75	SN74LS175N(TI)
IC3L	8-759-901-61	SN74LS161AN(TI)
IC3M	8-759-900-74	SN74LS74AN(TI)
IC3N	8-759-900-74	SN74LS74AN(TI)
IC4A	8-759-901-66	SN74LS166AN(TI)

Ref.No. Parts No. Description

IC4B	8-759-901-66	SN74LS166AN(TI)
IC4C	8-759-903-74	SN74LS374N(TI)
IC4D	8-759-901-28	MSM5128-12RS(OKI)
IC4E	8-759-903-74	SN74LS374N(TI)
IC4F	8-759-901-66	SN74LS166AN(TI)
IC4G	8-759-901-28	MSM5128-12RS(OKI)
IC4H	8-759-901-57	SN74LS157N(TI)
IC4J	8-759-901-75	SN74LS175N(TI)
IC4K	8-759-901-63	SN74LS163AN(TI)
IC4L	8-759-901-51	SN74LS151N(TI)
IC4M	8-759-900-30	SN74LS30N(TI)
IC4N	8-759-900-74	SN74LS74AN(TI)
IC5A	8-759-901-66	SN74LS166AN(TI)
IC5B	8-759-901-66	SN74LS166AN(TI)
IC5C	8-759-903-74	SN74LS374N(TI)
IC5D	8-759-901-28	MSM5128-12RS(OKI)
IC5E	8-759-901-64	SN74LS164N(TI)
IC5F	8-759-903-74	SN74LS374N(TI)
IC5G	8-759-901-28	MSM5128-12RS(OKI)
IC5H	8-759-901-57	SN74LS157N(TI)
IC5J	8-759-901-63	SN74LS163AN(TI)
IC5K	8-759-900-85	SN74LS85N(TI)
IC5L	8-759-903-93	SN74LS393N(TI)
IC5M	8-759-900-04	SN74LS04N(TI)
IC5N	8-759-900-04	SN74LS04N(TI)
IC6A	8-759-901-66	SN74LS166AN(TI)
IC6B	8-759-901-66	SN74LS166AN(TI)
IC6C	8-759-901-64	SN74LS164N(TI)
IC6E	8-759-901-64	SN74LS164N(TI)
IC6F	8-759-901-64	SN74LS164N(TI)
IC6H	8-759-901-61	SN74LS161AN(TI)
IC6J	8-759-901-61	SN74LS161AN(TI)
IC6K	8-759-901-91	SN74LS191N(TI)
IC6L	8-759-900-00	SN74LS00N(TI)
IC6M	8-759-900-74	SN74LS74AN(TI)
IC6P	8-759-900-00	SN74LS00N(TI)
IC7A	8-759-901-66	SN74LS166AN(TI)
IC7B	8-759-901-66	SN74LS166AN(TI)
IC7C	8-759-901-64	SN74LS164N(TI)
IC7D	8-759-901-28	MSM5128-12RS(OKI)
IC7E	8-759-901-66	SN74LS166AN(TI)
IC7F	8-759-901-66	SN74LS166AN(TI)
IC7G	8-759-901-28	MSM5128-12RS(OKI)
IC7H	8-759-901-57	SN74LS157N(TI)
IC7J	8-759-901-57	SN74LS157N(TI)

NOTES:

1. The shaded and  -marked components are critical to safety. Replace only with same components as specified.

2. Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.

MY-17, PB-8, PC-9

Ref.No.	Parts No.	Description
IC7K	8-759-901-61	SN74LS161AN(TI)
IC7L	8-759-900-08	SN74LS08N(TI)
IC7M	8-759-902-21	SN74LS221N(TI)
IC7N	8-759-901-23	SN74LS123N(TI)
IC7P	8-759-901-64	SN74LS164N(TI)
IC8A	8-759-901-66	SN74LS166AN(TI)
IC8B	8-759-901-66	SN74LS166AN(TI)
IC8C	8-759-903-74	SN74LS374N(TI)
IC8E	8-759-903-74	SN74LS374N(TI)
IC8F	8-759-901-64	SN74LS164N(TI)
IC8H	8-759-901-57	SN74LS157N(TI)
IC8J	8-759-901-57	SN74LS157N(TI)
IC8K	8-759-901-61	SN74LS161AN(TI)
IC8L	8-759-901-91	SN74LS191N(TI)
IC8M	8-759-900-00	SN74LS00N(TI)
IC8N	8-759-974-04	SN7404N(TI)
IC8P	8-759-974-04	SN7404N(TI)
IC9A	8-759-901-66	SN74LS166AN(TI)
IC9B	8-759-901-66	SN74LS166AN(TI)
IC9C	8-759-901-64	SN74LS164N(TI)
IC9D	8-759-901-28	MSM5128-12RS(OKI)
IC9E	8-759-901-66	SN74LS166AN(TI)
IC9F	8-759-901-64	SN74LS164N(TI)
IC9G	8-759-901-28	MSM5128-12RS(OKI)
IC9H	8-759-901-63	SN74LS163AN(TI)
IC9J	8-759-904-96	MBM2149L-55(FUJITSU)
IC9K	8-759-901-23	SN74LS123N(TI)
IC9L	8-759-901-61	SN74LS161AN(TI)
IC9M	8-759-900-04	SN74LS04N(TI)
IC9N	8-759-901-61	SN74LS161AN(TI)
IC9P	8-759-900-00	SN74LS00N(TI)
IC10A	8-759-901-66	SN74LS166AN(TI)
IC10B	8-759-901-66	SN74LS166AN(TI)
IC10C	8-759-903-74	SN74LS374N(TI)
IC10D	8-759-901-28	MSM5128-12RS(OKI)
IC10E	8-759-901-66	SN74LS166AN(TI)
IC10F	8-759-903-74	SN74LS374N(TI)
IC10G	8-759-901-28	MSM5128-12RS(OKI)
IC10H	8-759-901-63	SN74LS163AN(TI)
IC10J	8-759-904-96	MBM2149L-55(FUJITSU)
IC10L	8-759-900-74	SN74LS74AN(TI)
IC10M	8-759-914-00	SN7400N(TI)
IC10N	8-759-901-61	SN74LS161AN(TI)
IC10P	8-759-901-61	SN74LS161AN(TI)
IC11A	8-759-901-66	SN74LS166AN(TI)

Ref.No.	Parts No.	Description
IC11B	8-759-901-66	SN74LS166AN(TI)
IC11C	8-759-903-74	SN74LS374N(TI)
IC11E	8-759-903-74	SN74LS374N(TI)
IC11F	8-759-903-74	SN74LS374N(TI)
IC11H	8-759-901-63	SN74LS163AN(TI)
IC11J	8-759-903-74	SN74LS374N(TI)
IC11K	8-759-900-02	SN74LS02N(TI)
IC11L	8-759-903-74	SN74LS374N(TI)
IC11M	8-759-903-74	SN74LS374N(TI)
IC11N	8-759-900-04	SN74LS04N(TI)
IC12A	8-759-903-74	SN74LS374N(TI)
IC12B	8-759-903-74	SN74LS374N(TI)
IC12C	8-759-901-64	SN74LS164N(TI)
IC12D	8-759-901-28	MSM5128-12RS(OKI)
IC12E	8-759-942-73	SN74273N(TI)
IC12F	8-759-900-04	SN74LS04N(TI)
IC12G	8-759-901-64	SN74LS164N(TI)
IC12H	8-759-974-04	SN7404N(TI)
IC12J	8-759-900-74	SN74LS74AN(TI)
IC12K	8-759-900-04	SN74LS04N(TI)
IC12N	8-759-900-04	SN74LS04N(TI)
L1	1-421-329-00	5.6
RB1	1-231-450-00	3.3Kx8
RB2	1-231-450-00	3.3Kx8
PB-8 BOARD		
Do not replace Mounted Circuit Board, PB-8. Replace the entire DRUM ASS'Y, UPPER A-6762-103-A.		
PC-9 BOARD		
1-604-351-00 PRINTED CIRCUIT BOARD, PC-9		
C1	1-131-379-00	TANTALUM 22 10% 10V
IC1	8-759-133-90	uPC339C (NEC)
IC2	8-719-104-42	PS4005-L (NEC)
IC3	8-719-104-42	PS4005-L (NEC)
IC4	8-719-104-42	PS4005-L (NEC)

NOTES:

- The shaded and  -marked components are critical to safety.
Replace only with same components as specified.

- Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.

PC-14, PC-17, PC-18, PD-20, PH-16, PR-48

Ref.No. Parts No. Description

PC-14 BOARD

1-604-353-00 PRINTED CIRCUIT BOARD, PC-14

IC1 8-719-104-42 PS4005-L (NEC)

PC-17 BOARD

1-608-070-00 PRINTED CIRCUIT BOARD, PC-17

PH1 8-719-104-42 PS4005-L (NEC)

PC-18 BOARD

1-608-071-00 PRINTED CIRCUIT BOARD, PC-18

PH1 8-719-104-42 PS4005-L (NEC)

PD-20 BOARD

1-608-069-00 PRINTED CIRCUIT BOARD, PD-20

PH-16 BOARD

1-608-054-00 PRINTED CIRCUIT BOARD, PH-16

Q1 8-729-206-01 PHOTO, TPS601

Ref.No. Parts No. Description

PR-48 BOARD

A-6711-431-A MOUNTED CIRCUIT BOARD, PR-41

C7 1-109-530-00 DIPPED MICA 62PF 5Z 100V
C10 1-130-475-00 FILM 0.0022 5Z 50V
C11 1-131-371-00 TANTALUM 10 10Z 16V
C12 1-131-371-00 TANTALUM 10 10Z 16V
C13 1-131-371-00 TANTALUM 10 10Z 16V

C14 1-131-371-00 TANTALUM 10 10Z 16V
C21 1-130-487-00 FILM 0.022 5Z 50V
C22 1-107-206-00 MICA 15PF 5Z 500V
C40 1-107-048-00 MICA 6.8PF 500V
C56 1-130-483-00 FILM 0.01 5Z 50V

C57 1-130-487-00 FILM 0.022 5Z 50V
C58 1-131-371-00 TANTALUM 10 10Z 16V
C59 1-131-371-00 TANTALUM 10 10Z 16V
C62 1-109-530-00 DIPPED MICA 62PF 5Z 100V
C73 1-130-471-00 FILM 0.001 5Z 50V

C74 1-107-206-00 MICA 15PF 5Z 500V
C75 1-131-374-00 TANTALUM 33 10Z 16V
C85 1-109-535-00 DIPPED MICA 100PF 5Z 100V
C94 1-107-048-00 MICA 6.8PF 500V
C99 1-131-374-00 TANTALUM 33 10Z 16V

C100 1-109-527-00 DIPPED MICA 47PF 5Z 100V
C101 1-109-542-00 DIPPED MICA 220PF 5Z 100V
C106 1-109-527-00 DIPPED MICA 47PF 5Z 100V
C107 1-109-542-00 DIPPED MICA 220PF 5Z 100V
C109 1-121-651-00 ELECT 10 16V

C111 1-121-651-00 ELECT 10 16V
C112 1-130-479-00 FILM 0.0047 5Z 50V
C115 1-109-525-00 DIPPED MICA 39PF 5Z 100V
C118 1-107-159-00 MICA 33PF 5Z 500V
C119 1-109-527-00 DIPPED MICA 47PF 5Z 100V

C122 1-131-345-00 TANTALUM 0.47 10Z 35V
C128 1-109-547-00 DIPPED MICA 330PF 5Z 100V
C129 1-131-345-00 TANTALUM 0.47 10Z 35V
C137 1-130-479-00 FILM 0.0047 5Z 50V
C139 1-131-349-00 TANTALUM 2.2 10Z 35V

C140 1-130-483-00 FILM 0.01 5Z 50V
C141 1-130-483-00 FILM 0.01 5Z 50V
C142 1-109-547-00 DIPPED MICA 330PF 5Z 100V
C145 1-109-547-00 DIPPED MICA 330PF 5Z 100V
C147 1-109-535-00 DIPPED MICA 100PF 5Z 100V

C148 1-109-547-00 DIPPED MICA 330PF 5Z 100V
C154 1-131-349-00 TANTALUM 2.2 10Z 35V
C155 1-130-479-00 FILM 0.0047 5Z 50V
C160 1-109-548-00 DIPPED MICA 360PF 5Z 100V
C165 1-109-537-00 DIPPED MICA 120PF 5Z 100V

NOTES:

1. The shaded and -marked components are critical to safety. Replace only with same components as specified.

2. Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.

Ref.No.	Parts No.	Description
C167	1-109-535-00	DIPPED MICA 100PF 5% 100V
C168	1-109-548-00	DIPPED MICA 360PF 5% 100V
C169	1-130-475-00	FILM 0.0022 5% 50V
C170	1-109-533-00	DIPPED MICA 82PF 5% 100V
C174	1-130-479-00	FILM 0.0047 5% 50V
C176	1-109-530-00	DIPPED MICA 62PF 5% 100V
C178	1-107-202-00	MICA 10PF 5% 500V
C181	1-109-530-00	DIPPED MICA 62PF 5% 100V
C186	1-109-530-00	DIPPED MICA 62PF 5% 100V
C203	1-131-349-00	TANTALUM 2.2 10% 35V
C208	1-107-211-00	MICA 24PF 5% 500V
C209	1-107-211-00	MICA 24PF 5% 500V
C210	1-107-211-00	MICA 24PF 5% 500V
C211	1-107-211-00	MICA 24PF 5% 500V
C212	1-107-211-00	MICA 24PF 5% 500V
C213	1-107-211-00	MICA 24PF 5% 500V
C214	1-107-211-00	MICA 24PF 5% 500V
C215	1-107-211-00	MICA 24PF 5% 500V
C217	1-107-211-00	MICA 24PF 5% 500V
C219	1-107-211-00	MICA 24PF 5% 500V
C220	1-107-211-00	MICA 24PF 5% 500V
C221	1-107-211-00	MICA 24PF 5% 500V
C222	1-107-211-00	MICA 24PF 5% 500V
C223	1-107-211-00	MICA 24PF 5% 500V
C224	1-107-211-00	MICA 24PF 5% 500V
C225	1-107-211-00	MICA 24PF 5% 500V
C226	1-107-211-00	MICA 24PF 5% 500V
C231	1-107-211-00	MICA 24PF 5% 500V
C232	1-107-211-00	MICA 24PF 5% 500V
C233	1-107-211-00	MICA 24PF 5% 500V
C234	1-107-211-00	MICA 24PF 5% 500V
C235	1-107-211-00	MICA 24PF 5% 500V
C236	1-107-211-00	MICA 24PF 5% 500V
C237	1-107-211-00	MICA 24PF 5% 500V
C238	1-107-211-00	MICA 24PF 5% 500V
C239	1-107-211-00	MICA 24PF 5% 500V
C246	1-131-349-00	TANTALUM 2.2 10% 35V
C247	1-131-349-00	TANTALUM 2.2 10% 35V
C248	1-107-048-00	MICA 6.8PF 500V
C249	1-107-211-00	MICA 24PF 5% 500V
C250	1-130-475-00	FILM 0.0022 5% 50V
C252	1-107-048-00	MICA 6.8PF 500V
C253	1-130-475-00	FILM 0.0022 5% 50V
C257	1-131-349-00	TANTALUM 2.2 10% 35V
C258	1-131-349-00	TANTALUM 2.2 10% 35V
C275	1-121-651-00	ELECT 10 16V
C501	1-109-555-00	DIPPED MICA 560PF 5% 100V

Ref.No.	Parts No.	Description
D1	8-719-815-55	1S1555
D2	8-719-908-10	QSC8-1754(4PCS)
D3		
D4		
D5		
D6	8-719-815-80	1S1587
D7	8-719-815-80	1S1587
D8	8-719-102-51	1SZ51
D9	8-719-815-55	1S1555
D10	8-719-908-10	QSC8-1754(4PCS)
D11		
D13		
D14		
D15	8-719-815-80	1S1587
D16	8-719-815-80	1S1587
D17	8-719-815-55	1S1555
D18	8-719-815-55	1S1555
D19	8-719-815-55	1S1555
D20	8-719-815-55	1S1555
D21	8-719-815-55	1S1555
D22	8-719-815-55	1S1555
D23	8-719-815-55	1S1555
D24	8-719-815-55	1S1555
D25	8-719-815-55	1S1555
D26	8-719-815-55	1S1555
D27	8-719-100-58	RD10EB3
D28	8-719-815-55	1S1555
DL1	1-415-168-00	200nS
DL2	1-415-173-00	50nS
DL1	1-415-173-00	50nS
FB1	1-535-178-00	
FB2	1-535-178-00	
FB3	1-535-178-00	
FB4	1-535-178-00	
IC1	8-749-936-51	BX365A(SONY)
IC2	8-759-900-59	HI1-201-5(HARRIS)
IC3	8-759-990-82	TL082CP(TI)
IC4	8-752-005-20	CX20052(SONY)
IC5	8-759-301-05	HD10105(HITACHI)
IC7	8-759-300-25	HD10125(HITACHI)
IC8	8-759-300-25	HD10125(HITACHI)
IC9	8-759-145-57	uPC4557C(NEC)
IC10	8-749-936-51	BX365A(SONY)
IC11	8-759-990-82	TL082CP(TI)

NOTES:

- The shaded and -marked components are critical to safety.
Replace only with same components as specified.

- Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.

Ref.No.	Parts No.	Description
IC12	8-759-900-59	HI1-201-5(HARRIS)
IC13	8-759-990-82	TL082CP(TI)
IC14	8-752-005-20	CX20052(SONY)
IC15	8-759-301-05	HD10105(HITACHI)
IC17	8-759-300-25	HD10125(HITACHI)
IC18	8-759-300-25	HD10125(HITACHI)
IC19	8-749-936-51	BX365A(SONY)
IC20	8-759-103-19	uPC319C(NEC)
IC21	8-749-936-51	BX365A(SONY)
IC22	8-759-103-19	uPC319C(NEC)
IC23	8-759-900-58	HA1-4905-5(HARRIS)
IC24	8-759-990-84	TL084CN(TI)
IC25	8-759-900-59	HI1-201-5(HARRIS)
IC26	8-759-901-23	SN74LS123N(TI)
IC27	8-759-900-59	HI1-201-5(HARRIS)
IC28	8-759-902-21	SN74LS221N(TI)
IC29	8-759-954-54	SN75454BP(TI)
IC30	8-759-900-58	HA1-4905-5(HARRIS)
IC31	8-759-990-84	TL084CN(TI)
IC32	8-759-900-58	HA1-4905-5(HARRIS)
IC33	8-759-900-59	HI1-201-5(HARRIS)
IC34	8-759-900-00	SN74LS00N(TI)
IC35	8-759-902-74	SN74LS74AN(TI)
IC36	8-759-902-21	SN74LS221N(TI)
IC37	8-759-900-20	SN74LS20N(TI)
IC38	8-759-245-28	TC4528BP(TOSHIBA)
IC39	8-759-902-21	SN74LS221N(TI)
IC40	8-759-240-22	TC4022BP(TOSHIBA)
IC41	8-749-936-51	BX365A(SONY)
IC42	8-749-936-51	BX365A(SONY)
IC43	8-749-936-51	BX365A(SONY)
IC44	8-752-005-11	CX20051(SONY)
IC45	8-752-005-11	CX20051(SONY)
IC46	8-752-005-11	CX20051(SONY)
IC47	8-759-145-57	uPC4557C(NEC)
IC48	8-759-990-82	TL082CP(TI)
IC49	8-759-906-07	TL607CP(TI)
IC50	8-759-906-07	TL607CP(TI)
IC51	8-759-990-82	TL082CP(TI)
IC52	8-759-145-57	uPC4557C(NEC)
IC53	8-759-001-98	MC10198L(MOTOROLA)
IC54	8-759-910-32	SN74S32N(TI)
IC55	8-759-901-63	SN74LS163AN(TI)
IC56	8-759-942-73	SN74273N(TI)
IC57	8-759-904-96	MBM2149L-55(FUJITSU)

Ref.No.	Parts No.	Description
IC58	8-759-904-96	MBM2149L-55(FUJITSU)
IC59	8-759-904-96	MBM2149L-55(FUJITSU)
IC60	8-759-904-96	MBM2149L-55(FUJITSU)
IC61	8-759-942-73	SN74273N(TI)
IC62	8-759-900-04	SN74LS04N(TI)
IC63	8-759-900-13	SN74LS113AN(TI)
IC64	8-759-903-74	SN74LS374N(TI)
IC65	8-759-901-63	SN74LS163AN(TI)
IC66	8-759-902-73	SN74LS273N(TI)
IC67	8-759-902-73	SN74LS273N(TI)
IC68	8-759-902-73	SN74LS273N(TI)
IC69	8-759-903-74	SN74LS374N(TI)
IC72	8-759-179-05	uPC7905H(NEC)
L1	1-421-329-00	5.6
L2	1-421-329-00	5.6
L3	1-408-422-00	120 5Z
L4	1-408-422-00	120 5Z
L5	1-408-424-00	180 5Z
L7	1-421-329-00	5.6
L8	1-421-329-00	5.6
L9	1-421-329-00	5.6
LPF1	1-235-177-00	LPF
LPF2	1-235-177-00	LPF
LPF3	1-235-178-00	LPF
LPF4	1-235-179-00	LPF
LPF5	1-235-179-00	LPF
Q1	8-729-672-43	2SC2724
Q2	8-729-368-90	2SC689H
Q3	8-729-672-43	2SC2724
Q4	8-769-193-09	2SK43-3
Q5	8-769-193-09	2SK43-3
Q6	8-729-353-00	2SA530H
Q7	8-729-368-90	2SC689H
Q8	8-729-368-90	2SC689H
Q9	8-729-100-87	2SC1275
Q10	8-729-100-87	2SC1275
Q11	8-729-672-43	2SC2724
Q12	8-729-113-32	2SB733
Q13	8-729-368-90	2SC689H
Q14	8-729-672-43	2SC2724
Q15	8-769-193-09	2SK43-3

NOTES:

1. The shaded and -marked components are critical to safety. Replace only with same components as specified.

2. Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.

Ref.No.	Parts No.	Description
Q16	8-769-193-09	2SK43-3
Q17	8-729-353-00	2SA530H
Q18	8-729-368-90	2SC689H
Q19	8-729-368-90	2SC689H
Q20	8-729-100-87	2SC1275
Q6	8-729-353-00	2SA530H
Q7	8-729-368-90	2SC689H
Q8	8-729-368-90	2SC689H
Q9	8-729-100-87	2SC1275
Q10	8-729-100-87	2SC1275
Q11	8-729-672-43	2SC2724
Q12	8-729-113-32	2SB733
Q13	8-729-368-90	2SC689H
Q14	8-729-672-43	2SC2724
Q15	8-769-193-09	2SK43-3
Q16	8-769-193-09	2SK43-3
Q17	8-729-353-00	2SA530H
Q18	8-729-368-90	2SC689H
Q19	8-729-368-90	2SC689H
Q20	8-729-100-87	2SC1275
Q21	8-729-100-87	2SC1275
Q22	8-729-672-43	2SC2724
Q23	8-729-672-43	2SC2724
Q24	8-729-612-77	2SA1027R
Q25	8-729-672-43	2SC2724
Q26	8-729-672-43	2SC2724
Q27	8-729-612-77	2SA1027R
Q28	8-729-110-53	2SA1005
Q29	8-729-110-53	2SA1005
Q30	8-729-110-53	2SA1005
Q501	8-724-375-01	2SC403C
R342	1-217-066-00	WIREWOUND 10 5W 10%
R501	1-212-364-00	METAL 2.2 1W 5%
RB1	1-231-502-00	510
RB2	1-231-405-00	1K
RB3	1-231-502-00	510
RB4	1-231-405-00	1K
RB5	1-235-128-00	1.5K
RB6	1-231-450-00	3.3K
RB7	1-235-128-00	1.5K
RB8	1-231-450-00	3.3K
RB9	1-235-128-00	1.5K
RB10	1-231-450-00	3.3Kx8
RB11	1-231-450-00	3.3Kx8
RB12	1-231-450-00	3.3Kx8

Ref.No.	Parts No.	Description
RV1	1-228-291-00	VAR, 1K
RV2	1-228-295-00	VAR, 20K
RV3	1-228-291-00	VAR, 1K
RV4	1-228-291-00	VAR, 1K
RV5	1-228-295-00	VAR, 20K
RV6	1-228-295-00	VAR, 20K
RV7	1-228-295-00	VAR, 20K
RV8	1-228-292-00	VAR, 2K
RV9	1-228-294-00	VAR, 10K
T1	1-446-330-00	PULSE
T2	1-446-330-00	PULSE
PS-16 BOARD		
A-6723-198-A		MOUNTED CIRCUIT BOARD, PS-16
C11	1-130-471-00	FILM 0.001 5% 50V
C17	1-130-471-00	FILM 0.001 5% 50V
C102	1-130-471-00	FILM 0.001 5% 50V
C105	1-130-477-00	FILM 0.0033 5% 50V
C108	1-131-342-00	TANTALUM 0.15 10% 35V
C110	1-130-477-00	FILM 0.0033 5% 50V
C113	1-131-342-00	TANTALUM 0.15 10% 35V
D1	8-719-100-28	RD4.7E-B3
D2	8-719-100-28	RD4.7E-B3
D3	8-719-100-28	RD4.7E-B3
D4	8-719-815-55	1S1555
D5	8-719-100-28	RD4.7E-B3
D6	8-719-200-02	10E-2
D8	8-719-200-02	10E-2
D101	8-719-815-55	1S1555
D102	8-719-815-55	1S1555
D103	8-719-815-55	1S1555
D104	8-719-815-55	1S1555
IC1	8-759-135-80	uPC358C(NEC)
IC2	8-759-135-80	uPC358C(NEC)
IC101	8-743-430-00	BX343(SONY)
IC102	8-743-420-00	BX342(SONY)
IC103	8-743-420-00	BX342(SONY)

NOTES:

1. The shaded and -marked components are critical to safety. Replace only with same components as specified.

2. Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.

PS-16, RE-6, SR-18, SS-8, ST-22

Ref.No.	Parts No.	Description
IC104	8-759-600-34	M54532P(MITSUBISHI)
IC105	8-759-240-49	TC4049BP(TOSHIBA)
IC106	8-759-240-49	TC4049BP(TOSHIBA)
IC107	8-759-645-23	M54523P(MITSUBISHI)
IC108	8-759-645-23	M54523P(MITSUBISHI)
Q1	8-729-331-53	2SC2315
Q2	8-729-331-53	2SC2315
Q3	8-729-850-73	2SB507HP-E
Q4	8-729-374-02	2SB740
Q5	8-729-313-42	2SD1134
Q6	8-729-177-43	2SD774
Q7	8-729-313-42	2SD1134
Q8	8-729-374-02	2SB740
Q9	8-729-313-42	2SD1134
Q10	8-729-313-42	2SD1134
Q11	8-729-177-43	2SD774
Q12	8-729-313-42	2SD1134
Q13	8-729-374-02	2SB740
Q14	8-729-313-42	2SD1134
Q15	8-729-177-43	2SD774
R26	1-217-059-00	WIREWOUND 2.7 6W 10%
R27	1-207-620-00	WIREWOUND 1.0 3W 10%
R31	1-207-679-00	WIREWOUND 15 6W 10%
R32	1-207-620-00	WIREWOUND 1.0 3W 10%
RV1	1-228-291-00	VAR, 1K
RV2	1-228-291-00	VAR, 1K
RV3	1-228-293-00	VAR, 5K
RV101	1-228-298-00	VAR, 200K
RV102	1-228-298-00	VAR, 200K
RE-6 BOARD		
	1-608-063-00	PRINTED CIRCUIT BOARD, RE-6
CN331	1-560-546-00	34P
CN332	1-561-028-00	RECEPTACLE, 36P "REMOTE-2"
CN333	1-561-655-00	RECEPTACLE, 9P "REMOTE-1"

Ref.No.	Parts No.	Description
SR-18 BOARD		
	1-608-132-00	PRINTED CIRCUIT BOARD, SR-18
SS-8 BOARD		
	1-586-946-00	PRINTED CIRCUIT BOARD, SS-8
L1	1-459-051-00	HEAD, SENSING
ST-22 BOARD		
	1-608-067-00	PRINTED CIRCUIT BOARD, ST-22
RV1	1-228-770-00	VAR, CARBON 5K "VIDEO"
RV2	1-228-770-00	VAR, CARBON 5K "CHROMA"
RV3	1-228-770-00	VAR, CARBON 5K "SET UP"
RV4	1-228-770-00	VAR, CARBON 5K "Y/C DELAY"
RV6	1-228-770-00	VAR, CARBON 5K "SYSTEM SYNC PHASE"
RV7	1-228-770-00	VAR, CARBON 5K "SYSTEM SC PHASE"
S1	1-516-226-00	SLIDE "VIDEO"
S2	1-516-226-00	SLIDE "CHROMA"
S3	1-516-226-00	SLIDE "SET UP"
S4	1-516-226-00	SLIDE "Y/C DELAY"
S6	1-516-226-00	SLIDE "AUDIO NR"

NOTES:

- The shaded and  -marked components are critical to safety. Replace only with same components as specified.

- Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.

SV-51(DU-44)

Ref.No. Parts No. Description

SV-51 BOARD

A-6715-182-A MOUNTED CIRCUIT BOARD,SV-51
WITH DU-44 BOARD

DU-44 BOARD

1-610-458-00 PRINTED CIRCUIT BOARD,DU-44

C1 1-108-563-00 MYLAR 0.0022 5Z 50V
C2 1-131-347-00 TANTALUM 1 10Z 35V
C3 1-131-369-00 TANTALUM 4.7 10Z 16V
C4 1-108-563-00 MYLAR 0.0022 5Z 50V

D1 8-719-911-19 1SS119

IC1 8-759-345-38 HD14538BP(HITACHI)
IC2 8-759-240-11 TC4011BP(TOSHIBA)

Q1 8-761-622-00 2SC1636

RV1 1-228-462-00 VAR,100K

SV-51 BOARD

C5 1-108-579-00 MYLAR 0.01 5Z 50V
C6 1-131-341-00 TANTALUM 0.1 10Z 35V
C8 1-131-341-00 TANTALUM 0.1 10Z 35V
C13 1-131-341-00 TANTALUM 0.1 10Z 35V
C15 1-108-599-00 MYLAR 0.068 5Z 50V

C17 1-108-555-00 MYLAR 0.001 5Z 50V
C18 1-108-555-00 MYLAR 0.001 5Z 50V
C20 1-108-599-00 MYLAR 0.068 5Z 50V
C22 1-131-345-00 TANTALUM 0.47 10Z 35V
C23 1-131-345-00 TANTALUM 0.47 10Z 35V

C24 1-131-345-00 TANTALUM 0.47 10Z 35V
C25 1-108-579-00 MYLAR 0.01 5Z 50V
C26 1-108-595-00 MYLAR 0.047 5Z 50V
C27 1-108-595-00 MYLAR 0.047 5Z 50V
C28 1-108-595-00 MYLAR 0.047 5Z 50V

C31 1-131-381-00 TANTALUM 47 10Z 10V
C32 1-131-341-00 TANTALUM 0.1 10Z 35V
C33 1-130-224-00 FILM 0.015 5Z 50V
C34 1-108-599-00 MYLAR 0.068 5Z 50V
C35 1-131-385-00 TANTALUM 22 10Z 6.3V

Ref.No. Parts No. Description

C39 1-108-573-00 MYLAR 0.0056 5Z 50V
C40 1-108-569-00 MYLAR 0.0039 5Z 50V
C41 1-108-569-00 MYLAR 0.0039 5Z 50V
C45 1-108-609-00 MYLAR 0.18 5Z 50V
C52 1-108-599-00 MYLAR 0.068 5Z 50V

C55 1-131-343-00 TANTALUM 0.22 10Z 35V
C56 1-108-555-00 MYLAR 0.001 5Z 50V
C57 1-108-555-00 MYLAR 0.001 5Z 50V
C58 1-108-555-00 MYLAR 0.001 5Z 50V
C59 1-108-555-00 MYLAR 0.001 5Z 50V

C62 1-131-371-00 TANTALUM 10 10Z 16V
C201 1-131-341-00 TANTALUM 0.1 10Z 35V
C202 1-108-593-00 MYLAR 0.039 5Z 50V
C203 1-108-569-00 MYLAR 0.0039 5Z 50V
C204 1-108-579-00 MYLAR 0.01 5Z 50V

C205 1-108-555-00 MYLAR 0.001 5Z 50V
C207 1-131-369-00 TANTALUM 4.7 10Z 16V
C208 1-108-591-00 MYLAR 0.033 5Z 50V
C209 1-107-163-00 MICA 47PF 5Z 500V
C210 1-108-603-00 MYLAR 0.1 5Z 50V

C212 1-108-571-00 MYLAR 0.0047 5Z 50V
C215 1-131-368-00 TANTALUM 3.3 10Z 16V
C216 1-131-368-00 TANTALUM 3.3 10Z 16V
C217 1-131-347-00 TANTALUM 1 10Z 35V
C218 1-131-355-00 TANTALUM 2.2 10Z 25V

C317 1-108-579-00 MYLAR 0.01 5Z 50V
C318 1-131-498-00 TANTALUM 1.0 10Z 25V
C319 1-108-557-00 MYLAR 0.0012 5Z 50V
C320 1-108-579-00 MYLAR 0.01 5Z 50V
C325 1-108-579-00 MYLAR 0.01 5Z 50V

C326 1-108-555-00 MYLAR 0.001 5Z 50V
C327 1-108-555-00 MYLAR 0.001 5Z 50V
C502 1-131-341-00 TANTALUM 0.1 10Z 35V
C503 1-131-347-00 TANTALUM 1.0 10Z 35V
C506 1-108-579-00 MYLAR 0.01 5Z 50V

C507 1-131-413-00 TANTALUM 1.0 20Z 20V
C508 1-131-345-00 TANTALUM 0.47 10Z 35V
C512 1-108-555-00 MYLAR 0.001 5Z 50V
C513 1-107-210-00 MICA 22PF 5Z 500V
C516 1-108-555-00 MYLAR 0.001 5Z 50V

C517 1-107-210-00 MICA 22PF 5Z 500V
C518 1-108-555-00 MYLAR 0.001 5Z 50V
C519 1-107-210-00 MICA 22PF 5Z 500V
C520 1-108-555-00 MYLAR 0.001 5Z 50V
C521 1-107-210-00 MICA 22PF 5Z 500V

NOTES:

1. The shaded and  -marked components are critical to safety. Replace only with same components as specified.

2. Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.

Ref.No.	Parts No.	Description	Ref.No.	Parts No.	Description
C522	1-107-177-00	MICA 220PF 5% 500V	D204	8-719-911-19	1SS119
C523	1-107-177-00	MICA 220PF 5% 500V	D205	8-719-101-36	RD3.3EL1
C524	1-108-595-00	MYLAR 0.047 5% 50V	D206	8-719-709-25	1S1925-P
C525	1-131-372-00	TANTALUM 15 10% 16V	D208	8-719-911-19	1SS119
C526	1-108-555-00	MYLAR 0.001 5% 50V	D209	8-719-911-19	1SS119
C527	1-108-555-00	MYLAR 0.001 5% 50V	D210	8-719-911-19	1SS119
C528	1-108-555-00	MYLAR 0.001 5% 50V	D211	8-719-911-19	1SS119
C529	1-108-555-00	MYLAR 0.001 5% 50V	D301	8-719-911-19	1SS119
C541	1-131-408-00	TANTALUM 1.0 20% 35V	D302	8-719-911-19	1SS119
C542	1-131-408-00	TANTALUM 1.0 20% 35V	D303	8-719-911-19	1SS119
C543	1-108-579-00	MYLAR 0.01 5% 50V	D304	8-719-911-19	1SS119
C544	1-108-579-00	MYLAR 0.01 5% 50V	D305	8-719-911-19	1SS119
C546	1-131-369-00	TANTALUM 4.7 10% 16V	D306	8-719-911-19	1SS119
C547	1-108-579-00	MYLAR 0.01 5% 50V	D307	8-719-911-19	1SS119
C548	1-108-579-00	MYLAR 0.01 5% 50V	D308	8-719-911-19	1SS119
C549	1-131-369-00	TANTALUM 4.7 10% 16V	D501	8-719-911-19	1SS119
C550	1-108-579-00	MYLAR 0.01 5% 50V	D504	8-719-911-19	1SS119
C552	1-131-345-00	TANTALUM 0.47 10% 35V	D505	8-719-911-19	1SS119
C553	1-131-385-00	TANTALUM 22 10% 6.3V	D506	8-719-911-19	1SS119
C554	1-108-579-00	MYLAR 0.01 5% 50V	D507	8-719-911-19	1SS119
C555	1-108-579-00	MYLAR 0.01 5% 50V	D508	8-719-911-19	1SS119
D1	8-719-911-19	1SS119	D509	8-719-911-19	1SS119
D2	8-719-911-19	1SS119	D510	8-719-911-19	1SS119
D3	8-719-911-19	1SS119	D511	8-719-911-19	1SS119
D4	8-719-911-19	1SS119	D512	8-719-911-19	1SS119
D5	8-719-911-19	1SS119	D513	8-719-911-19	1SS119
D6	8-719-982-04	ERB81-004	D514	8-719-911-19	1SS119
D7	8-719-982-04	ERB81-004	D515	8-719-911-19	1SS119
D8	8-719-982-04	ERB81-004	D516	8-719-911-19	1SS119
D9	8-719-982-04	ERB81-004	IC1	8-759-240-81	TC4081BP(TOSHIBA)
D10	8-719-911-19	1SS119	IC2	8-759-240-81	TC4081BP(TOSHIBA)
D11	8-719-911-19	1SS119	IC3	8-759-345-38	HD14538BP(HITACHI)
D12	8-719-911-19	1SS119	IC4	8-759-240-30	TC4030BP(TOSHIBA)
D13	8-719-911-19	1SS119	IC5	8-759-240-69	TC4069BP(TOSHIBA)
D14	8-719-911-19	1SS119	IC6	8-759-240-75	TC4075BP(TOSHIBA)
D17	8-719-911-19	1SS119	IC7	8-759-940-94	MSM4094RS(OKI)
D18	8-719-911-19	1SS119	IC8	8-759-240-21	TC4021BP(TOSHIBA)
D19	8-719-911-19	1SS119	IC9	8-759-240-71	TC4071BP(TOSHIBA)
D20	8-719-911-19	1SS119	IC10	8-759-240-30	TC4030BP(TOSHIBA)
D21	8-719-911-19	1SS119	IC11	8-759-240-01	TC4001BP(TOSHIBA)
D22	8-719-911-19	1SS119	IC12	8-759-240-53	TC4053BP(TOSHIBA)
D23	8-719-911-19	1SS119	IC13	8-759-240-73	TC4073BP(TOSHIBA)
D101	8-719-911-19	1SS119	IC14	8-759-245-16	TC4516BP(TOSHIBA)
D201	8-719-911-19	1SS119	IC15	8-759-240-30	TC4030BP(TOSHIBA)
D202	8-719-911-19	1SS119			
D203	8-719-911-19	1SS119			

NOTES:

- The shaded and -marked components are critical to safety. Replace only with same components as specified.

- Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.

Ref.No.	Parts No.	Description
IC16	8-759-135-80	uPC358C(NEC)
IC17	8-759-145-58	uPC4558C(NEC)
IC18	8-759-245-32	TC4532BP(TOSHIBA)
IC19	8-759-245-32	TC4532BP(TOSHIBA)
IC20	8-759-240-81	TC4081BP(TOSHIBA)
IC21	8-759-240-73	TC4073BP(TOSHIBA)
IC22	8-759-240-81	TC4081BP(TOSHIBA)
IC23	8-759-345-38	HD14538BP(HITACHI)
IC24	8-759-240-71	TC4071BP(TOSHIBA)
IC25	8-759-940-94	MSM4094RS(OKI)
IC27	8-759-240-49	TC4049BP(TOSHIBA)
IC28	8-759-240-01	TC4001BP(TOSHIBA)
IC29	8-759-240-53	TC4053BP(TOSHIBA)
IC30	8-759-240-49	TC4049BP(TOSHIBA)
IC31	8-759-240-01	TC4001BP(TOSHIBA)
IC32	8-759-245-16	TC4516BP(TOSHIBA)
IC33	8-759-240-81	TC4081BP(TOSHIBA)
IC34	8-759-729-03	NJM2903D(JRC)
IC35	8-759-729-03	NJM2903D(JRC)
IC36	8-759-240-51	TC4051BP(TOSHIBA)
IC37	8-759-240-51	TC4051BP(TOSHIBA)
IC38	8-759-240-53	TC4053BP(TOSHIBA)
IC39	8-759-345-38	HD14538BP(HITACHI)
IC40	8-759-240-30	TC4030BP(TOSHIBA)
IC41	8-759-240-13	TC4013BP(TOSHIBA)
IC42	8-759-345-38	HD14538BP(HITACHI)
IC43	8-759-240-49	TC4049BP(TOSHIBA)
IC44	8-759-345-38	HD14538BP(HITACHI)
IC45	8-759-240-49	TC4049BP(TOSHIBA)
IC46	8-759-345-38	HD14538BP(HITACHI)
IC47	8-759-240-50	TC4050BP(TOSHIBA)
IC48	8-759-729-03	NJM2903D(JRC)
IC49	8-759-240-66	TC4066BP(TOSHIBA)
IC50	8-759-240-49	TC4049BP(TOSHIBA)
IC51	8-749-909-15	BX3915A(SONY)
IC52	8-759-250-67	TC5067BP(TOSHIBA)
IC53	8-759-135-80	uPC358C(NEC)
IC54	8-759-135-80	uPC358C(NEC)
IC55	8-759-133-90	uPC339C(NEC)
IC56	8-759-240-13	TC4013BP(TOSHIBA)
IC57	8-759-145-58	uPC4558C(NEC)
IC58	8-759-145-58	uPC4558C(NEC)
IC59	8-759-745-50	NJM4558D-D(JRC)
IC60	8-751-941-03	CX194B(SONY)
IC61	8-759-700-58	NJM4558D-FA(JRC)

Ref.No.	Parts No.	Description
IC62	8-749-911-54	BX1154(SONY)
IC63	8-749-911-55	BX1155(SONY)
IC65	8-759-133-90	uPC339C(NEC)
IC66	8-759-135-80	uPC358C(NEC)
IC67	8-759-132-40	uPC324C(NEC)
IC68	8-759-729-03	NJM2903D(JRC)
IC69	8-759-145-58	uPC4558C(NEC)
IC70	8-759-145-58	uPC4558C(NEC)
IC74	8-759-708-05	NJM78L05A(JRC)
IC75	8-759-145-58	uPC4558C(NEC)
IC76	8-759-345-38	HD14538BP(HITACHI)
IC77	8-759-345-38	HD14538BP(HITACHI)
IC78	8-759-240-53	TC4053BP(TOSHIBA)
IC79	8-759-240-66	TC4066BP(TOSHIBA)
L1	1-459-155-00	45
L2	1-408-298-00	2mH
L3	1-459-155-00	45
L4	1-408-298-00	2mH
Q1	8-729-631-02	2SC1310
Q2	8-729-188-23	2SD882
Q3	8-729-288-02	2SD880
Q4	8-729-631-02	2SC1310
Q6	8-729-631-02	2SC1310
Q8	8-729-631-02	2SC1310
Q9	8-729-384-46	2SA844
Q10	8-729-631-02	2SC1310
Q201	8-761-622-00	2SC1636
Q202	8-729-631-02	2SC1310
Q203	8-729-631-02	2SC1310
Q204	8-761-622-00	2SC1636
Q205	8-769-193-09	2SK43-3
Q206	8-729-631-02	2SC1310
Q207	8-729-631-02	2SC1310
Q209	8-729-631-02	2SC1310
Q301	8-761-622-00	2SC1636
Q502	8-729-606-32	2SC2603
Q503	8-729-606-32	2SC2603
Q505	8-761-622-00	2SC1636
Q506	8-761-622-00	2SC1636
Q507	8-761-622-00	2SC1636
Q508	8-761-622-00	2SC1636
Q509	8-729-606-32	2SC2603
Q510	8-729-606-32	2SC2603

NOTES:

- The shaded and -marked components are critical to safety. Replace only with same components as specified.

- Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.

SV-51, SW-85, SW-86, SY-91

Ref.No.	Parts No.	Description
R54	1-207-621-00	WIREWOUND 1.5 3W 10%
R55	1-212-360-00	METAL 1 1W 5%
R99	1-207-636-00	WIREWOUND 100 3W 10%
R323	1-210-817-00	CARBON 1.5M 1/4W 5%
R326	1-210-817-00	CARBON 1.5M 1/4W 5%
R327	1-210-817-00	CARBON 1.5M 1/4W 5%
R502	1-212-708-00	METAL 180K 1/2W 1%
R504	1-212-715-00	METAL 360K 1/2W 1%
R505	1-212-715-00	METAL 360K 1/2W 1%
RB101	1-231-411-00	100Kx8
RB102	1-231-411-00	100Kx8
RV1	1-228-297-00	VAR, 100K
RV2	1-228-297-00	VAR, 100K
RV3	1-228-297-00	VAR, 100K
RV4	1-228-296-00	VAR, 50K
RV5	1-228-295-00	VAR, 20K
RV6	1-228-296-00	VAR, 50K
RV7	1-228-298-00	VAR, 20K
RV8	1-228-295-00	VAR, 20K
RV201	1-228-293-00	VAR, 5K
RV202	1-228-293-00	VAR, 5K
RV203	1-228-293-00	VAR, 5K
RV204	1-228-295-00	VAR, 20K
RV205	1-228-293-00	VAR, 5K
RV206	1-228-293-00	VAR, 5K
RV501	1-228-294-00	VAR, 10K
RV502	1-228-294-00	VAR, 10K
RV503	1-228-293-00	VAR, 5K
RV504	1-228-293-00	VAR, 5K
RV505	1-228-294-00	VAR, 10K
RV506	1-228-294-00	VAR, 10K
RV507	1-228-294-00	VAR, 10K
RV508	1-228-294-00	VAR, 10K
RV509	1-228-290-00	VAR, 500
RV510	1-228-290-00	VAR, 500
RV511	1-228-292-00	VAR, 2K
RV513	1-228-290-00	VAR, 500
RV515	1-228-293-00	VAR, 5K
RV516	1-228-293-00	VAR, 5K
RV517	1-228-290-00	VAR, 500
RV519	1-228-292-00	VAR, 2K
RV520	1-228-289-00	VAR, 200
X1	1-527-980-00	4.433619MHz

Ref.No.	Parts No.	Description
SW-85 BOARD		
	1-608-050-00	PRINTED CIRCUIT BOARD, SW-85
S1	1-516-963-00	SLIDE "AUDIO MONITOR"
S2	1-516-995-00	SLIDE "REMOTE SELECT"
SW-86 BOARD		
	1-608-064-00	PRINTED CIRCUIT BOARD, SW-86
S1	1-514-448-00	SLIDE "75ohm ON/OFF"
SY-91 BOARD		
	A-6717-281-A	MOUNTED CIRCUIT BOARD, SY-91
C26	1-107-158-00	MICA 30PF 5% 500V
C27	1-107-158-00	MICA 30PF 5% 500V
C63	1-131-345-00	TANTALUM 0.47 10% 35V
C65	1-131-345-00	TANTALUM 0.47 10% 35V
C66	1-108-583-00	MYLAR 0.015 5% 50V
C68	1-131-371-00	TANTALUM 10 10% 16V
C82	1-108-587-00	MYLAR 0.022 5% 50V
C95	1-131-348-00	TANTALUM 1.5 10% 35V
D1	8-719-815-55	1S1555
D2	8-719-815-55	1S1555
D3	8-719-815-55	1S1555
D4	8-719-815-55	1S1555
D5	8-719-815-55	1S1555
IC1	8-759-200-39	TC40H240P(TOSHIBA)
IC2	8-759-200-39	TC40H240P(TOSHIBA)
IC3	8-759-200-43	TC40H244P(TOSHIBA)
IC4	8-759-200-43	TC40H244P(TOSHIBA)
IC5	8-759-200-39	TC40H240P(TOSHIBA)

NOTES:

- The shaded and -marked components are critical to safety. Replace only with same components as specified.

- Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.

Ref.No.	Parts No.	Description
IC6	8-759-200-43	TC40H244P(TOSHIBA)
IC7	8-759-200-43	TC40H244P(TOSHIBA)
IC8	8-759-200-43	TC40H244P(TOSHIBA)
IC9	8-759-200-43	TC40H244P(TOSHIBA)
IC10	8-759-200-43	TC40H244P(TOSHIBA)
IC11	8-759-200-22	TC40H138P(TOSHIBA)
IC12	8-759-906-80	LH0080(SHARP)
IC13	8-759-200-44	TC40H245P(TOSHIBA)
IC14	8-759-200-43	TC40H244P(TOSHIBA)
IC15	8-759-200-43	TC40H244P(TOSHIBA)
IC16	8-759-200-22	TC40H138P(TOSHIBA)
IC17	8-759-220-32	TC40H032P(TOSHIBA)
IC18	8-759-220-04	TC40H004P(TOSHIBA)
IC19	8-759-220-32	TC40H032P(TOSHIBA)
IC20	8-759-200-23	TC40H139P(TOSHIBA)
IC21	8-759-223-68	TC40H368P(TOSHIBA)
IC22	8-759-240-20	TC4020BP(TOSHIBA)
IC23	8-759-220-74	TC40H074P(TOSHIBA)
IC24	8-759-223-68	TC40H368P(TOSHIBA)
IC25	8-759-200-46	TC40H273P(TOSHIBA)
IC26	8-759-200-46	TC40H273P(TOSHIBA)
IC27	8-759-200-46	TC40H273P(TOSHIBA)
IC28	8-759-200-46	TC40H273P(TOSHIBA)
IC29	8-759-200-46	TC40H273P(TOSHIBA)
IC30	8-759-200-46	TC40H273P(TOSHIBA)
IC31	8-759-200-46	TC40H273P(TOSHIBA)
IC32	8-759-200-46	TC40H273P(TOSHIBA)
IC33	8-759-200-22	TC40H138P(TOSHIBA)
IC34	8-759-200-43	TC40H244P(TOSHIBA)
IC35	8-759-200-22	TC40H138P(TOSHIBA)
IC36	8-759-921-28	MSM2128-1AS(OKI)
IC39		
IC40	X-3675-838-3	ROM ASS'Y
IC41		
IC42	8-759-906-84	LH0084(SHARP)
IC43	8-759-916-82	LH0082A(SHARP)
IC44	8-759-916-82	LH0082A(SHARP)
IC45	8-759-200-14	TC40H011P(TOSHIBA)
IC46	8-759-240-50	TC4050BP(TOSHIBA)
IC47	8-759-240-50	TC4050BP(TOSHIBA)
IC48	8-759-645-29	M54529P(MITSUBISHI)
IC49	8-759-900-05	SN74LS05N(TI)
IC50	8-759-240-21	TC4021BP(TOSHIBA)
IC51	8-759-240-21	TC4021BP(TOSHIBA)
IC52	8-759-240-21	TC4021BP(TOSHIBA)

Ref.No.	Parts No.	Description
IC53	8-759-240-21	TC4021BP(TOSHIBA)
IC54	8-759-240-50	TC4050BP(TOSHIBA)
IC55	8-759-926-31	AM26LS31PC(AMD)
IC56	8-759-645-29	M54529P(MITSUBISHI)
IC57	8-759-240-11	TC4011BP(TOSHIBA)
IC58	8-759-240-71	TC4071BP(TOSHIBA)
IC59	8-759-240-81	TC4081BP(TOSHIBA)
IC61	8-759-240-81	TC4081BP(TOSHIBA)
IC62	8-759-240-69	TC4069BP(TOSHIBA)
IC63	8-759-345-38	HD14538BP(HITACHI)
IC64	8-759-240-93	TC4093BP(TOSHIBA)
IC65	8-759-940-94	MSM4094RS(OKI)
IC66	8-759-940-94	MSM4094RS(OKI)
IC67	8-759-940-94	MSM4094RS(OKI)
IC68	8-759-940-94	MSM4094RS(OKI)
IC69	8-759-145-84	uPD4584BC(NEC)
IC70	8-759-926-32	AM26LS32PC(AMD)
IC71	8-759-240-01	TC4001BP(TOSHIBA)
IC72	8-759-240-81	TC4081BP(TOSHIBA)
IC73	8-759-645-29	M54529P(MITSUBISHI)
IC74	8-759-345-38	HD14538BP(HITACHI)
IC75	8-759-240-81	TC4081BP(TOSHIBA)
IC76	8-759-240-50	TC4050BP(TOSHIBA)
IC77	8-759-223-68	TC40H368P(TOSHIBA)
IC78	8-759-900-37	SN74LS37N(TI)
IC79	8-759-645-29	M54529P(MITSUBISHI)
IC80	8-759-240-24	TC4024BP(TOSHIBA)
L1	1-459-155-00	45
R21	1-244-762-00	CARBON 5.1M 1/4W 5Z
RB1	1-231-411-00	100Kx8
RB2	1-231-411-00	100Kx8
RB3	1-231-407-00	2.2Kx8
RB4	1-231-407-00	2.2Kx8
RB5	1-231-407-00	2.2Kx8
RB6	1-231-407-00	2.2Kx8
RB7	1-231-407-00	2.2Kx8
RB8	1-235-005-00	47Kx8
RB9	1-231-407-00	2.2Kx8
RB10	1-231-411-00	100Kx8
RB11	1-231-410-00	10Kx8
RB12	1-231-405-00	1Kx8
RB13	1-231-407-00	2.2Kx8
RB14	1-231-411-00	100Kx8

NOTES:

1. The shaded and  -marked components are critical to safety. Replace only with same components as specified.

2. Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.

Ref.No.	Parts No.	Description
RV1	1-226-095-00	VAR,200K

S1	1-552-509-00	DIP
S2	1-552-509-00	DIP
S3	1-552-509-00	DIP
S4	1-516-925-21	DIP

X1	1-527-827-00	4.9152MHz
----	--------------	-----------

TC-25 BOARD

A-6715-170-A MOUNTED CIRCUIT BOARD,TC-25

C1	1-131-349-00	TANTALUM 2.2 10% 35V
C2	1-108-555-00	MYLAR 0.001 5% 50V
C3	1-107-207-00	MICA 16PF 5% 500V
C4	1-131-347-00	TANTALUM 1.0 10% 35V
C5	1-131-349-00	TANTALUM 2.2 10% 35V

C107	1-108-569-00	MYLAR 0.0039 5% 50V
C118	1-131-344-00	TANTALUM 0.33 10% 35V
C128	1-131-344-00	TANTALUM 0.33 10% 35V
C129	1-131-344-00	TANTALUM 0.33 10% 35V
C301	1-131-350-00	TANTALUM 3.3 10% 35V

C302	1-131-350-00	TANTALUM 3.3 10% 35V
C303	1-131-350-00	TANTALUM 3.3 10% 35V
C304	1-131-350-00	TANTALUM 3.3 10% 35V

D1	8-719-200-02	10K-2
D100	8-719-815-55	1S1555
D101	8-719-815-55	1S1555
D103	8-719-815-55	1S1555
D104	8-719-815-55	1S1555

D105	8-719-815-55	1S1555
D200	8-719-400-35	LED,1N35BP
D201	8-719-400-35	LED,1N35BP
D202	8-719-400-35	LED,1N35BP
D203	8-719-400-35	LED,1N35BP

D204	8-719-400-25	LED,1N25RP
D205	8-719-400-25	LED,1N25RP
D206	8-719-400-25	LED,1N25RP
D301	8-719-815-55	1S1555
D302	8-719-815-55	1S1555

Ref.No.	Parts No.	Description
D303	8-719-815-55	1S1555
D304	8-719-815-55	1S1555
D305	8-719-200-02	10K-2
D306	8-719-200-02	10K-2
D307	8-719-200-02	10K-2
D308	8-719-200-02	10K-2
D309	8-719-200-02	10K-2
D310	8-719-200-02	10K-2
D311	8-719-200-02	10K-2
D312	8-719-200-02	10K-2
IC1	8-759-979-22	CX7912(SONY)
IC2	8-759-151-11	uPD5101LC-1(NEC)
IC3	8-759-151-11	uPD5101LC-1(NEC)
IC4	8-759-145-19	uPD4519BC(NEC)
IC5	8-759-240-53	TC4053BP(TOSHIBA)
IC6	8-759-240-13	TC4013BP(TOSHIBA)
IC7	8-759-729-03	NJM2903D(JRC)
IC8	8-759-240-30	TC4030BP(TOSHIBA)
IC9	8-759-240-81	TC4081BP(TOSHIBA)
IC10	8-759-240-81	TC4081BP(TOSHIBA)
IC11	8-759-240-11	TC4011BP(TOSHIBA)
IC12	8-759-240-69	TC4069UBP(TOSHIBA)
IC13	8-759-240-69	TC4069UBP(TOSHIBA)
IC100	8-759-705-62	NJM4562D-D(JRC)
IC200	8-759-645-17	M54517P(MITSUBISHI)
IC201	8-759-729-03	NJM2903D(JRC)
IC202	8-759-345-38	HD14538BP(HITACHI)
IC203	8-759-345-38	HD14538BP(HITACHI)
IC204	8-759-729-03	NJM2903D(JRC)
IC205	8-759-240-81	TC4081BP(TOSHIBA)
IC301	8-759-645-23	M54523P(MITSUBISHI)
IC302	8-759-240-71	TC4071BP(TOSHIBA)
IC303	8-759-645-23	M54523P(MITSUBISHI)
IC304	8-759-600-24	M54543L(MITSUBISHI)
IC305	8-759-600-24	M54543L(MITSUBISHI)
Q1	8-729-663-47	2SC1364
Q100	8-729-663-47	2SC1364
Q101	8-729-663-47	2SC1364
Q102	8-729-663-47	2SC1364
Q103	8-729-663-47	2SC1364
Q104	8-729-663-47	2SC1364
Q105	8-729-663-47	2SC1364
Q106	8-729-663-47	2SC1364
Q107	8-729-663-47	2SC1364
Q108	8-729-663-47	2SC1364

NOTES:

- The shaded and  -marked components are critical to safety. Replace only with same components as specified.

- Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.

TC-25, TE-2, TR-14, VR-8, YD-15

Ref.No.	Parts No.	Description
Q109	8-729-663-47	2SC1364
Q110	8-729-663-47	2SC1364
R103	1-212-717-00	METAL 430K 1/2W 1%
RB1	1-231-410-00	10Kx8
RV101	1-228-292-00	VAR, 2K
RV102	1-228-294-00	VAR, 10K
RV103	1-228-296-00	VAR, 50K
RV104	1-228-294-00	VAR, 10K
S1	1-552-782-00	DIP
X1	1-527-827-00	4.9152MHz
TE-2 BOARD		
	1-608-060-00	PRINTED CIRCUIT BOARD, TE-2
PH1	8-719-104-42	PS4005-L (NEC)
TR-14 BOARD		
	1-608-055-00	PRINTED CIRCUIT BOARD, TR-14
RM1	8-745-208-00	DM208
VR-8 BOARD		
	1-608-294-00	PRINTED CIRCUIT BOARD, VR-8
RV1	1-228-218-00	VAR, CARBON 500/500 "HEADPHONES"

Ref.No.	Parts No.	Description
YD-15 BOARD		
	A-6711-424-A	MOUNTED CIRCUIT BOARD, YD-15
C1	1-107-208-00	MICA 18PF 5% 500V
C7	1-107-210-00	MICA 22PF 5% 500V
C9	1-107-159-00	MICA 33PF 5% 500V
C11	1-107-208-00	MICA 18PF 5% 500V
C19	1-107-159-00	MICA 33PF 5% 500V
C30	1-107-211-00	MICA 24PF 5% 500V
C31	1-107-202-00	MICA 10PF 5% 500V
C42	1-130-471-00	FILM 0.001 5% 50V
C44	1-130-471-00	FILM 0.001 5% 50V
C60	1-127-460-00	ELECT 1.0 20% 25V
C61	1-127-460-00	ELECT 1.0 20% 25V
C62	1-127-460-00	ELECT 1.0 20% 25V
C63	1-127-460-00	ELECT 1.0 20% 25V
C64	1-127-460-00	ELECT 1.0 20% 25V
C70	1-109-692-00	DIPPED MICA 620PF 1% 500V
C73	1-107-047-00	MICA 5.6PF 500V
C75	1-109-680-00	DIPPED MICA 200PF 1% 500V
C80	1-109-673-00	DIPPED MICA 100PF 1% 500V
C81	1-109-681-00	DIPPED MICA 220PF 1% 500V
C86	1-127-460-00	ELECT 1.0 20% 25V
C104	1-107-157-00	MICA 27PF 5% 500V
C130	1-107-043-00	MICA 2.7PF 5% 500V
C131	1-107-211-00	MICA 24PF 5% 500V
C132	1-107-211-00	MICA 24PF 5% 500V
C142	1-107-047-00	MICA 5.6PF 500V
D1	8-719-151-07	RD5.1E-B
D2	8-719-815-55	1S1555
D3	8-719-162-07	RD6.2E-B
D4	8-719-191-07	RD9.1E-B
D5	8-719-815-55	1S1555
D6	8-719-815-55	1S1555
D7	8-719-815-55	1S1555
DL1	1-415-154-00	1MHz 35nS
DL2	1-415-154-00	1MHz 35nS
FL1	1-235-190-00	LFP

NOTES:

- The shaded and -marked components are critical to safety. Replace only with same components as specified.

- Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.

YD-15, FRAME

Ref.No. Parts No. Description

IC1 8-751-340-00 CX134A(SONY)
IC2 8-741-114-00 BX1140(SONY)
IC3 8-759-208-94 CX894(SONY)
IC4 8-759-951-07 SN75107AN(TI)
IC5 8-741-110-10 BX1101(SONY)

IC7 8-749-938-90 BX389(SONY)
IC8 8-749-938-90 BX389(SONY)
IC9 8-759-200-60 TA7060AP(TOSHIBA)
IC10 8-759-200-60 TA7060AP(TOSHIBA)
IC11 8-749-936-61 BX366A(SONY)
IC12 8-759-700-14 NJM78M09A(JRC)

LV1 1-407-568-00 VAR,6.8
LV2 1-407-568-00 VAR,6.8
LV11 1-407-568-00 VAR,6.8
LV12 1-407-568-00 VAR,6.8

Q1 8-724-375-01 2SC403C
Q2 8-724-375-01 2SC403C
Q3 8-724-375-01 2SC403C
Q4 8-724-375-01 2SC403C
Q5 8-724-375-01 2SC403C

Q6 8-761-622-00 2SC1636
Q7 8-724-375-01 2SC403C
Q8 8-729-384-48 2SA844
Q10 8-724-375-01 2SC403C
Q11 8-724-375-01 2SC403C

Q12 8-724-375-01 2SC403C
Q13 8-729-663-47 2SC1364
Q14 8-724-375-01 2SC403C
Q15 8-729-374-02 2SB740
Q16 8-724-375-01 2SC403C

Q18 8-729-663-47 2SC1364
Q20 8-724-375-01 2SC403C
Q21 8-724-375-01 2SC403C
Q22 8-724-375-01 2SC403C
Q24 8-761-622-00 2SC1636

Q23 8-724-375-01 2SC403C
Q25 8-729-190-12 2SC2901
Q26 8-724-375-01 2SC403C

RV1 1-228-292-00 VAR,2K
RV2 1-228-292-00 VAR,2K
RV3 1-228-292-00 VAR,2K
RV4 1-228-291-00 VAR,1K
RV5 1-228-295-00 VAR,20K

Ref.No. Parts No. Description

RV6 1-228-295-00 VAR,20K
RV11 1-228-292-00 VAR,2K
RV12 1-228-292-00 VAR,2K
RV70 1-228-291-00 VAR,1K
RV71 1-228-290-00 VAR,500

RV72 1-228-291-00 VAR,1K
RV73 1-228-288-00 VAR,100
RV74 1-228-288-00 VAR,100
RV75 1-228-291-00 VAR,1K
RV76 1-228-290-00 VAR,500
RV77 1-228-457-00 VAR,2K

FRAME

1-413-119-00 SWITCHING REGULATOR,UR-06

1-413-120-00 SWITCHING REGULATOR,UR-07

1-556-458-00 FLAT CABLE ASS'Y,16P
KY-32 to MB-41

1-586-633-00 CONDENSATION SENSOR

CN310 1-562-160-00 RECEPTACLE,12P
"DUB/COMPONENT OUT"

CN311 1-561-045-00 RECEPTACLE,7P "DUB OUT"

CN312 1-509-095-00 RECEPTACLE,8P "MONITOR"

CN313 1-561-781-21 RECEPTACLE,BNC "VIDEO OUT-1"

CN314 1-561-781-21 RECEPTACLE,BNC "VIDEO OUT-2"

CN315 1-561-781-21 RECEPTACLE,BNC "REF VIDEO IN-1"

CN316 1-561-781-21 RECEPTACLE,BNC "REF VIDEO IN-1"

CN317 1-509-176-00 RECEPTACLE,XLR,MALE

"AUDIO OUT MONITOR"

CN318 1-509-176-00 RECEPTACLE,XLR,MALE

"AUDIO OUT CH-2"

CN319 1-509-176-00 RECEPTACLE,XLR,MALE

"AUDIO OUT CH-1"

CN320 1-561-781-21 RECEPTACLE,BNC "TIME CODE OUT"

1-509-546-00 RECEPTACLE "AC IN"

NOTES:

- The shaded and **Δ**-marked components are critical to safety.
Replace only with same components as specified.

- Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.

FRAME

Ref.No. Parts No. Description

H901 8-825-554-71 PP244-21 "CTL"
H902 8-825-554-51 PP240-2103 "AUDIO/TIME CODE"

M301 1-541-209-00 DC,FAN
M302 1-541-209-00 DC,FAN
M801 1-541-163-00 DC "CASSETTE UP"
M901 8-838-047-02 DC,BHF-1905B "CAPSTAN"
M902 1-541-163-00 DC "THREADING"
M903 A-6737-113-A MOTOR ASS'Y "S-REEL"
M904 A-6737-113-A MOTOR ASS'Y "T-REEL"

ME401 1-520-455-21 "RF"
ME402 1-520-439-00 "AUDIO CH-1"
ME403 1-520-439-00 "AUDIO CH-2"

PL401 1-518-461-00 14V 50mA "RF METER"
PL402 1-518-461-00 14V 50mA "RF METER"
PL403 1-518-461-00 14V 50mA "AUDIO CH-1 METER"
PL404 1-518-461-00 14V 50mA "AUDIO CH-1 METER"
PL405 1-518-461-00 14V 50mA "AUDIO CH-2 METER"
PL406 1-518-461-00 14V 50mA "AUDIO CH-2 METER"
PL801 1-518-508-00 12V 60mA "CASSETTE LAMP"
PL802 1-518-508-00 12V 60mA "CASSETTE LAMP"

PM901 1-454-338-00 "PINCH"
PM902 1-454-336-00 "T-BRAKE"
PM903 1-454-336-00 "S-BRAKE"
PM904 1-454-337-00 "MAIN BRAKE"

RV401 1-224-694-XX VAR,CARBON 20K
"AUDIO LEVEL CH-1"
RV402 1-224-694-XX VAR,CARBON 20K
"AUDIO LEVEL CH-2"
RV403 1-226-616-00 VAR,CARBON 100K "TRACKING"

△ S901 1-554-256-00 **ROCKER "POWER"**

TM901 1-548-100-11 "HOURS METER"

19-4. PACKING MATERIAL AND ACCESSORY (SUPPLIED)

Ref.No. Parts No. Description

△ 1-534-698-XX **CORD,POWER**

3-677-775-00 INDIVIDUAL CARTON
3-677-776-00 CUSHION,LOWER
3-677-777-00 CUSHION,UPPER

3-701-633-00 BAR,POLY(FOR MANUAL)
3-701-649-00 BAG,POLY(FOR BVW-10P)

STANDARD

PRODUCTS 9PIN REMOTE CONTROL CABLE(RCC-5G)
1-560-651-00 PLUG,9P,MALE
1-561-749-00 SHELL

NOTES:

- The shaded and **△**-marked components are critical to safety.
Replace only with same components as specified.

- Parts printed in **Bold-Face type** are normally stocked for replacement purposes. The remaining parts shown in this manual are not normally required for routine service work. Orders for parts not shown in **Bold-Face type** will be processed, but allow for additional delivery time.

SONY®

VIDEOCASSETTE PLAYER

BVW-10P

SUPPLEMENT-2

(For the 1st Edition, 1st Edition Revised-1,
2nd Edition, 2nd Edition Revised-1)

SUBJECT: TABLE OF CONTENTS

MECHANICAL ALIGNMENT

Section 6. REPLACEMENT OF MAJOR PARTS

Section 7. LINK AND DRIVE SYSTEM ALIGNMENT

Section 8. TORQUE AND BACK TENSION ALIGNMENT

Section 9. TAPE RUN ALIGNMENT

Please file this SUPPLEMENT-2 to your own manual, and replace
the TABLE OF CONTENTS with attached one.

BETACAM

OPERATION AND MAINTENANCE MANUAL

ご注意

このマニュアルに記載されている事柄の著作権は当社にあり、説明内容は機器購入者の使用を目的としています。

従って、当社の許可なしに無断で複写したり、説明内容(操作、保守等)と異なる目的で本マニュアルを使用することを禁止します。

CONFIDENTIAL

The material contained in this manual consists of information that is the property of Sony Corporation and is intended solely for use by the purchasers of the equipment described in this manual.

Sony Corporation expressly prohibits the duplication of any portion of this manual or the use thereof for any purpose other than the operation or maintenance of the equipment described in this manual without the express written permission of Sony Corporation.

CONFIDENTIEL

Le matériel contenu dans ce manuel consiste en informations qui sont la propriété de Sony Corporation et sont destinées exclusivement à l'usage des acquéreurs de l'équipement décrit dans ce manuel.

Sony Corporation interdit formellement la copie de quelque partie que ce soit de ce manuel ou son emploi pour tout autre but que des opérations ou entretiens de l'équipement à moins d'une permission écrite de Sony Corporation.

VERTRAULICH

Das in dieser Anleitung enthaltene Material besteht aus Informationen, die Eigentum der Sony Corporation sind, und ausschließlich zum Gebrauch durch den Käufer der in dieser Anleitung beschriebenen Ausrüstung bestimmt sind.

Die Sony Corporation untersagt ausdrücklich die Vervielfältigung jeglicher Teile dieser Anleitung oder den Gebrauch derselben für irgendeinen anderen Zweck als die Bedienung oder Wartung der in dieser Anleitung beschriebenen Ausrüstung ohne ausdrückliche schriftliche Erlaubnis der Sony Corporation.

TABLE OF CONTENTS

INHALTSVERZEICHNIS

1. OPERATION

1-1.	Features	1-1 (E)
1-2.	Location and Function of Controls	1-2 (E)
1-2-1.	Control Panel	1-2 (E)
1-2-2.	Connector Panel	1-4 (E)
1-2-3.	Sub Control Panel	1-6 (E)
1-3.	Connections	1-8 (E)
1-3-1.	Playback	1-8 (E)
1-3-2.	Editing with Two VTRs	1-9 (E)
1-3-3.	Editing with a Control Unit	1-11(E)
1-4.	Cassette Insertion and Removal	1-13(E)
1-5.	Playback	1-14(E)
1-5-1.	Preparation	1-14(E)
1-5-2.	Operation	1-14(E)
1-5-3.	Adjustments	1-15(E)
1-5-4.	Tape Protection Devices	1-15(E)
1-6.	Check Routines	1-16(E)
1-7.	Head Cleaning	1-19(E)
1-8.	Specifications	1-19(E)
1-9.	Repacking for Shipment	1-22(E)

1. BETRIEB

1-1.	Besondere Merkmale	1-1 (G)
1-2.	Lage und Funktion der Bedienelemente	1-2 (G)
1-2-1.	Bedienungsfeld	1-2 (G)
1-2-2.	Anschlußfeld	1-4 (G)
1-2-3.	Hilfsbedienungsfeld	1-6 (G)
1-3.	Anschlüsse	1-8 (G)
1-3-1.	Wiedergabe	1-8 (G)
1-3-2.	Schneiden mit zwei Videorecordern	1-9 (G)
1-3-3.	Schneiden mit einer Steuereinheit	1-11(G)
1-4.	Einlegen und Herausnehmen der Cassette	1-13(G)
1-5.	Wiedergabe	1-14(G)
1-5-1.	Vorbereitung	1-14(G)
1-5-2.	Betrieb	1-14(G)
1-5-3.	Einstellungen	1-15(G)
1-5-4.	Bandschutzeinrichtungen	1-15(G)
1-6.	Überprüfungen	1-16(G)
1-7.	Reinigung der Köpfe	1-19(G)
1-8.	Technische Daten	1-19(G)
1-9.	Wiederverpackung zum Transport	1-22(G)

2. INSTALLATION

2-1.	Operational Environment	2-1
2-2.	Installation Space	2-1
2-3.	Operating Voltage	2-2
2-4.	Connectors for Optional Connection	2-2
2-5.	Input/Output Signal of the Connector	2-2
2-6.	Select Switch Setting	2-4
2-7.	Rack Mounting	2-5

2-8.	Supplied Accessory	2-6
2-9.	Optional Accessory	2-6

3. TECHNICAL INFORMATION

3-1.	Specifications	3-1
3-2.	Location of the Printed Circuit Board	3-3
3-3.	Location of the Mechanical Main Parts/Components	3-6
3-4.	Printed Circuit Boards	3-7

4. PERIODIC CHECK AND MAINTENANCE

4-1.	System Control Operation Check	4-1
4-2.	Maintenance Time Table	4-3
4-3.	Hours Meter	4-4
4-4.	Cleaning Procedure	4-4
4-4-1.	Video Head	4-4
4-4-2.	Stationary Heads	4-4
4-4-3.	Tape Movement Areas	4-4
4-5.	Maintenance after Repairs	4-4

5. SERVICE INFORMATION

5-1.	Removal of Cabinet	5-1
5-2.	Removal of Cassette-up Compartment	5-2
5-3.	Note for Check and Maintenance of Printed Circuit Board	5-2
5-4.	Module Extender	5-2
5-5.	Spare Parts	5-2
5-6.	To Operate the Machine without Installing Cassette Tape	5-2
5-7.	Maintenance of KY or DE Board	5-3
5-8.	Cassette Removal Procedure when the Tape is Slacken in the Machine	5-3
5-9.	Alignment Fixture	5-4

6. REPLACEMENT OF MAJOR PARTS

6-1	Replacement of Reel Motor	6-1
6-2	Replacement of Reel Table	6-1
6-2-1	Replacement of Supply Reel Table	6-1
6-2-2	Replacement of Take-up Reel Table	6-2
6-3	Replacement of Upper Drum	6-2
6-4	Replacement of Drum Assembly	6-4
6-5	Replacement of Capstan Motor	6-5
6-6	Replacement of CTL Head	6-6
6-7	Replacement of Audio/Time Code Head	6-7
6-8	Replacement of Tension Regulator	6-8
6-8-1	Replacement of Tension Regulator Block	6-8
6-8-2	Replacement of Tension Regulator Arm	6-8
6-9	Replacement of Tension Regulator Block DME	6-9
6-10	Replacement of Rotation Detector Block	6-10
6-11	Replacement of Threading Motor	6-11
6-12	Replacement of Threading Ring	6-11
6-13	Adjustment Item Table Main Parts Replacement	6-12

7. LINK AND DRIVE SYSTEM ALIGNMENT

Alignment Information		7-1
7-1.	Reel Table Adjustment	7-3
7-1-1.	Reel Motor Shaft Slantness Adjustment	7-3
7-1-2.	Reel Table Height Adjustment	7-4
7-1-3.	Reel Table Rotation Detector Block Position Adjustment	7-5
7-2.	Brake System Adjustment	7-6
7-2-1.	Main Brake Clearance Adjustment	7-6
7-2-2.	Supply Soft Brake Adjustment	7-7
7-2-3.	Take-up Pause Brake Adjustment	7-8
7-3.	Threading Ring System Adjustment	7-9
7-3-1.	Threading Ring Rotation Adjustment	7-9
7-3-2.	Gear Box Position Adjustment	7-10
7-3-3.	Ring Arm Position Adjustment	7-11
7-3-4.	TE-2 Block Position Adjustment	7-12
7-3-5.	TE-3 Block Position Adjustment	7-13
7-4.	Pinch Press Mechanism Block Adjustment	7-14
7-4-1.	Pinch Roller Pressure Adjustment	7-14
7-4-2.	Pinch Press Mechanism Block Position Adjustment	7-15
7-5.	Tension Regulator System Adjustment	7-16
7-5-1.	Tension Regulator Arm Slantness Adjustment	7-16

7-5-2	Tension Regulator Hook Arm Release Adjustment	7-17
7-5-3	Hook Adjusting Plate Position Adjustment	7-17
7-5-4	Tension Regulator Arm Position Adjustment	7-18
7-6	Cassette Up Compartment Adjustment	7-20
7-6-1	Lid Opener Lever Position Adjustment	7-20
7-6-2	Lid Opener Lever Block Position Adjustment	7-21
7-6-3	Motor Block Position Adjustment	7-22
7-6-4	Cassette in Switch Position Adjustment	7-23
7-6-5	Cassette Down Switch Position Adjustment	7-24
7-7	End Sensor Position Adjustment	7-25
7-8	Pinch Release Arm Position Adjustment	7-26

8. TORQUE AND BACK TENSION ALIGNMENT

Alignment Information	8-1
8-1. S Soft Brake Torque Adjustment	8-3
8-2. Reel Motor Torque Adjustment	8-4
8-3. Tension Sensor Impressed Voltage Adjustment	8-4
8-4. FWD Back Tension Adjustment	8-5
8-5. REV Tension Adjustment	8-6

9. TAPE RUN ALIGNMENT

Alignment Information		9-1
9-1.	Tape Run Adjustment	9-5
9-2.	Video Tracking Adjustment	9-6
9-3.	Video Head Dihedral Adjustment	9-9
9-4.	CTL Polarity Check	9-10
9-5.	CTL Head Position Adjustment	9-11
9-6.	TC Head Position Adjustment	9-12
9-7.	Switching Position Adjustment	9-13
9-8.	CTL Head Azimuth/Zenith Adjustment	9-14
9-9.	CTL Head Height Adjustment	9-15
9-10.	AUDIO/TC Head Zenith Adjustment	9-16
9-11.	Audio Head Height Adjustment	9-17
9-12.	Audio Head Tape-to-Head Contact Adjustment	9-18
9-13.	Audio Head Phase Adjustment	9-19
9-14.	Pinch Roller Pressure Timing Adjustment	9-20
9-15.	Slip-Ring and Brush Position Adjustment	9-20

17. SEMICONDUCTOR ELECTRODES

Semiconductor Electrodes 17-1

18. PRINTED WIRING BOARD AND SCHEMATIC DIAGRAM

VIDEO

PB-8 18-2
YD-15 18-5
CD-25 18-11
CF-12 18-17
CK-14 18-22
MY-17 18-40
PR-48 18-58
EN-20 18-76

AUDIO

AU-37 18-94

SERVO

SV-51 18-101

SYSTEM CONTROL

SY-91 18-128

TIME CODE

TC-25 18-146

POWER SUPPLY/DRIVER

PS-16 18-151

CONTROL/CONNECTOR PANEL

CP-52
SW-85
VR-8
HP-7
LA-4
CP-56
SW-86
ST-22
KY-32
DP-30
PC-9
PC-14
RE-6
..... 18-155
..... 18-159
..... 18-163
..... 18-167
..... 18-171
..... 18-173

FRAME

DE-12
DE-11
SS-8
HE-5
PH-16
LE-19
SS-8
CL-7
PC-17
PC-18
LM-4
PD-20
TE-2
TR-14
..... 18-175
..... 18-179
..... 18-181
..... 18-183
..... 18-184
..... 18-185
..... 18-186

AC-40 18-187
MB-41 18-189
MB-42 18-197
FRAME 18-203

19. SPARE PARTS AND FIXTURE

19-1. Parts Information 19-1
19-2. Exploded View 19-1
 Take-up Side Reel Chassis 19-5
 Supply Side Reel Chassis 19-7
 Head Drum, Stationary Heads and
 Tape Guides Block 19-9
 Threading Ring Block 19-11
 Pinch Press Mechanism Block 19-13
 Supply Tension Regulator Block 19-14
 Gear Box Block 19-16
 Level Control Chassis Block 19-17
 Function Control Chassis Block 19-19
 Connector Panel Block 19-21
 TBC Control Block 19-23
 Chassis Block (1) 19-24
 Switching Regulator 19-26
 Switching Regulator (UR-06) 19-26
 Switching Regulator (UR-07) 19-29
 Cassette-up Compartment 19-29
 Ornamental Panel Block (1) 19-31
 Ornamental Panel Block (2) 19-33
 Printed Circuit Board Block (1) 19-35
 Printed Circuit Board Block (2) 19-37
 Extension Board Block 19-39
19-3. Electrical Parts List 19-41
19-4. Packing Material
 and Accessory (Supplied) 19-74

SEMI-CONDUCTOR ELECTRONICS

PRINTED WIRING BOARD AND SCHEMATIC DIAGRAM

17-1

Semiconductor Electronics

SPARE PARTS AND FIXTURE

18-187 AC-40
18-188 MB-41
18-189 MB-42
18-190 FRAME

VIDEO

18-2 PD-2
18-3 YD-12
18-11 CD-22
18-17 CR-12
18-22 CR-14
18-40 MY-17
18-28 BR-48
18-26 EN-20

AUDIO

18-24 AL-37

SESAVO

18-101 SV-21

SYSTEM CONTROL

18-128 SV-17

TIME CODE

18-146 TC-22

POWER SUPPLY/DRIVER

18-121 PS-15

CONTROL/COMMUNICATION PANEL

18-121 CP-22
18-121 SW-22
18-121 VR-22
18-121 BR-22
18-121 BA-22

18-121 CP-26
18-121 SW-26
18-121 ST-22
18-121 KY-22
18-121 DP-20

18-121 PC-9
18-121 HC-14
18-121 RB-2

FRAME

18-121 DF-12
18-121 DF-17

18-121 SE-2
18-121 HE-2
18-121 PH-16
18-121 LE-16

18-121 SE-2
18-121 CL-7
18-121 PC-17
18-121 PC-14

18-121 LM-4
18-121 PD-20
18-121 TE-2
18-121 TR-24

19-1

Parts Information

19-1 Raytheon View

19-2 Time-up Side Rail Channel

19-3 Supply Side Rail Channel

19-7 Head (Front), Stationary Head and

19-9 Tape Guide Block

19-11 Timing Head Block

19-12 Pin-In Press Mechanism Block

19-14 Supply Tension Regulator Block

19-16 Gear Box Block

19-17 Layer Control Channel Block

19-19 Function Control Channel Block

19-21 Counter Panel Block

19-23 TIM Control Block

19-24 Channel Block (1)

19-26 Switching Regulator

19-26 Switching Regulator (15V-05)

19-26 Switching Regulator (05V-07)

19-29 Counter-on Component

19-31 Operational Panel Block (1)

19-32 Operational Panel Block (2)

19-34 Printed Circuit Board Block (1)

19-37 Printed Circuit Board Block (2)

19-39 Expansion Board Block

19-41 Operational Parts List

19-44 Packing Material

19-24 and Accessory (Supplied)

SECTION 6

REPLACEMENT OF MAJOR PARTS


6-1. REPLACEMENT OF REEL MOTOR

Mode: Unthreading end

Tool: Allen wrench (each edge has 1.5mm)

Replacement procedure:

- (1) Remove the reel table. (See sec. 6-2)
- (2) Disconnect the connector of the reel motor.
- (3) Remove the mounting screws of the reel motor on the front of the chassis.
- (4) Place the connector of the reel motor in the direction as shown in figure, and install the reel motor.
- (5) Insert a poly-slider-washer on the reel shaft.
- (6) Perform the adjustment as sec 6-13.



6-2. REPLACEMENT OF REEL TABLE


6-2-1. Replacement of Supply Reel Table

Mode: Unthreading end

Tool: Allen wrench (each edge has 1.5mm)

Replacement procedure:

- (1) Loosen the two fixing screws of the reel table with allen wrench and remove it.
- (2) Push the iron core of the brake solenoid into the energized position. Push the iron core of the S brake solenoid into the energized position.
- (3) While pushing the iron cores of the two solenoids, install the new reel table to the reel motor shaft.
- (4) Perform the adjustment as sec 6-13.




6-2-2. Replacement of Take-up Reel Table

Mode: Unthreading end

Tool: Allen wrench (each edge has 1.5mm)

Replacement procedure:

- (1) Loosen the two fixing screws of the reel table with allen wrench and remove it.
- (2) Push the iron core of the brake solenoid into the energized position.
- (3) While pushing the iron core, install the new reel table to the reel motor shaft.
- (4) Perform the adjustment as sec. 6-13.



6-3. REPLACEMENT OF UPPER DRUM

The rotary video heads cannot be replaced individually, the whole upper drum assembly must be replaced when any one of these heads fails.

Since the PB-8 board is mounted on the repair parts of the upper drum, the upper drum and the PB-8 board cannot be replaced individually.

Tool: Drum eccentricity gauge (1)

Drum eccentricity gauge (2)

Drum eccentricity gauge (3)


Drum eccentricity gauge (5)

Cleaning fluid

Cleaning piece

Replacement procedure:

- (1) Remove the brush of the slip ring.
- (2) Unsolder the eleven leads from the PB-8 board.
- (3) Remove the two screws of the upper drum and remove the upper drum.
- (4) Clean the machine surfaces of the flange and new upper drum assembly with a cleaning piece moistened with cleaning fluid. (If there is a spacer between drum and flange, it should be remain in place, or be re-installed in the same place with the new upper drum




assembly. The spacer is 0.01mm, 0.03mm, 0.05mm or 0.1mm thick.)

- (5) Place the upper drum assembly so that the marked A of the PB-8 board is closest to the marked A of the printed circuit board and thread snugly with two screws but do not tighten.

Adjustment procedure:

- (1) Remove the pinch release arm.
- (2) Assemble the drum eccentricity gauges (1), (2), (3) and (5) as shown in figure. Mount the assembled gauges on the hole as shown in figure so that the tip probe positions at the point about 5mm apart from the top edge of the upper drum.
- (3) Turn the upper drum slowly clockwise direction and confirm the pointer deflection of the gauge is within 5 micron during one complete turn of the upper drum. If this specification is satisfied, proceed to step (5). If it is not, perform then continue with remaining steps.
- (4) Tap the upper side of the upper drum with a nylon hammer or a screwdriver handle so that the gauge deflection remains within 5 micron.
- (5) After the adjustment, tighten the two screws that are securing the upper drum, alternately and gradually using a tightening torque: 8Kg.cm
- (6) After the screws are tightened, check again that the eccentricity of the upper drum is within 5 micron.
- (7) Solder the eleven leads to the PB-8 board.
- (8) Install the brush and the pinch release arm.
- (9) Perform the adjustment as sec. 6-13.



6-4. REPLACEMENT OF DRUM ASSEMBLY

Replacement Procedure:

- (1) Disconnect the connectors, CN222/MB-42 board and CN221/MB-42 board.
- (2) Disconnect the connector, CN125/MB-41 board.
- (3) Disconnect the connector, CN126/MB-41 board.


(Note)

If the connector is directly mounted on the drum motor, don't disconnect the connector, CN126/MB-41 board but disconnect the connector of the drum motor.

- (4) Remove the brush of the slip ring block.
- (5) Remove the three fixing screws on the back of the set and remove the defective drum.
- (6) Install the drum on the base. Tighten the mounting screws while turning the drum ass'y in the counterclockwise direction.
- (7) Insert the connector of the drum harness to the CN222, CN221/MB-42 board and the CN125/MB-41 board.
- (8) When disconnect the connector, CN126/MB-41 board in the step (3), connect the drum harness into the repair parts drum ass'y between the CN126/MB-41 board and the drum motor.

When disconnect the connector of the drum harness in the step (3), connect this connector to the new drum motor.


- (9) After the brush is installed, perform the adjustment as sec. 6-13.



6-5. REPLACEMENT OF CAPSTAN MOTOR

Replacement procedure:



- (1) Disconnect the connector of the capstan motor.
- (2) Remove the three screws as shown in figure and remove the capstan motor.
- (3) Install the capstan motor. Tighten the fixing screws while turning the capstan motor in the clockwise direction viewing from top of the set.
- (4) Perform the adjustment as sec. 6-13.



6-6. REPLACEMENT OF CTL HEAD

Replacement procedure:

- (1) Remove the CTL head block.
- (2) Unsolder the leads of the CH-10 board on CTL head.
- (3) Remove the mounting screws of the CTL head.
- (4) Install the new CTL head to the CTL head block while pressing the head in the direction as shown in figure.
- (5) Install the CTL head block and perform the adjustment as sec. 6-13.





7. REPLACEMENT OF AUDIO/TIME CODE HEAD

Replacement procedure:

- (1) Remove the audio/time code head block.
- (2) Remove the shield case (2).
- (3) Unsolder the six leads of AH-9 board.
- (4) Replace the audio/time code head to the new one and solder the leads that is unsoldered in step (3).

tube color	lead color	AH-9 board
black	white	TY
	red	TX
blue	white	2Y
	red	2X
red	red	1X
	white	1Y

- (5) Install the shield case while pressing in the direction of the arrow.
- (6) Perform the adjustment as sec. 6-13.




6-8. REPLACEMENT OF TENSION REGULATOR

6-8-1. Replacement of Tension Regulator Block

Replacement procedure:


- (1) Remove the threading ring as sec. 6-12.
- (2) Remove the two fixing screws on the back of the set and remove the tension regulator block.
- (3) After replacement, perform the adjustment as sec. 6-13.



6-8-2. Replacement of Tension Regulator Arm

Replacement procedure:

- (1) Put the machine into the unthreading end mode.
- (2) Remove the T.DME shield plate.
- (3) Remove the tension regulator arm.
- (4) After replacement, perform the adjustment as sec. 6-13.



7-9. REPLACEMENT OF TENSION REGULATOR BLOCK. DME


Since the DME of the tension regulator block is pasted with a locking compound to the DME holder, replace the following two parts simultaneously.

DME (DM 208) : 8-745-208-00

DME holder : 3-675-868-00

Replacement procedure:


- (1) Disconnect the connector on the TR-14 board on the back of the chassis.
Remove the tension regulator arm as sec. 6-8-2.
- (2) Remove the TR-14 board from the tension regulator block.
Remove the DME from the TR-14 board.
- (3) Bend the four leads of the DME so that it can be through the hole of the DME holder.
- (4) Apply an adhesive compound such as epoxy resin at the DME holder as shown in figure.
- (5) Insert the DME that leads is bent in step (3) to the DME holder. Bend again the four leads of the DME while holding the DME not to make clearance.
- (6) Cut the four leads of the DME as specified size.
- (7) Solder the DME block on the TR-14 board.
- (8) Attach the DME block on the TR-14 board with an adhesive compound such as epoxy resin.
(Never cut the adhesive compound from the * marked portion of the DME holder.)
- (9) After replacement, perform the adjustment as sec. 6-13.



6-10. REPLACEMENT OF ROTATION DETECTOR BLOCK

Replacement procedure:


- (1) Remove the threading ring as sec. 6-12.
- (2) Remove the rotation detector block.
- (3) Replace the defective parts.
- (4) Solder the harness on the LE board as shown in figure.
- (5) After replacement, perform the adjustment as sec. 6-13.



6-11. REPLACEMENT OF THREADING MOTOR

Replacement procedure:


- (1) Remove the connector, CN1/LM-4 board of the gear box block on the back of the set.
- (2) Remove the gear box.
- (3) Remove the LM pulley (2) from the threading motor and install it on the new threading motor so that the clearance between the pulley and the motor meets the required specification.
- (4) After replacement, perform the adjustment as sec. 6-13.



6-12. REPLACEMENT OF THREADING RING

Replacement procedure:

- (1) Turn the pulley of the gear box with hand till the threading ring places just before threading completion state.
- (2) Loosen the mounting screw of the gear box and disengage the threading ring and the drive gear.
- (3) Loosen the mounting screw of the tape beginning sensor and move the tape beginning sensor to the opposite direction of the threading ring.
- (4) Loosen the mounting screw of the ring roller (B) ass'y and cancel the holding of the threading ring.
- (5) Replace the threading ring.
- (6) After replacement, perform the adjustment as sec. 6-13.



6-13. ADJUSTMENT ITEM TABLE MAIN PARTS REPLACEMENT

Replacement of Supply Reel Table

Reel Table Height Adjustment (7-1-2) → Reel Table Rotation Detector Block Position Adjustment (7-1-3) → S Soft Brake Torque Adjustment (8-1) → FWD Back Tension Adjustment (8-4) → Video Tracking Adjustment (9-2) (When the tracking adjustment is performed, adjust referring "Adjustment Steps of Tracking Adjustment", described on Sec.9 Adjustment Information.) → Pinch Roller Pressure Timing Adjustment (9-14)

Replacement of Take-up Reel Table

Reel Table Height Adjustment (7-1-2) → Reel Table Rotation Detector Block Position Adjustment (7-1-3) → Tape Run Adjustment (9-1)

Replacement of Supply Reel Motor

Reel Motor Shaft Slantness Adjustment (7-1-1) → Reel Table Height Adjustment (7-1-2) → Main Brake Clearance Adjustment (7-2-1) → Supply Soft Brake Adjustment (7-2-2) → Reel Table Rotation Detector Block Position Adjustment (7-1-3) → S Soft Brake Torque Adjustment (8-1) → Reel Motor Torque Adjustment (8-2) → Tension Sensor Impressed Voltage Adjustment (8-3) → FWD Back Tension Adjustment (8-4) → REV Tension Adjustment (8-5) → Video Tracking Adjustment (9-2) (When the tracking adjustment is performed, adjust referring "Adjustment Steps of Tracking Adjustment", described on Sec.9 Adjustment Information.) → Pinch Roller Pressure Timing Adjustment (9-14) → Servo System Adjustment

Replacement of Take-up Reel Motor

Reel Motor Shaft Slantness Adjustment (7-1-1) → Reel Table Height Adjustment (7-1-2) → Reel Table Rotation Detector Block Position Adjustment (7-1-3) → Main Brake Clearance Adjustment (7-2-1) → Take-up Pause Brake Adjustment (7-2-3) → Reel Motor Torque Adjustment (8-2) → Tension Sensor Impressed Voltage Adjustment (8-3) → Tape Run Adjustment (9-1) → Video Tracking Adjustment (9-2) (When the tracking adjustment is performed, adjust referring "Adjustment Steps of Tracking Adjustment", described on Sec.9 Adjustment Information.) → Pinch Roller Pressure Timing Adjustment (9-14) → Servo System Adjustment

Replacement of Capstan Motor

Pinch Press Mechanism Block Position Adjustment (7-4-2) → Tape Run Adjustment (9-1) → Video Tracking Adjustment (9-2) (When the tracking adjustment is performed, adjust referring "Adjustment Steps of Tracking Adjustment", described on Sec.9 Adjustment Information.) → Pinch Roller Pressure Timing Adjustment (9-14) → Servo System Adjustment

Replacement of Threading Motor

Gear Block Position Adjustment (7-3-2) → Servo System Adjustment

Replacement of Threading Ring

Replacement of Rotation Detector Block

Threading Ring Rotation Adjustment (7-3-1) ———> Gear Box Position Adjustment
(7-3-2) ———> Ring Arm Position Adjustment (7-3-3) ———> TE-2 Block Position Adjustment (7-3-4) ———> TE-3 Block Position Adjustment (7-3-5) ———> Tension Regulator
Hook Arm Release Adjustment (7-5-2) ———> Hook Adjustment Plate Position Adjustment
(7-5-3) ———> END Sensor Position Adjustment (7-7) ———> Pinch Release Arm Position
Adjustment (7-8) ———> Tape Run Adjustment (9-1) ———> Video Tracking Adjustment
(9-2) (When the tracking adjustment is performed, adjust referring "Adjustment
Steps of Tracking Adjustment", described on Sec.9 Adjustment Information.)
——> Pinch Roller Pressure Timing Adjustment (9-14)

Replacement of Tension Regulator

Replacement of Tension Regulator Arm

Replacement of Tension Regulator Arm. DME

All Adjustments described on Replacement of Threading Ring ———> Tension Regulator
System Adjustment (7-5) ———> FWD Back Tension Adjustment (8-4) ———> REV Tension
Adjustment (8-5) ———> Video Tracking Adjustment (9-2) (When the tracking adjust-
ment is performed, adjust referring "Adjustment Steps of Tracking Adjustment",
described on Sec.9 Adjustment Information.) ———> Pinch Roller Pressure Timing
Adjustment (9-14)

Replacement of CTL Head

CTL Polarity Check (9-4) ———> CTL Head Azimuth/Zenith Adjustment (9-8) ———> CTL Head
Height Adjustment (9-9) ———> Video Tracking Adjustment (9-2) (When the tracking
adjustment is performed, adjust referring "Adjustment Steps of Tracking Adjust-
ment", described on Sec.9 Adjustment Information.) ———> CTL Head Position Adjust-
ment (9-5) ———> TC Head Position Adjustment (9-6) ———> Pinch Roller Pressure Timing
Adjustment (9-14) ———> Servo System Adjustment

Replacement of Audio/TC Head

Audio/TC Head Zenith Adjustment (9-10) ———> Audio Head Height Adjustment (9-11)
——> Audio Head Tape-to-Head Contact Adjustment (9-12) ———> Audio Head Phase
Adjustment (9-13) ———> Video Tracking Adjustment (9-2) (When the tracking adjust-
ment is performed, adjust referring "Adjustment Steps of Tracking Adjustment",
described on Sec.9 Adjustment Information.) ———> TC Head Position Adjustment (9-6)
——> Audio System Adjustment

Replacement of Drum Assembly

Servo System Adjustment ———> (When the tracking adjustment is performed, adjust
referring "Adjustment Steps of Tracking Adjustment", described on Sec.9 Adjust-
ment Information.) ———> Slip-ring Brush Position Adjustment (9-15) ———> Video
System Adjustment

Replacement of Upper Drum Assembly

Upper Drum Eccentricity Adjustment (6-3) — Video Tracking Adjustment (9-2)

(When the tracking adjustment is performed, adjust referring "Adjustment Steps of Tracking Adjustment", described on Sec.9 Adjustment Information.) — Video Head

Dihedral Adjustment (9-3) — CTL Head Position Adjustment (9-5) — TC Head

Position Adjustment (9-6) — Switching Position Adjustment (9-7) — Slip-ring

Brush Position Adjustment (9-15) — Pinch Roller Pressure Timing Adjustment

(9-14) — Video System adjustment

SECTION 7 LINK AND DRIVE SYSTEM ALIGNMENT

ALIGNMENT INFORMATION

MODE

. Unthreading end mode

It means EJECT completion mode.

The tension regulator arm and threading ring are put back at the cassette tape side completely.

. Threading mode

Press the PLAY button. Threading mode means that the threading ring is rotating in counterclockwise direction.

. Threading end mode

Press the PLAY button. The threading ring is rotating in counterclockwise direction, and then the threading ring rotation is stopped. This state means the threading end mode.

. PLAY mode without cassette tape

Press the PLAY button. The threading ring is rotating in counterclockwise direction, and the pinch roller is pressed against the capstan shaft after the threading ring rotation is stopped. This state means the PLAY mode without tape.

. STANDBY OFF mode without tape

- (1) Put the machine into the PLAY mode without tape. (Refer to "PLAY mode without tape".)
- (2) Press the STOP button. Then, the pinch roller is disengaged from the capstan shaft.
- (3) Press the STANDBY button. Then, the machine put into the STANDBY OFF mode. (The drum rotation is stopped in the STANDBY OFF mode.)

. REV mode without tape

- (1) Put the machine into the PLAY mode without tape. (Refer to "PLAY mode without tape".)
- (2) Turn the SEARCH DIAL in counterclockwise direction. Then, the machine put into the REV mode.

SECTION 7 LINK AND DRIVE SYSTEM ALIGNMENT

ALIGNMENT INFORMATION

NOTE

Unintentional and reads

It means EJECT completion mode.
The tension regulator air and threading ring are put back at the cassette tape side completely.

Threading mode

Press the PLAY button. Threading mode means that the threading ring is rotating in counterclockwise direction.

Threading and mode

Press the PLAY button. The threading ring is rotating in counterclockwise direction, and then the threading ring rotation is stopped. This state means the threading and mode.

PLAY mode without cassette tape

Press the PLAY button. The threading ring is rotating in counterclockwise direction, and the pinch roller is pressed against the cassette shell after the threading ring rotation is stopped. This state means the PLAY mode without tape.

STANDBY OFF mode without tape

- (1) Put the machine into the PLAY mode without tape. (Refer to "PLAY mode without tape".)
- (2) Press the STOP button. Then the pinch roller is disengaged from the cassette shell.
- (3) Press the STANDBY button. Then the machine goes into the STANDBY OFF mode. (The drum rotation is stopped in the STANDBY OFF mode.)

REW mode without tape

- (1) Put the machine into the PLAY mode without tape. (Refer to "PLAY mode without tape".)
- (2) Press the STANDBY button. Then the machine goes into the STANDBY OFF mode. (The drum rotation is stopped in the STANDBY OFF mode.)

7-1. REEL TABLE ADJUSTMENT

- Since the reel motor shaft slantness adjustment and the reel table height adjustment functions as the reference in the entire tape run system, it is requested that these adjustments should be attempted carefully, and deliberately.

7-1-1. Reel Motor Shaft Slantness Adjustment

- This adjustment is required only when the reel motor is replaced or removed.

Mode: Unthreading end

Tool: Cassette reference plate

Reel motor shaft slantness check jig

Check procedure:

- (1) Remove the reel table from the reel motor shaft.
- (2) Put the cassette reference plate at the position for the cassette.
- (3) Check that the clearance between the check jig and the shaft meets the required specification, when the reel motor shaft slantness check jig is set on the reel motor shaft from two directions as shown in figure.

Adjustment procedure:

- (1) Insert the reel motor spacer at the reel motor mounting screw as shown in figure.


video head spacer

0.01mm thick : 3-630-035-01

0.02mm thick : 3-630-035-11

0.03mm thick : 3-630-035-21

0.04mm thick : 3-630-035-31



7-1-2. Reel Table Height Adjustment

. This adjustment is required only when the reel motor and reel table are replaced or removed.

Mode: Unthreading end

Tool: Cassette reference plate

Allen wrench (each edge has 1.5mm)

Adjustment procedure:

- (1) Put the cassette reference plate at the position for the cassette.

- (2) Move the gauge as shown in figure. Adjust height by the washer from under the reel table so that the * marked portion of the gauge can slide over the reel table, while the ** marked portion is blocked, and cannot slide over reel table.


Adjustment washer

Poly-slider-washer, 4mm dia.

0.13mm thick : 3-701-441-01

0.25mm thick : 3-701-441-11

0.5 mm thick : 3-701-441-21



7-1-3. Reel Table Rotation Detector Block Position Adjustment

Mode: Any mode


Tool: Thickness gauge

Check procedure:

- (1) Check that the clearances between the supply reel table and the DME on the reel table rotation detector block, and between the take-up reel table and the DME meet the required specification.

Adjustment procedure:

- (1) Adjust the position of the reel table rotation detector block to meet the required specification.



7-2. BRAKE SYSTEM ADJUSTMENT

7-2-1. Main Brake Clearance Adjustment


Mode: Unthreading end

Check procedure:

- (1) Push the iron core of the brake solenoid with finger into the energized position in the direction of the arrow.
Check that the clearances between the supply reel table and the supply main brake, and between the take-up reel table and the take-up main brake meet the required specification.

Adjustment procedure:

- (1) Loosen the mounting screw of the MB solenoid base about 1/2 to 1 turn.
- (2) Insert the flatblade screwdriver, 3mm dia. into the adjusting hole as shown in figure.
- (3) Adjust the position of the MB solenoid base with screwdriver to meet the required specification, when the iron core of the brake solenoid is pushed in the direction of the arrow with finger.



7-2-2. Supply Soft Brake Adjustment


Mode: Unthreading end

Check procedure:

- (1) Check that the clearance between the supply reel table and the supply soft brake exists. (Spec. (2))
- (2) Push the iron core of the S brake solenoid with finger into the energized position in the direction of the arrow. Check that the clearance between the S brake arm and the S brake limiter meets the required specification. (Spec. (1))

Adjustment procedure:

- (1) Remove the reel table rotation detector block.
- (2) Loosen the two mounting screws of the S brake solenoid block about 1/2 to 1 turn.
- (3) Insert the flatblade screwdriver, 3mm dia. in the adjusting hole as shown in figure.
- (4) Adjust the position of the S brake solenoid block with screwdriver to meet the required specification (1), when the iron core of the S brake solenoid is pushed with finger in the direction of the arrow.
- (5) After adjustment, take finger off and check that the required specification (2) is met.
- (6) After adjustment, install the reel table rotation detector block and adjust its position.



7-2-3. Take-up Pause Brake Adjustment


Mode: Unthreading end

Check procedure:

- (1) Check that the clearance between the take-up reel table and the T brake rubber roller exists. (Spec. (2))
- (2) Push the iron core of the take-up reel brake solenoid with finger into the energized position in the direction of the arrow.
Check that the clearance between the T brake base and the boss meets the required specification. (Spec. (1))

Adjustment procedure:

- (1) Loosen the mounting screw of the take-up pause brake block about 1/2 to 1 turn.
- (2) Move the take-up pause brake block in the direction of the arrow to meet the required specification (1), when the iron core of the take-up reel brake solenoid is pushed with finger in the direction of the arrow.
- (3) After adjustment, take finger off the iron core and check that the required specification (2) is met.



7-3. THREADING RING SYSTEM ADJUSTMENT

7-3-1. Threading Ring Rotation Adjustment

- . This adjustment is required only when the threading ring or ring roller (B) ass'y is replaced or removed.

Mode: Turn the power off while rotating the threading ring 180 degrees from unthreading end state.

Check procedure:

- (1) Check that the horizontal play meets the required specification when the threading ring is pushed in the direction of the arrow with finger.
- (2) Check that the rotation of the threading ring into the threading and unthreading modes are smooth.


Adjustment procedure:

- (1) Adjust the position of the ring roller (B) ass'y to meet the required specification.

Adjusting procedure;

.Insert a 0.3mm thick paper between the threading ring and the ring roller.

.Paper of this manual is about 0.1mm thick so that three fold becomes 0.3mm thick.



7-3-2. Gear Box Position Adjustment


. It is required that the sec. 7-3-1 threading ring rotation adjustment is checked to be correct or properly adjusted before initiating this adjustment.

Check procedure:

- (1) Put the machine into the unthreading end mode.
- (2) Turn the pulley of the gear box with finger about 90 degrees in the direction of the arrow.
- (3) While pushing the threading ring in the direction of the arrow (B) with finger, check that the clearance between the threading ring and the drive gear of the gear box meets the specification.

Adjustment procedure:

- (1) Loosen the mounting screws of the gear box 1 to 2 turns.
- (2) Press the threading ring in the direction of the arrow (A), while pushing the drive gear of the gear box against the threading ring lightly.
- (3) Tighten the mounting screws of the gear box confirm as check procedure.



7-3-3. Ring Arm Position Adjustment



Mode: Threading end

Check procedure:

- (1) Check that the clearance (A) between the release arm and the ring arm meets the specification (1).
- (2) Check that the clearance (B) between the threading ring and the roller of the ring arm meets the specification (2).

Adjustment procedure:

- (1) Move the ring arm position in the direction of the arrow (D) so that it meets the specifications (1) and (2).



Spec. (1):
 $0.1 \text{ mm} \leq \textcircled{A} \leq 0.3 \text{ mm}$
 Spec. (2):
 $\textcircled{B} \leq 0.2 \text{ mm}$

7-3-4. TE-2 Block Position Adjustment

The threading end detection is performed in the TE-2 block.

Mode: Threading end (POWER ON)

Tool: Circuit tester

Thickness gauge

Check procedure:


- (1) Remove the SY-91 board. Extend it with the extension board. Connect the (+) lead of the circuit tester to the CN2 pin13B/SY-91 board and the (-) lead to the CN1 pin30/SY-91 board.
- (2) Move the roller of the TE arm with finger in the direction of the arrow. Check that the circuit tester indicates about 1V when the roller is placed 3.5mm apart from the threading ring. (Spec (1))
- (3) Check that the circuit tester indicates about 5V when the roller is placed 4.5mm apart from the threading ring. (Spec (2))

Adjustment procedure:

- (1) Loosen the mounting screw of the TE-2 block about 1/2 to 1 turn.
- (2) Insert a flatblade screwdriver, 3mm dia. into the adjusting hole and adjust the position of the TE-2 block so that it meets the specifications (1) and (2).

Adjusting procedure;

Adjust the TE-2 block so that the circuit tester indicates about 1V to 5V when the TE roller arm is placed 4mm apart from the threading ring.



7-3-5. TE-3 Block Position Adjustment

The threading end and the unthreading end detections are performed in the TE-3 block.

Mode: Threading end (POWER ON)

Tool: Circuit tester

Thickness gauge

Check procedure:


- (1) Remove the SY-91 board. Extend it with the extension board. Connect the (+) lead of the circuit tester to the CN2 pin14B/SY-91 board and the (-) lead to the CN1 pin30/SY-91 board.
- (2) Move the roller of the ring arm with finger in the direction of the arrow. Check that the circuit tester indicates about 1V when the roller is placed 3.5mm apart from the threading ring. (Spec.(1))
- (3) Check that the circuit tester indicates about 5V when the roller is placed 4.5mm apart from the threading ring. (Spec (2))

Adjustment procedure:

- (1) Loosen the mounting screw of the TE-3 block about 1/2 to 1 turn.
- (2) Insert a flatblade screwdriver, 3mm dia. into the adjusting hole and adjust the TE-3 block position to meet the specifications (1) and (2).

Adjusting procedure;

Adjust the TE-3 block so that the circuit tester indicates about 1V to 5V when the ring arm roller is placed 4mm apart from the threading ring.



7-4. PINCH PRESS MECHANISM BLOCK ADJUSTMENT

7-4-1. Pinch Roller Pressure Adjustment

Mode: Unthreading end


Tool: Tension scale (500g full scale)

Check procedure:

- (1) Push the iron core of the pinch solenoid into the fully energized position in the direction of the arrow.
- (2) Set the tension scale as shown in figure, and press the pinch press lever (B) with it in the direction of the arrow.
- (3) When the clearance between the pinch press lever (A) and (B) is $0.7\text{mm} \pm 0.2\text{mm}$, check that the scale reading meets the required specification.

Adjustment procedure:

- (1) Change the position of the spring to meet the required specification.



4-2. Pinch Press Mechanism Block Position Adjustment


Mode: PLAY mode without cassette tape

Check procedure:

- (1) Put the machine into the PLAY mode without cassette tape.
- (2) Check that the clearance between the pinch press levers (A) and (B) meets the required specification.

Adjustment procedure:

- (1) Loosen the mounting screws of the pinch press mechanism block about 1/2 to 1 turn.
- (2) Insert a flatblade screwdriver, 3mm dia. into the notch of the pinch press mechanism, and adjust the pinch press mechanism position to meet the required specification.



7-5. TENSION REGULATOR SYSTEM ADJUSTMENT

7-5-1. Tension Regulator Arm Slantness Adjustment

. This adjustment is closely related with the video tracking adjustment.

. Perform the video tracking adjustment after this adjustment.

Mode: Threading end

Tool: Cassette reference plate

Tension regulator slantness check tool

Check procedure:

(1) Put the cassette reference plate in the cassette position.

(2) Place the tension regulator slantness check tool against the tension regulator roller.

Check that the slantness of the roller meets the required specification viewing from the direction of the arrows A and B as shown in figure.

Adjustment procedure:

. When the slantness is out of spec. viewing from the direction of the arrow A:

(1) Loosen the fixing screws (A) and (B).

(2) Adjust the slantness with the adjusting screw (A) and fixing screw (B).

. When turning the adjusting screw (A) and fixing screw (B) in the clockwise direction, the upper clearance is narrowed.

(3) Tighten the fixing screw (A) and check again.

(4) After adjustment, perform the step (8).

. When the slantness is out of spec. viewing from the direction of the arrow B.

(5) Loosen the fixing screws (A) and (C).

(6) Adjust the slantness with the adjusting screw (B).


. When turning the adjusting screw (B) in the counterclockwise direction, the upper clearance is more narrow.

(7) Tighten the fixing screws in order of (C), (A) and check again.

(8) After adjustment, perform the following adjustments.

Sec.9-2 Video Tracking Adjustment

Sec.7-5-4 Tension Regulator Arm Position Adjustment




7-5-2. Tension Regulator Hook Arm Release Adjustment

Check procedure:

- (1) Start the threading and turn the power off when the threading ring rotate 180 degrees from unthreading end state.
- (2) Check that the clearance between the tension regulator hook arm and the return arm pin meets the required specification.

Adjustment procedure:

- (1) Loosen the mounting screw of the hook adjusting plate about 1/2 to 1 turn.
- (2) Insert a flatblade screwdriver 3mm dia. into the adjusting hole. Adjust the position of the hook adjusting plate so that it meets the required specification.
- (3) After adjustment, perform sec. 7-5-3, Hook Adjusting Plate Position Adjustment.



7-5-3. Hook Adjusting Plate Position Adjustment


Mode: Treading end

Check procedure:

- (1) Check that the clearance between the TE arm and the hook adjusting plate meets the required specification.

Adjustment procedure:

- (1) Loosen the mounting screw of the hook adjusting plate about 1/2 to 1 turn.
- (2) Insert a flatblade screwdriver 3mm dia. into the adjusting hole. Adjust the position of the hook adjusting plate so that it meets the required specification.
- (3) After adjustment, perform sec. 7-5-2, Tension Regulator Hook Arm Release Adjustment.



7-5-4. Tension Regulator Arm Position Adjustment

- . This adjustment is closely related with the video tracking adjustment and the tension regulator arm slantness adjustment.
- . Perform this adjustment after initiating the video tracking adjustment and the tension regulator arm slantness adjustment.

Mode: STANDBY OFF (POWER ON state)

Tool: Digital multi meter

Tension scale (50g full scale)

Locally-Specially-Made-Tape
(prepare this tape as follows)

- (1) Prepare a 12cm long video tape. (Worm out tape is acceptable)
- (2) Make a loop on an end of the video tape. Attach adhesive tape on the other end. Make a hole on the adhesive tape.
- (3) Make a loop of 30cm long string through the hole.

Preparation:


- (1) Connect the digital multi meter to pin 16 of IC36/SV-51 board, and check the voltage.
- (2) Connect the digital multi meter to TP12/SV-51 board.

Check procedure:



- (1) Install the locally-specially-made-tape on the TG-0 and thread the tape as shown in figure.
- (2) Hook a tension scale on an end of a string. Move the scale in the direction of the arrow till the scale indicates 45g.
- (3) When the scale indicates 45g, check that the clearance between the tape guide (2) stopper and the tension regulator arm meets the specification (1), and the digital multi meter reading meets the specification (2) simultaneously.

Adjustment procedure:

- . When the clearance is out of spec. (1).
- (1) Loosen the mounting screw of the tension regulator hook ass'y about 1/2 to 1 turn.
 - (2) Insert a flatblade screwdriver 3mm dia. into the adjusting hole and adjust the tension regulator hook ass'y position so that it meets the specification (1).



Locally-Specially-Made-Tape



Spec. 1:
 $0.7\text{mm} \leq \textcircled{A} \leq 1\text{mm}$

Spec. 2:
 $\frac{1}{2}B - 0.05\text{ Volt} \leq C \leq \frac{1}{2}B + 0.05\text{ Volt}$
• B is a voltage between IC36, pin 16/
SV-51 board and TPE

(3) After tighten the mounting screw, check to meet the specification (1) again.

(4) Check to meet the specification (2).

. When the digital multi meter reading is out of spec. (2).

(5) Loosen the mounting screw of TR board.



(6) Adjust the position of the TR board so that it meets the specification (2).

(7) Tighten the mounting screw and check to meet the specification (2) again.

(8) After adjustment, perform the following adjustment.

Sec. 8-4, FWD Back Tension Adjustment

Sec. 8-5, REV Tension Adjustment



7-6. CASSETTE UP COMPARTMENT ADJUSTMENT

7-6-1. Lid Opener Lever Position Adjustment


This adjustment is required only when the lid opener lever is re-placed or removed. Remove the cassette up compartment from the machine in this adjustment.

Check procedure:

- (1) Check that there is no clearance between the hook and the lid opener lever (black colored plastic) on the two points as shown in figure.

Adjustment procedure:

- (1) Adjust to meet the required specification with adjusting screw.



7-6-2. Lid Opener Lever Block Position Adjustment

This adjustment is required only when the lid opener lever block is removed from the cassette up compartment. Remove the cassette up compartment from the machine in this adjustment.


Tool: Slide vernier caliper or equivalent

Check procedure:

- (1) Place the cassette up compartment in the up state.
- (2) Check that the positional relationship between the lid opener lever and the right side panel meets the required specification.

Adjustment procedure:

- (1) Adjust the position of the lid opener lever block so that it meets the required specification.



7-6-3. Motor Block Position Adjustment


- . Remove the cassette up compartment from the machine in this adjustment.

Check procedure:

- (1) When the midway gear is turned in the direction of the arrow, check that the clearance between the midway gear and the worm gear meets the required specification.

Adjustment procedure:

- (1) Loosen the mounting screws about 1 turn.
- (2) Adjust the position of the motor block to meet the required specification.



7-6-4. Cassette in Switch Position Adjustment

Remove the cassette up compartment from the machine in this adjustment.

Tool: Slide vernier caliper or equivalent
Circuit tester

Preparation:

- (1) Remove the SY-91 board.
Extend it with the extension board.
- (2) Connect the circuit tester to the connector CN2-12A/SY-91 board.
- (3) Unsolder the jumper lead of the motor, A terminal from the CL-7 board.
- (4) Connect the following terminals with jumper leads between CN1 on CL-7 board and harness connector for cassette up compartment.

harness connector	CN1/CL-7
5pin	5pin
6pin	6pin
7pin	7pin
8pin	8pin


- (5) Turn the power on.

Check procedure:

- (1) Turn the worm gear of the motor block in the cassette up state.
- (2) Move the slider with finger into direction of the arrow as shown in figure. Check that the circuit tester indicates less than 1V to more than 4V when the clearance between the slider and the cassette compartment is 3.5mm to 4.5mm.
- (3) Check that the clearance between the slider and the sensor meets the required specification. (Spec.(2))
- (4) When the specifications (1) and (2) are met, perform the adjustment procedure step (2).

Adjustment procedure:

- (1) Adjust the position of the cassette in switch block (PC-18 board) to meets the specifications (1) and (2).
- (2) After adjustment, solder the jumper lead of the motor to the A terminal, CL-7 board.



7-6-5. Cassette Down Switch Position Adjustment

. Remove the cassette up compartment from the machine in this adjustment.

Tool: Slide vernier caliper or equivalent
Circuit tester

Preparation:

- (1) Remove the SY-91 board.
Extend it with the extension board.
- (2) Connect the circuit tester to the connector CN2,13A/SY-91 board.
- (3) Unsolder the jumper lead of the motor, the A terminal from the CL-7 board.
- (4) Connect the following terminals with jumper leads between CN1 on CL-7 board and harness connector for cassette up compartment.

harness connector	CN1/CL-7
5pin	5pin
6pin	6pin
7pin	7pin
8pin	8pin

- (5) Turn the power on.


Check procedure:

- (1) Turn the worm gear of the motor block in the cassette down state.
- (2) Move the drive gear (L) with finger in the direction of the arrow as shown in figure.

Check that the circuit tester indicates less than 1V to more than 4V when the clearance as shown in figure is 3.5mm to 4.5mm.

Adjustment procedure:

- (1) Move the cassette down switch block (PC-17 board) in the direction of the arrow.



7-7. END SENSOR POSITION ADJUSTMENT


Mode: PLAY

Check procedure:

- (1) Insert a cassette tape and put the machine into the PLAY mode.
- (2) Check that the clearance between the tape end sensor and the tape meets the required specification.
- (3) Check that the clearance between the tape beginning sensor and the tape meets the required specification as shown in figure.

Adjustment procedure:

- When the clearance of tape end sensor is out of spec.
 - (1) Bend the mounting plate with pliers as shown in figure.
- When the clearance of tape beginning sensor is out of spec.
 - (2) Loosen the mounting screw as shown in figure and adjust the position of the tape beginning sensor.



7-8. PINCH RELEASE ARM POSITION ADJUSTMENT

Mode: Unthreading end


Tool: Thickness gauge

Check procedure:

- (1) Check that the clearance between the pinch release arm and the threading ring meets the required specification.

Adjustment procedure:

- (1) Adjust the position of the pinch release arm to meet the required specification.



SECTION 8

TORQUE AND BACK TENSION ALIGNMENT

ALIGNMENT INFORMATION

MODE

. Unthreading end mode

It means EJECT completion mode.

The tension regulator arm and threading ring are put back at the cassette tape side completely.

. Threading mode

Press the PLAY button. Threading mode means that the threading ring is rotating in counterclockwise direction.

. Threading end mode

Press the PLAY button. The threading ring is rotating in counterclockwise direction, and then the threading ring rotation is stopped. This state means the threading end mode.

. PLAY mode without cassette tape


Press the PLAY button. The threading ring is rotating in counterclockwise direction, and the pinch roller is pressed against the capstan shaft after the threading ring rotation is stopped. This state means the PLAY mode without tape.

. STANDBY OFF mode without tape

- (1) Put the machine into the PLAY mode without tape. (Refer to "PLAY mode without tape".)
- (2) Press the STOP button. Then, the pinch roller is disengaged from the capstan shaft.
- (3) Press the STANDBY button. Then, the machine put into the STANDBY OFF mode. (The drum rotation is stopped in the STANDBY OFF mode.)

. REV mode without tape

- (1) Put the machine into the PLAY mode without tape. (Refer to "PLAY mode without tape".)
- (2) Turn the SEARCH DIAL in counterclockwise direction. Then, the machine put into the REV mode.




SECTION 8 TORQUE AND BACK TENSION ALIGNMENT

HOW TO MAKE THE LOCALLY-SPECIALLY-MADE-TAPE

This tape is used for the FWD Back Tension and REV Back Tension adjustments. Prepare this tape as follows:

- (1) Wind the L-500 cassette tape to the tape beginning portion.
- (2) Remove the four screws on back of the cassette tape, and remove the upper half of the cassette.
- (3) Remove the lock mechanism parts and the springs on the left and right.
- (4) Remove the cassette lid from the upper half.
- (5) Taken up the video tape on the take-up reel about 1 meter. Cut the video tape at the position as shown in figure. Remove the take-up reel from the cassette.
- (6) Attach an adhesive tape on an end of the tape at the supply side and make a hole on the adhesive tape.
- (7) Make a loop of 6cm long string through the hole.
- (8) Install the upper half on the lower half with four screws from the back side.

< locally-specially-made-tape >



8-1. S SOFT BRAKE TORQUE ADJUSTMENT

Mode: Unthreading end (POWER on state)

Tool: Reel table tension gauge

Tension scale (20g full scale)

Preparation:


- (1) Remove the left and right side ornamental panels.
- (2) Remove the control panel.

Check procedure:

- (1) Wind the string of the reel table tension gauge in the clockwise direction.
- (2) Install the reel table tension gauge on the supply reel table, and hook a tension scale on an end of the string.
- (3) Push the iron core of the S brake solenoid into the fully energized position. (Don't remove finger.)
- (4) In the energized position, pull out the tension scale to the direction of the arrow and confirm that the scale reading is in the specification.

Adjustment procedure:

- (1) Change the position of the spring on the S brake block so that it meets the required specification.



8-2. REEL MOTOR TORQUE ADJUSTMENT

. This adjustment is only applied to the machine, serial No. 10001 to 10515.

The following variable resistors are changed to the resistor (non adjustable type) for the machine, serial No. 10516 and later.

Mode: Unthreading end (POWER on state)

Tool: Digital voltmeter

Check procedure: (1) Remove the SV-51 board. Extend it with extension board.

(2) Connect the digital voltmeter to each terminals, and check that the indication meets the required specification.

Adjustment procedure: (1) Adjust each variable resistor to meet the required specification.

Item	Check Point	Spec.	Adjustment
STOP Torque	15 pin / IC36	$146 \pm 10 \text{ mV}$	RV509
FF Back Tension	5 pin / IC36	$40 \pm 3 \text{ mV}$	RV510
Brake Torque	2 pin / IC36	$1080 \pm 50 \text{ mV}$	RV511
Brake Torque	4 pin / IC37	$-455 \pm 20 \text{ mV}$	RV519
EJECT Torque	14 pin / IC37	$135 \pm 10 \text{ mV}$	RV513
FWD Torque	12 pin / IC37	$223 \pm 20 \text{ mV}$	RV515
REV Back Tension	1 pin / IC37	$131 \pm 10 \text{ mV}$	RV516
REW Back Tension	5 pin / IC37	$10 \pm 2 \text{ mV}$	RV517

8-3. TENSION SENSOR IMPRESSED VOLTAGE ADJUSTMENT

Tool: Digital Voltmeter

Mode: STOP

Check procedure:

(1) Remove the SV-51 board. Extend it with extension board.

(2) Connect the digital voltmeter to TP513/SV-51 board, and check that the indication meets the required specification.
(Connect GND to E-3.)

Adjustment procedure:

(1) Adjust the RV520/SV-51 board to meet the required specification.

Spec.:
TP513/SV-51
 $9.0 \pm 0.1 \text{ V}$

8-4. FWD BACK TENSION ADJUSTMENT

Mode: Threading end → PLAY

Tool: Locally-specially-made-tape (Refer to alignment information)

Tension scale (100g full scale)

Preparation:


- (1) Remove the right side ornamental panel.
- (2) Remove the handle on the chassis of the control panel side.
- (3) Set the TROUBLE INHIBIT switch (S4-6) on the SY-91 board to ON state. (After completing this check and/or adjustment, be sure to set this switch to OFF state.)
- (4) Remove the SV-51 board. Extend it with extension board.

Check procedure:

- (1) Put the machine into the threading end state. Install the locally-specially-made-tape.
- (2) Thread the tape as shown in figure. Thread an end of the tape through the square hole of the side chassis as shown in figure.
- (3) Hook the tension scale on an end of the tape.
- (4) Put the machine into the PLAY mode.
- (5) Pull out the tape at the constant speed of approx. 12cm/sec. in the direction of the arrow. Check that the scale reading meets the required specification.
- (6) If the specification is met, perform the step (2) in the adjustment procedure.

Adjustment procedure:

- (1) Adjust RV502 on the SV-51 board to meet the required specification.
- (2) Set the TROUBLE INHIBIT switch (S4-6) on the SY-91 board to OFF state.



8-5. REV TENSION ADJUSTMENT

Mode: Threading end → REV

Tool: Locally-specially-made-tape (Refer to alignment information)

Tension scale (50g full scale)

Preparation:


- (1) Remove the right side ornamental panel.
- (2) Remove the handle on the chassis of the control panel side.
- (3) Set the TROUBLE INHIBIT switch (S4-6) on the SY-91 board to ON state. (After completing this check and/or adjustment, be sure to set this switch to OFF state.)
- (4) Remove the SV-51 board. Extend it with extension board.

Check procedure:

- (1) Put the machine into the threading end state. Install the locally-specially-made-tape.
- (2) Thread the tape as shown in figure. Thread an end of the tape through the square hole of the side chassis as shown in figure.
- (3) Hook a tension scale on an end of the tape.
- (4) Put the machine into REV mode.
- (5) Let the tape be pulled at the constant speed of approx. 12cm/sec. Check that the scale reading meets the required specification.
- (6) If the specification is met, perform the step (2) in the adjustment procedure.

Adjustment procedure:

- (1) Adjust RV501 on the SV-51 board to meet the required specification.
- (2) Set the TROUBLE INHIBIT switch (S4-6) on the SY-91 board to OFF state.



SECTION 9

TAPE RUN ALIGNMENT

ALIGNMENT INFORMATION

ALIGNMENT TAPE

. Alignment tape for tracking adjustment

CR2-1PS (8-960-098-02)

Contents	For use
Video, Y track : 4MHz signal (track width : 73 μ) C track : 5MHz signal (track width : 73 μ) Audio, blank TC, CTL signal	.Video tracking adjustment for player .CTL head position adjustment for player .TC head position adjustment for player .Switching position adjustment for player and recorder.

. Alignment tape for general adjustment

CR5-1PS (8-960-098-22)

Contents	For use
Video, color-bar signal TC, SMPTE time code signal	.Video, Audio, Servo and Time Code system adjustments
Video, gated sweep signal Audio, 1kHz signal	.Video and Audio adjustments
Video, 2T pulse/2T bar signal Audio, 10kHz signal	.Video adjustment .Audio head position adjustment
Video, monoscope signal (switching position is shifted) Audio, 1kHz, 7kHz, 10kHz, 15kHz signals	.Video head dihedral adjustment .Audio frequency response adjust- ment
Video, blank Audio, blank CTL, audio 0.8kHz signal	.CTL head height adjustment

SECTION 9 TAPE RUN ALIGNMENT

MODE

. Unthreading end mode

It means EJECT completion mode.

The tension regulator arm and threading ring are put back at the cassette tape side completely.

. Threading mode

Press the PLAY button. Threading mode means that the threading ring is rotating in counterclockwise direction.

. Threading end mode

Press the PLAY button. The threading ring is rotating in counterclockwise direction, and then the threading ring rotation is stopped. This state means the threading end mode.

. PLAY mode without cassette tape

Press the PLAY button. The threading ring is rotating in counterclockwise direction, and the pinch roller is pressed against the capstan shaft after the threading ring rotation is stopped. This state means the PLAY mode without tape.

. STANDBY OFF mode without tape

- (1) Put the machine into the PLAY mode without tape. (Refer to "PLAY mode without tape".)
- (2) Press the STOP button. Then, the pinch roller is disengaged from the capstan shaft.
- (3) Press the STANDBY button. Then, the machine put into the STANDBY OFF mode. (The drum rotation is stopped in the STANDBY OFF mode.)

. REV mode without tape


- (1) Put the machine into the PLAY mode without tape. (Refer to "PLAY mode without tape".)
- (2) Turn the SEARCH DIAL in counterclockwise direction. Then, the machine put into the REV mode.

HOW TO MAKE THE CASSETTE TAPE WITHOUT LID

Since the VTR is designed compact size, the check and adjustment can not be performed if cassette tape lid is installed.

The cassette tape lid removal procedures are as follows:

- (1) Remove the four screws on the back of the cassette as shown in figure, and remove the upper half of the cassette.
- (2) Remove the lock mechanism parts and the springs on the left and right.
- (3) Remove the cassette lid from the upper half.
- (4) Install the upper half on the lower half with four screws from the back side.




HOW TO MAKE THE ALIGNMENT TAPE WITHOUT LID

Since the VTR is designed compact size, the check and adjustment can not be performed if the alignment tape lid is installed.

Remove the lid of the alignment tape CR2-1PS for the tracking adjustment referring "How to make the cassette tape without lid".

ADJUSTMENT STEPS OF TRACKING ADJUSTMENT

. Perform the tracking adjustment of Video, Audio, CTL and Time Code Heads as follows.



9-1. TAPE RUN ADJUSTMENT

Mode: Playback


Tool: Cassette tape without lid (Never use the alignment tape)

Check procedure:

- 1) Insert a cassette tape and put the machine into the playback mode.
- 2) Check that the positional relationship between the tape and the tape guide at the take-up side of the cassette tape is as shown in figure. (Spec.(1))
- 3) Check that the tape tension is exactly equal at the tape top and tape bottom around the roller guide on the threading ring as shown in figure. (Spec.(2)).

Adjustment procedure:

- 1) Adjust the height of the guide (A) on the threading ring to meet the required specification (1).
- 2) Bend the T tape guide shaft in the direction of the arrow to meet the required specification (2).



9-2. VIDEO TRACKING ADJUSTMENT

Mode: Playback the alignment tape

Tool: Alignment tape, CR2-1PS

Oscilloscope

Allen wrench (each edge has 1.27mm)

Inspection mirror

Preparation:

- (1) Remove the YD-15 board. Extend it with the extension board.
- (2) Connect the oscilloscope as follows:
CH-1 : TP4/YD-15 board
GND : F1/YD-15 board
EXT.TRIG : TP2/YD-15 board
- (3) Playback the alignment tape.

Check procedure:

- (1) When turn the TRACKING volume, check that the RF waveform maintains a flat envelope while amplitude increases and decreases.
- (2) Check that the RF envelope fluctuation and head-to-tape contact are within the specification at the FIXED position of the TRACKING volume.
- (3) Check that the tape curls at the tension regulator, TG-1, TG-2, TG-3 and the tape threading guide meet the required specification.
- (4) Check that the RF envelope head-to-tape contact is within the specification in the REV x 1 mode.

Adjustment procedure:

When adjust the tape guide height.

- . Loosen the set screws of each tape guide and adjust with adjusting nut.

When the tracking at the drum entrance side is no good.

- (1) Turn the adjusting nuts of TG-1 and TG-2, and make clearances at (a), (b), of TG-1 and (a) of TG-2 as shown in figure 2.
- (2) Turn the adjusting nut of the tension regulator so that the RF envelope waveform changes from (i) state to (ii) state as shown in figure 3. Check that the tape runs in contact with the guide flange at the (a) portion of the tension




Fig. 1.





Fig. 2.



regulator. If not, turn the adjusting screw (a) of tension regulator in counter-clockwise direction as shown in figure 4.

- (3) Turn the adjusting nut of TG-2 so that the tape runs in contact with the guide flange at the (a) portion of TG-2 and the RF envelope waveform flatten. Check that the tape is not in contact with the guide flange at the (b) portion of TG-1. The tape curl at the (a) portion of tension regulator and/or (a) portion of TG-2 is acceptable within the range as shown in figure 5. But tape curl at the drum is not acceptable.
 - (4) Turn the TRACKING volume in FIXED position. Put the machine into REV x 1 mode.
 - (5) Check that the RF envelope waveform is small at the drum entrance side as shown in figure 6.
 - (6) Put the machine into FWD mode. Turn the adjusting nut of TG-1 so that the tape runs in contact with the guide flange at the (a) portion. The tape curl at (a) portion is acceptable within the range as shown in figure 5.
 - (7) Put the machine into REV x 1 mode. Check that the RF envelope waveform is flat and the tape-to-head contact meets the required specification. If the RF envelope waveform is not able to flat, turn the adjusting screw (b) of the tension regulator in clockwise direction as shown in figure 4. If the adjusting screw (b) turns in this step, perform step (1) and later.
 - (8) Put the machine into FWD mode. Check that the tape-to-head contact meets the required specification.
 - (9) Tighten the set screws of each tape guide, and check again.
- . When the tracking at the drum exit side is no good.
- (1) Turn the adjusting nuts of TG-3 and TG-4, and make clearances at the (a) of TG-3, (b) of TG-4 and (a) and (b) of the tape threading guide as shown in figure 7.

Fig. 3.




Fig. 4.




Fig. 5.




Fig. 6.






Fig. 7.



- (2) Turn the adjusting nut of TG-4 so that the RF envelope waveform changes from (i) state to (ii) state as shown in figure 8. Check that the tape is not in contact with the guide flange at the (a) portion of TG-3 and (a) portion of the tape threading guide.
- (3) Turn the adjusting nut of TG-3 so that the tape runs in contact with the guide flange at the (a) portion of TG-3 and the RF envelope waveform flattens.
- (4) Turn the adjusting nut of the tape threading guide so that the tape runs in contact with the guide flange lightly at the (a) portion.
- (5) Turn the TRACKING volume in FIXED position. Check that the tape-to-head contact meets the required specification.
- (6) Put the machine into REV x 1 mode.
- (7) Check that the RF envelope waveform is flat and the tape-to-head contact meets the required specification.
- (8) Tighten the set screws of each tape guides, and check again.

Fig. 8.



When press down the tape at A portion as shown in figure 7, the waveform should be flatten.



9-3. VIDEO HEAD DIHEDRAL ADJUSTMENT

This adjustment is performed only for the Y head.

The reference head is CH-A.

Mode: Playback the alignment tape

Tool: Alignment tape, CR5-1PS

Monitor TV

Dihedral adjusting screw (four pieces)

Oscilloscope

Preparation:


- (1) Connect the oscilloscope to TP7/YD-15 board and E1/YD-15 board. Connect the monitor TV to CH-1 OUT terminal of the oscilloscope.
- (2) Insert the alignment tape, and playback the monoscope signal (for dihedral adjustment) of the alignment tape.

Check procedure:

- (1) Check the vertical line beneath the switching point visually on a monitor. If the vertical line does not split into two lines, no adjustment is necessary.

Adjustment procedure:

- (1) Screw lightly four dihedral adjusting screws into the upper drum.
- (2) Turn the adjusting screw adjacent to the Y head with red/yellow leads until some resistance is felt.
- (3) If this screw is turned further, the video head is moved and the dihedral is adjusted. Therefore, turn this screw an additional quarter turn.
- (4) Check for dihedral distortion. If the distortion has gotten worse, turn this screw back one turn and tighten the other screw (red/orange leads side) a quarter turn. Check again for dihedral distortion and continue in this way until dihedral error is eliminated.
- (5) When the adjustment is completed, remove the four dihedral adjusting screws. After removal, playback the alignment tape and check dihedral again as error sometimes reappears after screws are removed.



(NOTE)

Be sure to stop the rotation of the upper drum in the dihedral adjustment.

Perform the following steps.

- (1) Press the STOP button.
- (2) Press the STANDBY button, then the machine put into the STANDBY OFF state. (The rotation of the upper drum is stopped.)
- (3) After dihedral adjustment, press the STANDBY button again.
- (4) Press the PLAY button.

9-4. CTL POLARITY CHECK

Mode: Playback the alignment tape

Tool: Alignment tape, CR2-1PS

Oscilloscope

Preparation:


- (1) Remove the SV-51 board. Extend it with extension board.
- (2) Connect the oscilloscope as follows:
CH-1 : TP301/SV-51 board
EXT.TRIG : TP301/SV-51 board
- (3) Playback the alignment tape.

Check procedure:

- (1) Check that the waveform meets the required specification.

Adjustment procedure:

- (1) Change the polarity of wiring on CTL head (CH-10 board).



9-5. CTL HEAD POSITION ADJUSTMENT

mode: Playback the alignment tape

Tool: Alignment tape, CR2-1PS

Oscilloscope

Preparation:



- (1) Remove the YD-15 board. Extend it with extension board.
- (2) Connect the oscilloscope as follows:
CH-1 : TP4/YD-15 board
GND : E1/YD-15 board
EXT.TRIG : TP2/YD-15 board
- (3) Playback the alignment tape.

Check procedure:

- (1) Check that the RF waveform has the maximum amplitude when the TRACKING volume is set in the detent position.

Adjustment procedure:

- (1) Loosen the fixing screws 1/4 to 1/2 turn.
- (2) Insert a flatblade screwdriver, 3mm dia. into the hole of CTL head base. Adjust the position of CTL head block to meet the required specification.
- (3) After adjustment, perform Sec. 9-6. TC Head Position Adjustment.



9-6. TC HEAD POSITION ADJUSTMENT

It is required that the CTL Head Position Adjustment is checked to be correct or properly adjusted before initiating this adjustment.

Mode: Playback the alignment tape

Tool: Alignment tape, CR2-1PS

Dual trace oscilloscope

Preparation:

(1) Connect the oscilloscope as follows:

CH-1 : TP301/SV-51 board

CH-2 : TP100/TC-25 board

TRIG : INTERNAL, CH-1

(2) Playback the alignment tape.


Check procedure:

(1) Check that the waveform meets the required specification.

Adjustment procedure:


(1) Loosen the fixing screw.

(2) Adjust the position of the head block with a flatblade screwdriver, 3mm dia. to meets the required specification.



TC
TP100/TC-25

CTL
TP301/SV-51



Spec.:
A = $0 \pm 400 \mu\text{sec.}$

9-7. SWITCHING POSITION ADJUSTMENT

Mode: Playback the alignment tape

Tool: Alignment tape, CR2-1PS

Oscilloscope

Preparation:


- (1) Remove the SV-51 board. Extend it with extension board.
- (2) Connect the oscilloscope as follows:
CH-1 : TP4/YD-15 board
CH-2 : TP4/CD-25 board
GND : E1/YD-15 board
EXT.TRIG : TP2/YD-15 board
- (3) Playback the alignment tape.

Check procedure:

- (1) Turn the TRACKING volume to the FIXED position.
- (2) Check that the lack of the CH-A and CH-B RF envelopes meet the required specification at the CH-1 of the oscilloscope.
- (3) Check that the lack of the CH-A and CH-B RF envelopes meet the required specification at the CH-2 of the oscilloscope.

Adjustment procedure:

- (1) Set the oscilloscope to the CH-1. (Y-RF envelope)
- (2) Adjust RV1 and RV3 on SV-51 board to meet the required specification.
(CAUTION)
Perform steps (3) and later when RV1 and RV3 are adjusted.
- (3) Set the oscilloscope to CH-2.
- (4) Adjust RV6 on SV-51 board to meet the required specification.



9-8. CTL HEAD AZIMUTH/ZENITH ADJUSTMENT

Mode: Unthreading end

Tool: Cassette reference plate

Tension regulator slantness check tool

Check procedure:

- (1) Install the cassette reference plate in the cassette position.
- (2) Place the tension regulator slantness check tool at the CTL head as shown in figure. Check that the slantness of the CTL head meets the required specification.

Adjustment procedure:

When the zenith is out of spec.

- (1) Loosen the fixing screw 1 turn.
- (2) Adjust the zenith with adjusting screw (C) to meet the required specification.
- (3) Tighten the fixing screw and check the azimuth and zenith.


. When the azimuth is out of spec.

- (4) Loosen the fixing screw 1 turn.
- (5) Adjust the azimuth with adjusting screw (D) to meet the required specification.
- (6) Tighten the fixing screw and check the azimuth and zenith.

- (7) After adjustment, perform the following adjustment.

Sec.9-9. CTL Head Height Adjustment

Sec.9-5. CTL Head Position Adjustment



9-9. CTL HEAD HEIGHT ADJUSTMENT

Mode: Playback the alignment tape

Tool: Alignment tape, CR5-1PS

Oscilloscope

Preparation:

- (1) Remove the SV-51 board. Extend it with extension board.
- (2) Connect the oscilloscope as follows:
CH-1 : TP302/SV-51 board
TRIG : INTERNAL, CH-1
- (3) Insert the alignment tape, and playback the audio 0.8kHz signal portion that is recorded on the CTL track of the alignment tape.

Check procedure:

- (1) When pressing down and pushing up the tape at (A) portion, check that the both levels decrease. If the levels increase, the following adjustments are required.

Adjustment procedure:

- When the levels increase while pressing down the tape at (A) portion.

- (1) Loosen the fixing screw 1 turn.
- (2) Turn the adjusting screw (D) in the counterclockwise direction and turn the adjusting screws (C) and (B) an exactly equal amount in the clockwise direction. Adjust for maximum output waveform.


- (3) Tighten the fixing screw and check again.

- When the levels increase while pushing up the tape at (A) portion.

- (4) Loosen the fixing screw 1 turn.
- (5) Turn the adjusting screw (D) in the clockwise direction and turn the adjusting screws (C) and (B) an exactly equal amount in the counterclockwise direction. Adjust the maximum output waveform.
- (6) Tighten the fixing screw and check again.
- (7) After adjustment, perform the following adjustment.

Sec.9-8. CTL Head Azimuth/Zenith Adjustment

Sec.9-5. CTL Head Position Adjustment



9-10. AUDIO/TC HEAD ZENITH ADJUSTMENT

Mode: Unthreading end

Tool: Flatness plate

Check procedure:

- (1) Check that the clearance between the head and the flatness plate meets the required specification, when the flatness plate is set on the audio/TC head and the TG-3.


Adjustment procedure:

If there is a clearance at the bottom portion.

- (1) Loosen the fixing screw 1/4 to 1 turn.
- (2) Turn the zenith height adjusting screw (R) in the clockwise direction to meet the required specification.
- (3) Tighten the fixing screw and check again.

If there is a clearance at the top portion.

- (4) Loosen the fixing screw 1/4 to 1 turn.
- (5) Turn the zenith height adjusting screw (R) in the counterclockwise direction to meet the required specification.
- (6) Tighten the fixing screw and check again.



9-11. AUDIO HEAD HEIGHT ADJUSTMENT

Mode: Playback the alignment tape

Tool: Alignment tape, CR5-1PS

Dual trace oscilloscope or VTVM

Preparation:



- (1) Connect the oscilloscope or VTVM to the AUDIO OUT CH-1 and CH-2.
- (2) Playback the audio 1kHz signal portion of the alignment tape.

Check procedure:

- (1) When pressing down the tape at (a) portion, check that the level decreases.
- (2) When pushing up the tape at (b) portion, check that the level decreases.

Adjustment procedure:

- When the level increase while pressing down the tape at (a) portion.
 - (1) Loosen the fixing screw 2 to 3 turns.
 - (2) Turn the zenith height adjusting screws (R) and (F) in the counterclockwise direction and turn the azimuth adjusting screw an exactly equal amount in the clockwise direction. Adjust for maximum output waveform.
 - (3) Tighten the fixing screw and check again.
- When the level increases while pushing up the tape at (b) portion.
 - (4) Turn the zenith height adjusting screws (R) and (F) in the clockwise direction and turn the azimuth adjusting screw an exactly equal amount in the counterclockwise direction. Adjust for maximum output waveform.
 - (5) Tighten the fixing screw and check again.



9-12. AUDIO HEAD TAPE-TO-HEAD CONTACT ADJUSTMENT

Mode: Playback the alignment tape

Tool: Alignment tape, CR5-1PS


Oscilloscope or VTVM

Preparation:

- (1) Connect the oscilloscope or VTVM to AUDIO OUT CH-2 terminal.
- (2) Playback the 10kHz portion of the alignment tape.

Adjustment procedure:

- (1) Loosen the mounting screw of the audio head 1/4 turn.
- (2) Insert a flatblade screwdriver, 3mm dia. into the hole as shown in figure. Adjust the audio head block where the output is maximum and starting to decrease.
- (3) Set the audio head block on the middle portion of two points and tighten the fixing screws.



9-13. AUDIO HEAD PHASE ADJUSTMENT

Mode: Playback the alignment tape

Tool: Alignment tape, CR5-1PS

Dual trace oscilloscope

Preparation:


- (1) Connect the horizontal and vertical terminals of the oscilloscope to AUDIO OUT CH-1 and CH-2 terminals.
- (2) Playback the audio 10kHz portion of the alignment tape.
- (3) Adjust the scope for horizontal and vertical amplitudes of 6cm of a lissajous waveshape.

Check procedure:

- (1) Check that the vertical amplitude at the center in the horizontal direction is within the specification.
- (2) The lissajous waveshape meets the required specification at 1kHz.

Adjustment procedure:

- (1) Loosen the fixing screw 1/4 to 1/2 turn.
- (2) Turn the azimuth adjusting screw to meet the required specification.
- (3) Tighten the fixing screw and check again.



9-14. PINCH ROLLER PRESSURE TIMING ADJUSTMENT

This adjustment is closely related with the accuracy of the tape-to-tape editing.

Therefore, this adjustment should be attempted carefully, and deliberately.

Tool: Oscilloscope

Preparation:


- (1) Remove the SY-91 board. Extend it with extension board.
- (2) Connect the oscilloscope as follows:
CH-1 : TP12/SY-91 board
TRIG : INTERNAL, CH-1

Check procedure:

- (1) Press the STOP button.
- (2) Press the PLAY button. Check that waveform meets the required specification.

Adjustment procedure:

- (1) Adjust RV1 on SY-91 board to meet the required specification.
Turn to right : time period make long.
Turn to left : time period make short.



9-15. SLIP-RING AND BRUSH POSITION ADJUSTMENT

Adjustment procedure:

- (1) Loosen the fixing screws of the brush block and disengage the brush from the slip-ring. Tighten the fixing screws.
- (2) Adjust the height of the brush so that the brush is positioned in the center of the two rings.
- (3) Loosen the fixing screws of the brush block again. Adjust the position of the brush to meet the specification.

